



Rinstrum R423 Panel Mount Indicator Instruction Manual

[Home](#) » [rinstrum](#) » Rinstrum R423 Panel Mount Indicator Instruction Manual 

Contents

- [1 Rinstrum R423 Panel Mount Indicator](#)
- [2 Installation Instructions](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)




Rinstrum R423 Panel Mount Indicator




Installation Instructions

R423 PANEL MOUNT INDICATOR INSTALLATION



- Recommended tightening torque range for the M4 hex nuts: 1.3Nm – 2.8Nm

Documents / Resources



[Rinstrum R423 Panel Mount Indicator](#) [pdf] Instruction Manual
R423 Panel Mount Indicator, R423, Panel Mount Indicator, Mount Indicator