Manuals+ — User Manuals Simplified.

RIPTUNES AS500BT Bluetooth Speaker User Guide

Contents

**RIPTUNES AS500BT Bluetooth Speaker**

Specification:

Bluetooth Speaker with crisp treble and deep acoustics TWS; ability to pair speakers simultaneously Bluetooth version: 5.0 up to 33' (10meters) Bluetooth distance: 10M

- Speaker power: 5W RMS
- 4 ways to play music: USB/BT/Micro-SD/AUX Built-in MIC for Hands-free calling 6 colors LED ambient lights
- Rechargeable battery: 1200mAh
- Material: ABS
- Measures; 4.65"x4.65"x5.35"H (118x118x136mm)

Includes:
AS500BT Bluetooth speaker, USB charging cable, User Manual

Identifying the buttons/controls and ports:

1. Power ON/OFF
2. Play/Pause
3. Volume up/Next song
4. Volume down/Previous song
5. Mode switch
6. USB playback
7. Aux-in port
8. Micro USB charging port
9. Micro-SD card slot

- **Getting started:**
    - Before the first time use, please fully recharge the battery. Do not play music while charging battery.
    - Please use only a DC-5V certified power adapter and cable to charge your speaker.
    - If experiencing intermittent sound while playing music, it may be caused by lack of power, please fully recharge the speaker.
    - To play music via Bluetooth, activate the Bluetooth feature on your source device phone/laptop/tablet/MP3 player, and set the device to search for wireless device.

- **Know the functions of each button: ON/OFF Button:**
    - Power On/Off; Press and hold for 3 seconds to turn on/off the speaker.
    - Bluetooth Pairing; When powering on the speaker, a sound will indicate "Bluetooth mode". Activate the Bluetooth feature on your source device phone/laptop/tablet/MP3 player, and set it to search. Wait for your new speaker "AS500BT" to appear, then press connect to pair and connect.
    - LED light control; Short press to change the light color/mode, total of 6 colors lighting/modes. Short press in sequence until the lights will turn off.
- **M Button:**
    - Mode; Short press to switch between BT/USB/micro-SD/Aux-in modes.
    - TWS; Press and hold for several seconds to connect/disconnect TWS.

- **TWS Function (2-speakers required)**
  Prepare 2 speakers and turn them ON, Press & Hold the M button of either of the 2 speakers to connect TWS. When tone will prompt indicating that the TWS connection is successful. At this time, your phone will only show one Bluetooth name, select to pair and connect, now you can enjoy two speakers playing music at the same time. Press & Hold the M button again to disconnect the TWS.
- **Play/Pause Button:**
    - Click to pause or play music
    - For incoming calls, click to answer the call, click again to hang up the call

- Double click in short time to redial the last number.
- Hold the button for 2 seconds to reject the phone call.

- **Volume↑/Next Button:**

  Press & Hold to increase the volume Short press to change to next music file

- **Volume↓/Previous Button:**

  Press & Hold to decrease the volume Short press to change to previous music file

- **USB/micro-SD Card Reading:**

  Insert the USB drive/micro-SD card into their slot to play MP3 files automatically. Adjust volume or switch to previous/next music files by following instructions above

- **Aux-in Mode:**

  Insert a 3.5mm audio cable (not included) into the AUX port and connect the other end of the 3.5mm cable into your music source device such as phone/laptop/tablet/MP3/audio player. A sound will prompt indicating the AUX connection is successful.

- **Charging:**

  Connect the small end of the Micro USB charging cable (included) to the Micro USB port located on the speaker. Connect the larger end of the cable to an AC adaptor (not included) or to a USB port on your computer. The LED indicator will turn red while charging. Once fully charged, the red LED will turn off.

- **Safety instructions:**

  - Do not disassemble, damage, or dispose this Product. Consult your local waste collection agency for proper disposal or recycling methods.
  - This product is not a toy. Use extra caution while children are using this product.
  - Keep the Speaker away from direct sunlight, fire, and from high voltage equipment. Do not store the Speaker inside a car during hot weather. Remember; a closed car acts as a greenhouse allowing the inside temperature to possibility reach over 200 degrees. Device may become warm while charging. Be assured Power is completely turned off when plugging and unplugging into a power outlet. Damage, shock, and/or injury can occur if this warning is not heeded properly.

- **Technical Support**

  Visit our website below to find answers to frequently asked questions, updated versions of this user's manual and/or contact information. **www.rip-tunes.com**

  Bluetooth is a registered trademark of Bluetooth SIG, INC. Important: Be sure to register your product within 14 days of purchase at **www.rip-tunes.com/register** for warranty purposes

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

- Consult the dealer or an experienced radio/TV technician for help.

Caution:
Any changes or modification to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

RIPTUNES AS500BT Bluetooth Speaker [pdf] User Guide
825500, 2AIO5-825500, 2AIO5825500, AS500BT Bluetooth Speaker, AS500BT, Bluetooth Speaker

References

- 🌐 **Search Page**
- 🎼 **Riptunes**
- 🎼 **Riptunes**