

RK ROYAL KLUDGE RK61 Wireless Mechanical Keyboard User Manual

Home » RK ROYAL KLUDGE » RK ROYAL KLUDGE RK61 Wireless Mechanical Keyboard User Manual



Contents


- 1 RK ROYAL KLUDGE RK61 Wireless Mechanical
- **Keyboard**
- **2 INTRODUCTION**
- **3 WIRELESS MODES**
- **4 SPECIAL FUNCTION KEYS**
- **5 Function Key Switch**
- **6 MULTIMEDIA KEY FOR WINDOWS**
- 7 Documents / Resources
- 7.1 References
- **8 Related Posts**




RK ROYAL KLUDGE RK61 Wireless Mechanical Keyboard



INTRODUCTION



Keyboard





Size 291(L)×101(W)×39.5(H)±2mm

Layoyt 61Key


Backlight Led

Switch Mechanical switch

Type-C Cable


User Manual

WIRED MODE & CHARGING




WIRELESS MODES

1. BT Connection




2. Ghz Connection



BACKLIGHT CONTROL




SPECIAL FUNCTION KEYS




Function Key Switch


• Press Fn + Enter Enter Arrow Keys Function



• Press Fn + Enter Again Quit Arrow Keys Function




SPECIAL FUNCTION KEYS




MULTIMEDIA KEY FOR WINDOWS

- In Windows mode FN + A: switch In Windows system
- FN + Left Ctrl (The primary key function and the second function of the composite key are interchanged)



- MAC system FN + S: switch to MAC system
- FN+Left Ctrl (The primary key function and the second function of the composite key are interchanged)



SYSTEM REQUIREMENTS BT Mode

- Device With Bluetooth 3.0 or later
- PC: Windows 7 or Later
- Android: 5.0 Lollipop or Later Wired/2.4Ghz Mode
- Computer With Available USB port
- PC: Windows 7 or Later
- **Mac**: macOS X 10.6 Snow Leopard or Later No operation on for 5 minutes, keyboard in standby, wake-up keyboard only need to press any key.

RK ROYAL KLUDGE RK61 Wireless Mechanical Keyboard [pdf] User Manual

166-83002-2161, 166-83002-21, RK61 Wireless Mechanical Keyboard, RK61, Wireless Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

• <u>User Manual</u>

Manuals+, Privacy Policy