



Roadie COACH Music Tutor Smart Recorder and MIDI Controller User Guide

[Home](#) » [Roadie COACH](#) » Roadie COACH Music Tutor Smart Recorder and MIDI Controller User Guide 

Contents

- 1 Roadie COACH Music Tutor Smart Recorder and MIDI Controller
- 2 Product Information
- 3 Product Usage Instructions
- 4 Hard Reset
- 5 MEET YOUR COACH
- 6 ATTACH COACH
- 7 TROUBLESHOOT
- 8 INSIDE THIS BOX
- 9 RECORD WITH COACH
- 10 FIND RECORDINGS
- 11 DOWNLOAD THE COACH MOBILE APP
- 12 PAIR TO THE APP
- 13 MANAGE TRACKS
- 14 LEARN WITH THE COACH APP
- 15 SAFETY INSTRUCTIONS
- 16 FCC Statement
- 17 WARRANTY
- 18 Documents / Resources
 - 18.1 References



Roadie COACH Music Tutor Smart Recorder and MIDI Controller



Product Information

- **Product Name:** Roadie Coach
- **Website:** www.roadiemusic.com
- **Quickstart Guide:** www.roadiemusic.com/downloads/coach-guide
- **Troubleshooting Tutorial for Round Back Instruments:** www.roadiemusic.com/tutorials/round-back
- **Mobile App:** Roadie Coach App (available for download)

Product Usage Instructions

Attach Coach

1. Select the most appropriate clamp size for your instrument and make sure the flat pad is attached to it.
2. Open the clamp latch.
3. Insert the clamp to the desired length.
4. Hold the Coach tightly on your instrument.
5. Close the latch to secure the clamp.
6. **Note:** For round-back instruments, switch the flat pad for the ball-head attachment. Refer to the tutorial here for detailed setup instructions.

Record with Coach

1. Turn Coach ON and click on Recorder on the home screen.
2. To perform a sound check, press “S. Check” or directly press “Start recording now!” to begin recording.
3. Adjust the gain using the sliders to avoid clipping. Tap on the icons to change inputs.
4. Recording will start after the countdown. Change gains using the sliders or press the stop button to stop recording.

Find Recordings:

1. Recorded tracks will show in Recorder. You can scroll down to access older recordings.
2. Press on any recording to enter playback mode. Here, you can also delete the track or adjust the input volumes.
3. To adjust input volumes, click on “Mic” or “Master” and adjust the sliders accordingly.

Factory Reset

Warning: Factory reset deletes all of your data and resets your device to factory settings.

1. Access the Settings from the home screen, and then select General.
2. Scroll all the way down to “Factory Reset”.

Hard Reset


If your Roadie Coach is frozen, a hard reset may be required. It will not delete your data.

1. To perform a hard reset, enter a pin into the reset pinhole at the back of the Coach.

Download the Coach Mobile App


Download the free Roadie Coach app to manage your recordings easily and access Coach’s educational content. The app includes a library of free public-domain songs and an optional in-app subscription for unlimited access to all licensed songs.

MEET YOUR COACH




ATTACH COACH

1. Select the most appropriate clamp size for your instrument and make sure the flat pad is attached to it
2. Open the clamp latch
3. Insert the clamp to the desired length
4. Hold Coach tightly on your instrument.
5. Close the latch to secure the clamp



Note: For round back instruments, switch the flat pad for the ball-head attachment. For a detailed explanation of how to set it up, watch the video linked to the QR code below.



www.roadiemusic.com/tutorials/round-back



TROUBLESHOOT

FACTORY RESET

Before performing a factory reset, make sure you have installed the latest firmware and that the issue is still persisting.



1. Access the “Settings” from the home screen, and then select “General”




2. Scroll all the way down to “Factory Reset”

Warning!

- Factory reset deletes all of your data and resets your device to factory settings.


HARD RESET

- If your Roadie Coach is frozen, a hard reset may be required. It will not delete your data.




- To perform a hard reset, enter a pin into the reset pinhole at the back of the Coach


INSIDE THIS BOX




RECORD WITH COACH




1. Turn Coach ON and click on "Recorder" on the home screen




2. To perform a sound check, press on  To record, press on  and continue to step 4



3. Adjust the gain using the sliders to avoid clipping. Tap on the icons to change inputs



4. Recording will start after the countdown. Change gains using the sliders or press the stop button to stop recording




FIND RECORDINGS




1. Recorded tracks will show in “Recorder”. You can scroll down to access older recordings



2. Press on any recording to enter playback mode. Here, you can also delete the track or adjust the input volumes (refer to step 3)



3. Click on  to enter the mixing screen and adjust the input volumes

Notes:

- When recording two inputs, the file will be saved as stereo with one input on the left channel and the other on the right channel.
- You can also connect Coach to your PC/MAC via USB to retrieve your recordings.

DOWNLOAD THE COACH MOBILE APP

Download the free Roadie Coach app to manage your recordings easily and access Coach's educational content. The library includes free public domain songs and an optional in-app subscription for unlimited access to all licensed songs.

www.roadiemusic.com/coach-app




PAIR TO THE APP



1. Launch the mobile app and click on "Set up a Roadie Coach"
2. Follow the on-screen instructions. You only need to do this once

MANAGE TRACKS




1. Once your Coach is paired (see “Section 6”) and turned on, press the “My Coach” button on the home screen
2. Select any track to listen to it or download it. Downloaded tracks will appear under the “Recordings” section on the home screen

LEARN WITH THE COACH APP

Make sure Coach is paired to the app and that it is turned on (see “Section 6”)





1. Launch the app and press on “More Songs” to see all the songs
2. Choose the song you would like to learn
3. Pick a level and start practicing
4. streaming” screen will automatically appear on your Coach
 - **Note:** For a more accurate scoring of both your playing and singing, adjust the gain of the microphones to avoid clipping or insufficient audio pick up.
5. Practice following the in-app guidance and enjoy the feedback!

GET MORE GUIDANCE

For the full user manual & FAQs, visit www.roadiemusic.com/support



- f • Roadieofficial
- t • Roadieofficial
- g • Roadieofficial
- Roadieofficial
- Roadieofficial
- Roadiemusicofficial
- www.roadiemusic.com

SAFETY INSTRUCTIONS

- Please read these instructions, keep them and follow them.
- Do not tamper with your device.

- Do not attempt to disassemble or open your device. Substances contained in this product and/or its battery may damage the environment and/or human health if handled and disposed of improperly.
- Do not expose your device to extremely high or low temperatures.
- Do not leave your device in direct sunlight for an extended period of time.
- Do not leave your device near open flames.
- Do not dispose of your device in a fire. The battery could explode.
- Do not use abrasive cleaners to clean your device.
- Do not place your device in a dishwasher, washing machine or dryer.
- Regardless of what reasons cause unit damage, please ask for the maintenance personnel to repair it.

FCC Radiation Exposure Statement

- This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 10mm between the radiator and your body.

FCC Statement

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Statement

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

ISED Radiation Exposure Statement

The equipment complies with ISED Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 10mm between the radiator and your body.

Caution

The battery shall not be exposed to excessive heat such as sunshine, fire or the like. Danger of explosion if

battery is incorrectly replaced. Replace only with the same or equivalent type.

Correct disposal of this product

This marking indicates that this product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

Operating temperature 32-104°F (0-40°C).

Disclaimer

This manual describes the version of Roadie as of July 2023. Although Band Industries has made every effort to ensure that the information contained in it was correct at publish time, it does not assume and hereby disclaim any liability to any party for any loss, damage or disruption caused by errors or omissions, whether such errors or omissions result from negligence, accident or any other cause. The information in this Product Manual is subject to change without notice.

Band Industries makes no representations or warranties with respect to the content hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose.

Band Industries reserves the right to revise this publication and to make changes from time to time in the content hereof without the obligation of Band

Industries to notify any person of such revisions or changes.

Copyright

This publication, including all photographs, illustrations, and software, is protected under international copyright laws, with all rights reserved.

Neither this Product Manual nor any of the material contained herein may be reproduced without written consent of Band Industries.

Trademark recognition

Band Industries, the Band Industries logo, Roadie, Roadie Coach, and the Roadie Coach Logo are trademarks and/or registered trademarks of Band Industries, Inc. in the US, EU, and other countries.


WARRANTY

- Your Coach has a 1-YEAR WARRANTY.
- To claim the warranty, contact our support team





GET SUPPORT

- Reach out to us anytime at [SUPPORT.ROADIEMUSIC.COM](mailto:support@roadiemusic.com)
- **Model Number:** RC100
- **EU Importer:** CCS Express GmbH
- **Address:** Lilienthalstr. 8, 85399 Hallbergmoos, Deutschlandz
- **UK Importer:** A.C.T.S Global Ltd No. 07162744.
- **Address:** 3rd Floor, Norvin House, 45-55 Commercial
- StreetLondon E1 6BD, UK

Documents / Resources

	Roadie COACH Music Tutor Smart Recorder and MIDI Controller [pdf] User Guide RC100, 2ACJ6RC100, 2ACJ6RC100 rc100, Music Tutor Smart Recorder and MIDI Controller, Music Tutor, Smart Recorder, MIDI Controller
---	--

References

-  [Roadie Music's Automatic Tuners | Fast, Easy, Accurate](#)
-  [Roadie Music's Automatic Tuners | Fast, Easy, Accurate](#)
-  [Roadie Music's Automatic Tuners | Fast, Easy, Accurate](#)
-  [Support : Roadie Music](#)

Manuals+.