


ROBO-TEK Robo-Plus V2 Robotic Pool Cleaner



ROBO-TEK Robo-Plus V2 Robotic Pool Cleaner Instruction Manual

[Home](#) » [ROBO-TEK](#) » ROBO-TEK Robo-Plus V2 Robotic Pool Cleaner Instruction Manual 

Contents

- 1 ROBO-TEK Robo-Plus V2 Robotic Pool Cleaner
- 2 OPERATING INSTRUCTIONS
- 3 What's in the Boxes?
- 4 WHAT TO DO POOLSIDE
- 5 AFTER USE
- 6 Remote Control Instruction
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts



ROBO-TEK Robo-Plus V2 Robotic Pool Cleaner



Specifications

- Product Name: Robo-Plus V2
- Brand: Robo-Tek
- Features: Remote control, extra filter bag, easy set up
- Usage: Pool cleaning

Easy Set Up – Box 2:

1. Remove the Control box, Remote control, extra Filter bag from the box.
2. Remove the robot from the caddy and place it in theater.

Robo-Plus V2

OPERATING INSTRUCTIONS

– April 2023

Firstly, thank you for choosing a Robo-Tek Pool Cleaner, and welcome to our family.

At Robo-Tek we put ourselves in your position.....and we don't like reading user guides either !

Please take 3 mins to read through these brief instructions to ensure trouble free use, and maximise the life span of your purchase.

What's in the Boxes?

1. Box 1

- Partly assembled Caddy cart.
- Box of screws and bolts.

2. Box 2

- 1 x Robo-Tek Robot
- 1 x Control box

- 2 Filter bags – (1x 70 Micron filter bag already fitted to the base plate and 1 x 20 micron filter bag for fine dust)
- 1 x remote control – (Battery already fitted)
- 1 x Impeller cover

EASY SET UP – Box 1

- Undo the Caddy Box
- Follow the instructions in the caddy box to assemble the caddy. (5 mins)
- You will have 2 long screws left over (for the control box)
- Place the caddy cart close by, we will need it again shortly

EASY SET UP – Box 2

- Remove the Control box, Remote control, extra Filter bag from the box.
- Remove the robot from the box.
- Cut the cable tie off the floating cable.
- Attach the Control box to the Caddy, using the 4 long screws left over from the Caddy Cart assembly.
- Place the robot on the caddy, and wheel to the pool.

WHAT TO DO POOLSIDE



- Remove the robot from the caddy and place in the water.
- Turn the robot over to release excess air bubbles...
- Squeeze the wheels to make them completely saturated.

NOTE:


If it doesn't sink right now....don't stress, we will sort that out a bit further down the page).

- Unroll the floating cable, and lay it in an "S" shape on the deck.

NOTE: (Don't throw all the cable in the pool...Let the robot take what it needs)

- Unscrew the socket safety cap from the side of the control box.
- Insert the floating cable plug (aviation plug) into the socket on the side of the control box .
- Wheel the caddy close to the power point. (Tether the caddy to a fence / pole if you have not connected the control box directly to a fixed power supply 3m from the pool).
- Turn the power on at the wall, and ensure the RED standby light on the control box illuminates. (otherwise check your power point)
- Press the red button on the control box (or remote control ).
- Select the 0.5hr time cycle (30mins ).
- The control box will beep.....Then the wheels on the robot will start to move, then the pump will engage and drive the robot to the bottom of the pool.

NOTE: If the robot is not fully submerged, when you start the robot, push the robot under the water as soon as the pump starts.

The default mode is floor only  (Blue Light for Floor only, changes to Green Light when in Climbing mode).

1. Let it clean the floor for the first 30mins.
2. Then : Stop the robot, remove it from the pool, empty the filter bag and then you can put on the climb mode.

NOTE: If you pool has a lot of dirt/leaves on the floor, we recommend you stop the robot before the 30mins and empty the filter bag. (this is only required when recovering a pool from a poor state).

AFTER USE

- Remove the robot from the pool, remove the impeller cover, check for and remove any debris from around the impeller.
- Remove the floating cable from the control box.
- Turn the robot upside down (preferably onto a mat so as not to scratch the handles).
- Remove the base plate.
- Remove and clean the filter-bag.
- Rinse the inside of the robot (optional but recommended).
- Re-insert the filter bag and base plate (if the locks don't slide easy, the filter bag is not fitted correctly.... Remove and refit...

Note: The Short side TAG goes on the shortest side of the base plate (Tag on the outside).

- Place the robot on the caddy, Sponge wheels rest on the Caddy frame(Not the drive belts) .
- Refit the impeller cover.
- Roll up the floating cable in big loops and store on the caddy bracket.
- Wheel the caddy into the garage or other protected area until next required.

NOTE: You need to run your filter everyday... But you only need to run your ROBO when you think the floor is too dirty for you.

Remote Control Instruction



Short Press will reverse direction of robot.



Long Press until robot turns then release.



Press to change time cycle.



Power on/off.




Not used.



Short Press will turn On/Off the climb mode.

For a full user guide go to <https://www.robotek.com.au/usermanuals> For any assistance call 03 9357 5662 we are here to help!

Documents / Resources

	<p>ROBO-TEK Robo-Plus V2 Robotic Pool Cleaner [pdf] Instruction Manual Robo-Plus V2 Robotic Pool Cleaner, Robo-Plus V2, Robotic Pool Cleaner, Pool Cleaner</p>
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.