



ROCCAT MAGMA Keyboard User Guide

[Home](#) » [ROCCAT](#) » ROCCAT MAGMA Keyboard User Guide

Contents [[hide](#)]

- [1 ROCCAT MAGMA Keyboard](#)
- [2 Instructions](#)
- [3 FCC CAUTION:](#)
- [4 TECHNICAL FACTS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)


ROCCAT MAGMA Keyboard

QUICK START GUIDE

[Download Driver](#)
[ROCCAT® Talk® FX](#)



ADDITIONAL FN-LAYER FUNCTIONALITY (PRESS FN-KEY + SECOND KEY)
(no driver installed)



STANDARD

- FN +F5** = Volume down
- FN+F6** = Volume up
- FN +F8** = Volume Mute
- FN +F9** = Previous Track
- FN +F10** = Stop
- FN +F11** = Play/Pause
- FN +F12** = Next Track
- FN +SCROLL** = Activate Game Mode (Key Assignments and deactivate Windows key)
- FN + CURSOR UP** = Backlight brightness +
- FN + CURSOR DOWN** = Backlight brightness –

Instructions

1. For a more ergonomic position, fold out the stands on the base of the keyboard.
2. Plug the ROCCAT Magma's USB connector into any free USB port.
3. Start your computer and connect to the internet.
4. Navigate to www.roccat.org/roccat-swarm and download the latest version of Swarm.
5. Start the software installation process and follow the on-screen instructions



D3D362
RoHS



R-R-VTB-COREMEM



Disposal information

The crossed-out wheeled-bin symbol means that you must not dispose of this product together with unsorted household waste. As electrical devices can contain harmful substances which may cause environmental damage or harm to your health if not disposed of correctly, please dispose of these products separately. As the end user, you are required by law to dispose of used electrical equipment at an official recycling point. For information about local recycling points, contact your local authority, civic amenity site, or the business where you purchased this product. By disposing of electrical products at an official recycling point, you are doing your bit to ensure equipment is recycled correctly and professionally, and our environment is protected.

When purchasing a new product, the retailer will let you hand in old products and dispose of them free of charge provided the product you are handing in is of a similar type and has the same functions as the product you are purchasing. You can hand in small used electrical and electronic equipment (measuring no longer than 25 cm on

any one side) for free and with no obligation to purchase a similar product at electrical and electronic retail outlets with sales areas larger than 400m² or at nearby recycling points designated by the retail outlet. Wherever possible, remove any batteries before disposing of the device. Under law, as a user you face the risk of penalties if you dispose of devices and batteries illegally.

FCC CAUTION:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation

GENERAL SAFETY GUIDELINES AND INTENDED USE

1. Do not open or modify the product.
2. Not approved changes or modifications may void the operation authority and/or warranty.
3. In case of trouble or doubt, contact us immediately.
4. Keep the product away from fire/water/humidity/temperature extremes.
5. Only use as intended with a compliant PC and connector part.
6. Improper or incorrect use of the product or use of the product for purposes
Not recommended by the manufacturer void the liability and/or warranty.
7. Don't look into the light beam on bottom of the mouse.

Hereby, Voyetra Turtle Beach Inc. declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU.

The full Declaration of Conformity can be requested via following:

Company: Voyetra Turtle Beach, Inc.

Address: 44 South Broadway, 4th Floor, White Plains NY 10601, USA

E-Mail: support@roccat.org

VOYETRA TURTLE BEACH, INC. | 44 SOUTH BROADWAY, 4TH FLOOR, WHITE PLAINS NY 10601, USA

© 2021 Voyetra Turtle Beach, Inc. All rights reserved. Any product names mentioned in this manual may be trademarks or registered trademarks and are the property of their respective owners. Information contained herein is subject to change without notice. Voyetra Turtle Beach, Inc. shall not be made liable for any errors that may appear in this manual. This publication or parts of it may not be reproduced without the express consent of the publisher.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Join the community

Become a ROCCAT member and **register your product** at: www.roccat.org/support/register-your-product

Service & support

Easy access to
customer support

Authenticity check

Make sure you
own an original

Exclusive deals

Opt-in for special offers and downloads

Please use your product's serial number (located on the bottom label)

TECHNICAL FACTS

TECH SPECS MAGMA

- Membrane keyboard
- Transparent front plate
- 5 AIMO light zones with 2 LEDs each
- 7 shared media control keys
- 26 keyroll over
- 1.8m USB cable
- Gaming Profile
- Weight: 870g
- Dimensions: 452 x 157 x 39mm

SYSTEM REQUIREMENTS


- Windows? 7, 8 and 10 (software support)
- USB 2.0 (or higher)
- Internet connection (for driver software)

Should you need assistance ...

Our support team is ready to help you with any technical questions.

Just send an e-mail to support@roccat.org or visit our website at: WWW.ROCCAT.ORG/SUPPORT

Documents / Resources

	<p>ROCCAT MAGMA Keyboard [pdf] User Guide MAGMA Keyboard</p>
---	--