

rocstor®

**Y1RB033-B1 Built In
3 In 1 Combination
Security Laptop
Lock**



rocstor Y1RB033-B1 Built In 3 In 1 Combination Security Laptop Lock Instruction Manual

[Home](#) » [rocstor](#) » rocstor Y1RB033-B1 Built In 3 In 1 Combination Security Laptop Lock Instruction Manual 

Contents

- [1 rocstor Y1RB033-B1 Built In 3 In 1 Combination Security Laptop Lock](#)
- [2 Reset Combination](#)
- [3 Locking Tip Adjustment](#)
- [4 Lock](#)
- [5 Unlock](#)
- [6 Removable Rubber Grommet](#)
- [7 Record Your Combination](#)
- [8 Technical Support](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)

rocstor®

rocstor Y1RB033-B1 Built In 3 In 1 Combination Security Laptop Lock



Rocbolt Universal Switchable Built-in 3-IN-1 Combination Security Laptop Lock – 4-Digit Resettable Lock – For Standard K-Slot, Nano, and Noble WedgeSlots – 6.6 ft Steel 5mm Cable – TAA

Congratulations!

On your new Rocstor Rocbolt Universal Switchable Built-in 3-IN-1 Combination Security Laptop Lock – 4-Digit Resettable Lock – For Standard K-Slot, Nano, and Noble Wedge Slots – 5mm Carbon Steel Cable – 360-Degree Swivel Head Rotation – With 6.6 ft Heavy-duty Cable – TAA Compliant


Reset Combination

1. Reset combination from 0-0-0-0.
2. Press down the Reset Button and turn 90° clockwise to set your own combination.
3. Turn the Reset Button 90° counterclockwise back to its original position. Keep your combination in a safe and accessible place for future reference.


Locking Tip Adjustment

Use a small flathead screwdriver or similar tool to switch the knob. Adjust the locking tip according to the lock slot specification of your device


Noble Slot



Nano Slot



Standard Slot



⚠ The Knob can only be switched when the lock is unlock.


Lock




Lock

1. Wrap your cable around an immovable object, by crossing the lock body, through the loop, on the opposite end of the cable.
2. Adjust the locking tip according to the lock slot specification of your device.


①




②



Noble



Nano




Standard


You must adjust the locking tip **before** inserting the lock into your device.


3. Press the release button and insert the locking tip into the slot.
4. Scramble the dials to lock the device

③



④






Unlock




Unlock


1. Turn the dials to the combination you set.
2. Press the release button to release the lock

①




②






Removable Rubber Grommet


For computers that have a tighter security lock fit, it is necessary to remove the grommet on the cable lock.



Record Your Combination



OR



- locks.rocstor.com

Technical Support

- Technical support is available to all registered users of Rocstor products.
- Technical Support contact information can be found on www.rocstor.com

Telephone Support

There is no charge for technical support except long-distance charges where applicable. Please visit www.rocstor.com Monday to Friday 9:00 am to 6:00 pm Pacific Standard Time.

Technical Support


- +1 [818-727-7000](tel:818-727-7000) – Office
- +1 [818-875-0002](tel:818-875-0002) – Fax

- support@rocstor.com

limited Two Year Warranty

Rocstor warrants this product against defects in material and workmanship for five years. Rocstor will supply, at its option, comparable new and rebuilt replacements for defective parts and will pay the labor charges to repair the product found to be defective. The dated bill of sale as evidence of the original purchase price along with the defective product is required. ©2024 Rocstor, Inc. Rocstor is a registered trademark of Rocstor, Inc. Kensington and Nanosaver is a registered trademark of Acco Brands Corporation. Wedge Lock is a trademark of Noble Security, Inc. All other trademarks, service marks, and trade names referenced in this document are the property of their respective owners. We reserve the right to make changes without further notice to a product or system described herein to improve reliability, function, or design.

Documents / Resources

	rocstor Y1RB033-B1 Built In 3 In 1 Combination Security Laptop Lock [pdf] Instruction Manual Y1RB033-B1, Y1RB033-B1 Built In 3 In 1 Combination Security Laptop Lock, Built In 3 In 1 Combination Security Laptop Lock, 3 In 1 Combination Security Laptop Lock, Combination Security Laptop Lock, Security Laptop Lock, Laptop Lock, Lock
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.