

RØDE Charge Case



RØDE Charge Case User Guide

[Home](#) » [Rode](#) » RØDE Charge Case User Guide 

Contents

- [1 RØDE Charge Case](#)
- [2 Specifications](#)
- [3 Introduction](#)
- [4 FCC](#)
- [5 MORE INFO](#)
- [6 Frequently Asked Questions](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

RØDE

RØDE Charge Case



Specifications

- Product: Wireless GO (Gen 3)
- Charging Case: Charge Case+
- Charging Port: USB-C
- LED Indicators: Blue, Green, Amber, Red

Introduction

1. Place each of your Wireless GO (Gen 3) units into the Charge Case+, ensuring the receiver is placed in the slot marked 'RX'.
2. When the charging case isn't connected to power, its LED will be solid blue when the case is charging any of the units placed inside of it.
3. Press the button next to the LED to display the case's internal battery status:
 - **a.** Solid green = healthy charge
 - **b.** Amber = low charge
 - **c.** Red = very low charge
 - **d.** Flashing red = critically low charge.
4. You can top up the case's internal battery while simultaneously charging your mounted transmitters and receivers by connecting the case to a power source via USB-C (the case's LED will flash green while its internal battery is charging and turn solid green when fully charged).
5. With your transmitters and receivers mounted in the case, connecting it to a computer via USB-C allows you to update the firmware of your Charge Case+ and Wireless GO (Gen 3), as well as access settings and on-board recordings of your Wireless GO (Gen 3) using RØDE Central. rode.com/apps/rode-centr



- To prevent possible hearing damage, do not listen at high volume levels for long periods

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation

Please note that changes or modifications of this product are not expressly approved by the party responsible for compliance, and could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MORE INFO

- CAN ICES-003 (B) / NMB-003 (B)
- Company Name: RØDE LLC
- Address: 2745 Raymond Ave, Signal Hill CA 90755, USA
- Telephone Number: +1 562 364 7400
- RØDE Microphones:
- 107 Carnarvon St, Silverwater NSW 2128, Australia

Authorised UK Representative:

- RØDE UK, Unit A, 23-25 Sunbeam Rd, London NW10 6JP, United Kingdom


Authorised EU Representative:

- RØDE EU, Neukirchner Str. 18, 65510 Hünstetten, Germany

SOUTH KOREA

- ID: R-R-R72-0557
- Company Name: RØDE Microphones
- Model: Charge Case Plus

- Country of Origin: Australia



Frequently Asked Questions

- **Q: How do I know if the internal battery of the Charge Case+ is fully charged?**
 - A: The LED on the case will turn solid green when the internal battery is fully charged.
- **Q: What should I do if the LED on the Charge Case+ is flashing red?**
 - A: A flashing red LED indicates a critically low charge. Connect the case to a power source via USB-C immediately to recharge.
- **Q: Can I charge the units without placing them in the Charge Case+?**
 - A: It is recommended to charge the units by placing them in the Charge Case+ for optimal performance and convenience.

Documents / Resources

	RØDE Charge Case [pdf] User Guide Charge Case, Case
--	--

References

- Ø [RØDE | Premium Microphones & Audio Equipment](#)
- Ø [RØDE Central | RØDE Companion App | RØDE](#)
- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.