




ROLL-A-SHADE RAS-4 4-6 Inch Contract Plus Roll Shade Installation Guide

[Home](#) » [ROLL-A-SHADE](#) » ROLL-A-SHADE RAS-4 4-6 Inch Contract Plus Roll Shade Installation Guide 

Contents

- [1 ROLL-A-SHADE RAS-4 4-6 Inch Contract Plus Roll Shade](#)
- [2 Specifications](#)
- [3 FAQs](#)
- [4 WHAT'S INCLUDED](#)
- [5 INSTALLATION](#)
- [6 TENSION DEVICE INSTALLATION INSTRUCTIONS](#)
- [7 CONTACT INFORMATION](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



ROLL-A-SHADE RAS-4 4-6 Inch Contract Plus Roll Shade



Specifications

- Product Name: Contract Plus+ Shade 4-6
- Manufacturer: Rollashade
- Phone: [888-245-5077](tel:888-245-5077)
- Website: www.rollashade.com

FAQs








Q: What should I do if the shade material tracks to one side?

A: Lower the shade until you see the metal tube and add layers of masking tape to correct any alignment issues.

Q: How do I adjust the tension device for smooth operation?

A: Follow the specific instructions provided for inside or outside mount installations and ensure that the chain is fully tensioned.


WHAT'S INCLUDED

Hardware Included					Tools Required	
						
Self Tapping Screws for Aluminum	Self Tapping Phillips Screws for Tension Device	Wood Screws (If requested)	Plastic Connectors	Metal Stop Balls	Drill	Phillips Head

INSTALLATION


Install Cassette Box

Pre-drill mounting holes in the top or back of the cassette box. Attach the cassette box to the window frame, window molding, or ceiling per diagram. Two screws must be installed in each end as shown. Additional screws should be used in the center if the cassette box is over 3 ft wide.




Install Shade

Insert the spring-loaded end of the shade into the round hole of the bracket. Next, on the other side of the shade, insert the hook arms of the clutch straight into the two hook arm receiver holes of the bracket. Gently pull down the clutch until the two hook arms have locked securely to the bracket. The bottom of the clutch should always point straight down.




Shade Adjustment (If Necessary)

Roll shade up and down to confirm the bottom rail is level and the material rolls up straight on the center tube. If the bottom rail is not level, lower the shade until you see the metal tube. Add layers of masking tape to the metal tube to the end that is too low until bottom rail is straight. If the material tracks to one side, lower the shade until you see the metal tube. Add layers of masking tape



Install Cassette Box Bottom Closure


Attach the bottom enclosure by hanging it on the front box hanger. Please note, the bottom closure should not interfere with the operating chain.



Install Chain Anchor

The chain anchor is a plastic piece that is attached to the chain to secure it from possible accidents. Position the chain anchor on the window frame so that the chain anchor and chain do not interfere with raising or lowering the shade. The chain anchor should be installed without stretching or pulling down on the chain. Leave a little play

through the chain anchor to allow the chain to pass freely. Do not twist or cross the bead chain. Secure the anchor with Phillips screws in both upper and lower holes.





Warning: Failure to use this device may cause injury or death



Young children can **STRANGLE** in cord and bead chain loops. They can also wrap cords around their necks and **STRANGLE**.


- Always keep cords and bead chains out of children's reach.
- Move cribs, playpens, and other furniture away from cords and bead chains. Children can climb furniture to get to cords.
- Attach the tension device to the wall or floor. This can prevent children from pulling cords and bead chains around their necks. Fasteners provided with the tension device may not be appropriate for all mounting surfaces. Use appropriate anchors for the mounting surface conditions.

WHATS INCLUDED




TENSION DEVICE INSTALLATION INSTRUCTIONS

INSIDE OR OUTSIDE APPLICATION



INSIDE MOUNT & TENSION DEVICE INSTALLATION


Pull the Chainhold down until the chain is fully tensioned (the plunger will be fully raised). Screw the device into wall



NOTE: Please make sure the shade operates smoothly

OUTSIDE MOUNT & TENSION DEVICE INSTALLATION

With provided screws, install the bracket first with large screws (use Chainhold marked screw hole locations as reference). Pull the chain down until the chain is fully tensioned (the plunger will be fully raised). Install Chainhold into a bracket with small screws.




NOTE: Please make sure the shade operates smoothly.

CONTACT INFORMATION

- Rollashade.com
- info@rollashade.com
- 951.245.5077



Documents / Resources



ROLL-A-SHADE RAS-4 4-6 Inch Contract Plus Roll Shade [pdf] Installation Guide

RAS-4, RAS-4 4-6 Inch Contract Plus Roll Shade, 4-6 Inch Contract Plus Roll Shade, Roll Shade, Shade

References

-  [Roll-A-Shade - Commercial Window Shade Solutions](#)
-  [Roll-A-Shade - Commercial Window Shade Solutions](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.