



Rollei LUMIS Key Light Desktop Bi-Color LED Panel User Manual

[Home](#) » [Rollei](#) » Rollei LUMIS Key Light Desktop Bi-Color LED Panel User Manual 

Contents

- [1 Rollei LUMIS Key Light Desktop Bi-Color LED Panel](#)
- [2 Before the First Use](#)
- [3 Safety Instructions](#)
- [4 Safety Instructions](#)
- [5 Components](#)
- [6 Setting Up the Rollei LUMIS Key Light](#)
- [7 Operation](#)
- [8 Technical Data](#)
- [9 Disposal](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)



Rollei LUMIS Key Light Desktop Bi-Color LED Panel



Before the First Use

Please read the operating instructions and the safety instructions carefully before using the device for the first time. Keep the operating instructions together with the device for future use. If you pass on the device to a third party, this manual is part of the device and must be supplied with the device.

Intended Use

This unit is designed for use as photo and video lighting only. It must not be used for other purposes and in particular not for domestic room lighting.

Explanation of Symbols

The following symbols are used in this manual, on the flash, Rollei LUMIS Key Light unit or on the packaging.



Products marked with this symbol comply with all relevant community regulations of the European Economic Area.



Products marked with this symbol are operated with direct current.

Safety Instructions

1. Only connect the product if the mains voltage of the USB input on the computer or USB power supply matches the information on the type plate on the back of the product.
2. Do not use the product if it is visibly damaged or if the cable is defective.
3. If the product or the accessories are damaged, they must be replaced or repaired by the manufacturer, its customer service or a similarly qualified person in order to avoid hazards.
4. The housing must not be opened and repairs may only be carried out by a specialist. To do this, contact a specialist workshop. In the event of repairs by the user, improper connection or incorrect operation, any liability and warranty claims are excluded.
5. Do not insert any objects into the product.
6. Do not leave the product unattended during operation.
7. Protect the product from moisture. Do not touch it with wet / damp hands and do not immerse it in water.


8. This product is not waterproof! Do not use this product in the rain or in wet areas.
9. Do not use or store the device at high or low temperatures or in closed rooms with direct sunlight. The product should not be used at ambient temperatures of more than 50°C or below -10°C.
10. Provide adequate ventilation during operation. Never cover the device.

Safety Instructions

1. Do not point the switched on product at drivers of cars, buses, bicycles, motorcyclists, or train drivers while driving. The driver can be blinded and cause an accident. This also applies to persons or groups not listed if an accident could be caused by possible glare.
2. Do not point the switched-on product directly into the eyes of people or animals, as this can damage the retina, impair vision and even lead to blindness.
3. The device is not a toy. Keep the device, accessories and packaging materials away from children and pets to prevent accidents and suffocation.
4. If you sell the product to someone else, pass these operating instructions on to that person as well.

Note: For lighting for video purposes only. Not suitable for permanent room lighting.

Components




1. Light panel
2. Ball head
3. Monopod
4. Hex wrench
5. Screw
6. Base plate

Remote Control

7. Brightness control
8. Operation LED
9. On / Off switch
10. Mode button

Setting Up the Rollei LUMIS Key Light



- Fasten the tripod leg (3) in the matching thread on the base plate (6). To do so, screw the screw (5) tightly into the thread at the bottom of the base plate (6) using the supplied hex wrench (4).
- Mount the light panel (1) on the ball head (2) of the monopod (3).
- Then adjust the Rollei LUMIS Key Light to the desired height by pulling the leg segments of the monopod (3) apart.
- Connect the Rollei LUMIS Key Light to your computer via the USB-A port or to a power supply unit with a USB-A port (not included; necessary output of the power supply unit: DC 5 V / 2 A).

Operation

- After having set up the Rollei LUMIS Key Light, you can switch the light on and off using the on / off switch (9) of the remote control on the cable of the Rollei LUMIS Key Light.
- You can set the brightness using the arrow buttons for brightness control (7).
- You can choose between 3 color temperatures with the help of the mode button.

Technical Data


Light panel	
Number of LEDs	108 (54 warm white, 54 cool white)
Power	10 W
Color temperatures	3200 K, 4500 K and 5500 K
Color rendering index (CRI)	95+
Power adjustment	Via remote control in 8 steps
Illuminance	630 lx (0.5 m at 5500 K)
Remote control	Via the remote control in the cable of the Rollei LUMIS Key Light
Power supply	DC 5 V = 2A
Connections	Light panel: 1/4" screw thread, ball head on monopod: 1/4" screw
Dimensions Weight	175 x 120 x 19 mm 230 g

Monopod with base plate	
Material	Iron and ABS
Weight	808 g
Max . height Min . height	780 mm 285 mm
Monopod segments	4
Diameter segments	25 mm, 20 mm, 16 mm, 14 mm
Diameter base plate	168 mm
Box content	Light panel, cable with remote control, monopod with ball head, base plate, hex wrench, screw

Disposal



Dispose of the packaging according to its type. Use the local possibilities for collecting paper, cardboard and other materials. (Applicable in the European Union and other European countries with systems for the separate collection of recyclable materials.)



Devices that are marked with this symbol must not be disposed of with household waste! You are legally obliged to dispose of old devices separately from to dispose of household waste. Information on collection points that accept old appliances free of charge can be obtained from your local authority or town council.

Conformity

Rollei GmbH & Co. KG hereby declares that the device "Rollei LUMIS Key Light" complies with the following directives:

2011/65/EU RoHS Directive

2014/30/EU EMV Directive

The full text of the EU Declaration of Conformity is available at the following Internet address:

www.rollei.com/egk/lumiskeylight

Rollei GmbH & Co. KG, In de Tarpen 42, 22848 Norderstedt Germany

Rollei GmbH & Co. KG In de Tarpen 42

D-22848 Norderstedt

Service Hotline:

+49 40 270750277

FACEBOOK: [/rollei.foto.de](https://www.facebook.com/rollei.foto.de)

Documents / Resources



[Rollei LUMIS Key Light Desktop Bi-Color LED Panel](#) [pdf] User Manual
LUMIS Key Light, Desktop Bi-Color LED Panel, Bi-Color LED Panel, Desktop LED Panel, LED Panel, Panel

References

- [cewe - best in print](#)
- [Rollei ? Online shop for camera, video and photo equipment](#)
- [Rollei: Der Online-Shop für Kamera- Video- und Foto-Equipment](#)