

# **ROTEL C8 and C8plus Eight Channel Power Amplifiers Owner's Manual**

Home » ROTEL » ROTEL C8 and C8plus Eight Channel Power Amplifiers Owner's Manual

#### **Contents**

- 1 ROTEL C8 and C8plus Eight Channel Power
- **Amplifiers**
- 2 Documents / Resources
  - 2.1 References
- **3 Related Posts**



# **ROTEL C8 and C8plus Eight Channel Power Amplifiers**



Caution: Risk of Electric Shock

Do Not Open.

WARNING: SHOCK HAZARD-DO NOT OPEN

APPLICABLE FOR USA, CANADA OR WHERE APPROVED FOR THE USAGE

CAUTION: ID PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT. INSERT FULLY.





Figure 1-1: Controls and Connections



1. ZONA 1 – 4 Configure the volume, source, bass treble and balance for Zone 1 to Zone 4 respectively.

Figure 1-2:




Figure 2: Connection Illustration





Figure 3: Bridged Connection Illustration




# Important Notes When making connections be sure to:

- Turn off all the components in the system before hooking up any components, including loudspeakers.
- Turn off all components in the system before changing any of the connections to the system.

# It is also recommended that you:

• Turn the volume control of the amplifier all the way down before the amplifier is turned on or off.



# The Rotel Co. Ltd.

Tachikawa Bldg. 1F., 2-11-4, Nakane, Meguro-ku, Tokyo, 152-0031 Japan

#### **Rotel USA**

Sumiko 1 1763 95th Avenue North Maple Grove, MN 55369 USA

Phone: (510) 843-4500 (option 2)

E-mail: Rotelsupport@sumikoaudio.net

# **Rotel Canada**

Kevro International 902 McKay Rd. Suite 4 Pickering, ON L1W 3X8 Canada Tel: +1 905-428-2800

### **Rotel Europe**

Dale Road Worthing, West Sussex BN11 2BH England

Phone: + 44 (0)1903 221 710 Fax: +44 (0)1903 221 525

www.rotel.com

## **Documents / Resources**



ROTEL C8 and C8plus Eight Channel Power Amplifiers [pdf] Owner's Manual C8 and C8plus Eight Channel Power Amplifiers, C8 Amplifier, C8plus Amplifier, Eight Channel Power Amplifiers

# References

• Rotel

Manuals+,