



ROTOLIGHT SmartSoft Box Installation Guide

[Home](#) » [Rotolight](#) » ROTOLIGHT SmartSoft Box Installation Guide 

Contents


- [1 ROTOLIGHT SmartSoft Box](#)
- [2 How to uninstall SmartSoft™ Box](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)



ROTOLIGHT SmartSoft Box



1. The SmartSoft™ Box is compatible with the AEOS 2 and AEOS 2 Pro.



2. Update your AEOS 2 or AEOS 2 Pro to the latest firmware www.rotolight.com/support
3. You'll need the Rotolight SmartSoft™ Box, 1x Small 1/4" knob, and 2x Large M8 knobs. TE – if you are using the AEOS yoke you do not need the 2x Large knobs Supplied with the SmartSoft™ Box.



4. Turn off the AEOS 2/AEOS 2 Pro and remove the Standard Diffuser or Barndoors if they are installed.
5. Attach the SmartSoft™ Box and secure it with a small knob, don't fully tighten at this point.
6. Install the 2x Large M8 knobs and fully tighten them and the small knob.

NOTE – if you have the AEOS Yoke installed now tighten the larger knobs and small knob.



7. Connect the SmartSoft™ Box control cable to the AEOS 2 / AEOS 2 Pro.
8. Turn ON the AEOS 2 / AEOS 2 Pro.
9. In CCT press the bottom left icon twice to cycle between the brightness and SmartSoft™ control.



10. Used the on-screen slider or left Red Control dial to increase and decrease the amount of diffusion. You are now ready to shoot!

How to uninstall SmartSoft™ Box

1. To Remove the SmartSoft™ Box turn OFF the AEOS 2 / AEOS 2 Pro.
2. Disconnect the Control cable from the AEOS 2 / AEOS 2 Pro.



3. Loosen the 2x Larger knobs
4. Remove the small 1/4" knob and then the SmartSoft™ Box
5. Now you are ready to attach our other light Modifiers <https://www.rotolight.com/product-category/light-modifiers/>

Documents / Resources

	ROTOLIGHT SmartSoft Box [pdf] Installation Guide SmartSoft Box, SmartSoft, Box
---	---

References

- [Support Centre | Rotolight](#)
- [Products Product Category | Rotolight](#)