

RowenTa BS1131V0 Electronic Scale Instructions

Home » Rowenta » Rowenta BS1131V0 Electronic Scale Instructions 🖫

Contents

- 1 RowenTa BS1131V0 Electronic Scale
- 2 Specifications
- 3 FAQs
- **4 SAFETY INSTRUCTIONS**
- **5 GUARANTEE**
- 6 Documents / Resources
 - **6.1 References**



RowenTa BS1131V0 Electronic Scale



Specifications

Model Number: 1820014520Intended Use: Home use only

• Materials: Contains valuable materials suitable for recovery or recycling

• Website: www.rowenta.com.

FAQs

- Q: Can this appliance be used for professional purposes?
 - A: No, this appliance is designed for home use only. Professional use will void the guarantee.
- Q: How should I dispose of used batteries?
 - A: Do not throw used batteries into the dustbin. Take them to a recognized collection point for proper disposal.
- Q: Where can I find more information about recycling this appliance?
 - A: You can find more information on recycling this appliance on our website at www.rowenta.com.

SAFETY INSTRUCTIONS

Read the instructions before use to avoid any danger due to misuse.

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Do not touch the liquid with bare hands. The liquid contacting the eyes or body may cause loss of vision, injury,

or inflammation.

- Immediately rinse with clean water such as tap water when the liquid contacts the body or clothing.
- Do not rub the eye and immediately rinse with clean water when the liquid gets into the eye, and immediately
 get treatment by a physician.
- Do not attempt to recharge non-rechargeable batteries.
- Do not mix new and used batteries or different types of batteries.
- Ensure that the polarity is correct when inserting the batteries.
- Empty batteries must be removed from the device and disposed of safely.
- Remove batteries from a device if it is to be stored or not intended to be used for a long period.
- Do not short-circuit the power supply terminal.
- Do not expose the appliance or battery to excessive temperatures
- Be aware of the risk of terminals of the battery-operated appliance or battery being short-circuited by metal objects.
- Do not use modified or damaged batteries.

GUARANTEE

- Your appliance is designed for use in the home only.
- It should not be used for professional purposes.
- The guarantee becomes null and void in the case of improper usage.

ENVIRONMENT PROTECTION FIRST!

- Your appliance contains valuable materials that can be recovered or recycled. Leave it at a local civic waste collection point.
- Never throw used batteries into the dustbin: consider them as chemical residue. Take them to a recognized collection point.
- These instructions are also available on our website www.rowenta.com.

Documents / Resources



RowenTa BS1131V0 Electronic Scale [pdf] Instructions

1820014520, BS1131V0 Electronic Scale, BS1131V0, Scale, BS1131V0 Scale, Electronic Scale

References

- Rowenta USA | Garment Steamers, Steam Irons & Humidifiers
- User Manual

SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsem	nent.