



Royal Sovereign RSB-1612 LED Scrolling Message Sign Owner's Manual

[Home](#) » [Royal Sovereign](#) » Royal Sovereign RSB-1612 LED Scrolling Message Sign Owner's Manual

Contents [[hide](#)]

- [1 Royal Sovereign RSB-1612 LED Scrolling Message Sign](#)
- [2 CONTENTS](#)
- [3 iOS DEVICES](#)
- [4 ANDROID DEVICES](#)
- [5 RESETTING OR RESTORING YOUR PASSWORD](#)
- [6 SPECIFICATIONS](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



Royal Sovereign RSB-1612 LED Scrolling Message Sign



Please read and retain these instructions.

To register your product, please go to www.royalsovereign.com USA.

Click the customer Support Tab, then Registration Tab www.royalsovereign.com

CONTENTS


LED sign, power adapter, hang chain, and hooks.

Setting up your Display Message Sign incredibly simple. You will need:

- Your Display Message Sign
- Android™ 4.0 device or later; or
- an iOS device for iPhones, 4S or newer

iOS DEVICES

Step 1:

On your mobile device, download and install the latest  App from the Apple® App Store by searching for “Royal Sovereign” or “Scrolling Message”.




Step 2:

Ensure your Bluetooth setting on the iOS device is enabled ('ON')


Step 2



Step 3:

- Launch the  App on your iOS device. Ensure that the Display Message Sign device is plugged in to a power outlet. Note: when initially plugged in the default message will read **Display Message Sign.**
- Pair the Display Message Sign device to the correct sign/signal.
The paired device you need to connect will begin with 'RGBLE-12_ 4.xxxxx' followed by a 5 digit suffix number.
(Note: The 5 digit suffix number allows you to connect and use more than 1 Display Message Signs at one time. Each Display Message Sign has a unique five digit suffix number). Enter the factory default password '000', followed by pressing OK.
Note: This password is user selectable and can be changed to any 3 numeric number.
- Press the confirm button to enter the Display Message Sign App.

Step 3 a



Step 3 b



Step 4:


You have successfully set up Display Message Sign.

You are now in the main screen of the Display Message Sign APP. Customize your Display Message Sign by creating your own message or playlist. Use the settings option to turn the Display Message Sign ON/ OFF using your APP or change your three digit passcode (Default code of 000).

Refer to Quick Reference Guide – About the APP

ANDROID DEVICES


Step 1:

On your mobile device, download and install the latest  App from the Google Play Store by searching for "Royal Sovereign" or "Scrolling Message".

Step 2:


Ensure your Bluetooth setting on the Android device is enabled ('ON')

Step 3:


- Launch the  App on your Android device. Ensure that the Display Message Sign device is plugged in to a power outlet
Note: when initially plugged in, the default message will be displayed.
- If RSB-1612 is not yet connected to any other devices via Bluetooth, it will be displayed on screen (Step 3-b (1)). It will begin with 'RG-BLE-12_3.xxxx' followed by a 5 digit suffix number. (Note: Each unit has its own unique 5 digit suffix number. It allows users to specify which unit to conned when user has multiple units). Select the displayed unit. Enter the Factory Default Password '000', then '1234' for Pairing Request.
Note 1: If "Failed connection" message shows, close the app completely then try Step 3-b once again.



Step 2



Step 3-b (1)



Step 3-b (2)



Step 3-b (3)

Note 2: This password is user selectable and can be changed to any 3 numeric number. c) Press the confirm button(OK) to enter the Display Message Sign App.

Step 4:


You have successfully set up Display Message Sign.

You are now in the main screen of the Display Message Sign APP. Customize your Display Message Sign by creating your own message or playlist. Use the settings option to turn the Display Message Sign ON/OFF using your APP or change your three digit passcode (Default code of 000).

Refer to Quick Reference Guide – About the APP



Step 4



RESETTING OR RESTORING YOUR PASSWORD


There is a green button located at the top left hand side of the display message sign. Press and hold this button for 5 seconds to reset the default password back to 1100011

Note: Resetting your password only resets the password. Your messages and playlist will be maintained.

SPECIFICATIONS

Messenger	1-99 up to 99 characters per message	
Number of Characters	12 characters on screen at one time	
Setting	Programmable Entry Animation (Right to Left, Down, Up, Blink)	
Delay		Selectable Fast / Slow Red, Orange, Green. Set Individually or Using Custom Setting Options 12V 2A cULus (included) ABS Plastic
Speed Control		
Color Settings		
Adaptor		
Material		
		Hang Chain (hardware included)

Documents / Resources

 <p>Owner's Manual RSB-1612 SCROLLING</p>	Royal Sovereign RSB-1612 LED Scrolling Message Sign [pdf] Owner's Manual RSB-1612, LED Scrolling Message Sign, RSB-1612 LED Scrolling Message Sign
---	--