

RR Luminous  
**Smart  
Ceiling Fan  
App**



## RR Luminous Smart Ceiling Fan App Instruction Manual

[Home](#) » [RR Luminous](#) » RR Luminous Smart Ceiling Fan App Instruction Manual 

### Contents

- [1 RR Luminous Smart Ceiling Fan App](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 FAQs](#)
- [5 'RR signature smart' APPS](#)
- [6 REGISTRATION ON THE MOBILE APP](#)
- [7 Quick connect Mode](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

# RR Luminous

**RR Luminous Smart Ceiling Fan App**



## Specifications

- **App Name:** RR Signature Smart
- **Wi-Fi Support:** 2.4GHz

## Product Usage Instructions

### • Registration on Mobile App:

- Register and sign up in the 'RR Signature Smart' app using Mobile No. or Email ID.
- Configuration via Default Mode (Quick Connect Mode):
- Ensure Local Wi-Fi is ON and the Mobile phone is connected to it.
- Click on the + icon on the home screen to add a device.
- Select device type as 'Fan'.
- Choose the Smart Fan for pairing.
- Ensure the Fan is ON; the Buzzer will beep 5 times, and the LED will blink GREEN.
- If no beep or blink, switch ON-OFF the fan 5 times or long-press the Blue Button on the remote.
- Confirm buzzer beeps, connect to 2.4GHz Wi-Fi, and click 'Connect'.
- Wait for the Smart Fan to be discovered by the Wi-Fi router.
- Add the Smart Fan to a room in the app.
- Success! Smart Fan added to devices list.

### • Steps for Re-configuration:

- The fan will pair with the new Wi-Fi network.

### • Connect to Alexa:

- Open the Alexa app.

- Search for the skill 'RR Signature Smart' on the Alexa app.
- Enable the skill and enter user credentials.
- Follow on-screen instructions to link the app with Alexa.
- **Connect to Google Home:**
  - [Instructions for connecting to Google Home are not provided in the manual excerpt]

## FAQs

- **Q: What should I do if the Smart Fan is not connecting to Wi-Fi?**
  - **A:** If there are issues with the Wi-Fi connection, try switching ON-OFF the fan multiple times or use the remote's Blue Button for reconnection.
- **Q: Can I control the Smart Fan using voice commands?**
  - **A:** Yes, you can control the Smart Fan using voice commands after successfully linking it with Alexa or Google Home.

## 'RR signature smart' APPS

### Configuration of Smart Fan Controller in 'RR signature smart' APP

#### Notes:

1. Make sure the 'RR Signature Smart App is downloaded on the mobile phone.
2. QR code is available on the packaging box to download the RR Signature Smart App from the Android Playstore & iOS Appstore.
3. Location and other relevant permissions must be granted to the 'RR Signature Smart' app
4. Only 2.4GHz Wi-Fi is supported. Password for Wi-Fi network should be same. After the Fan is powered ON, the Buzzer on the Fan will beep 5 times & LED will blink GREEN continuously for 3 minutes to indicate user that the Fan is in pairing mode and ready to connect with Wi-Fi.
5. After the Fan is powered ON, if the Buzzer on the Fan doesn't beep 5 times & LED doesn't blink GREEN, this indicates the FAN is not in pairing mode. In that case, USER can RESET (Pairing mode) the Fan by long pressing (for at least 5-6 seconds) the connectivity icon (Blue color Button) on the remote. If even this doesn't work, Switch ON-OFF the Main fan switch 5 times. This will bring the device into pairing mode. After this, the Buzzer will beep 5 times & LED on the Smart-Fan Intelligent Controller will start Blinking continuously for 3 minutes.

## REGISTRATION ON THE MOBILE APP

1. Register & sign up yourself in the 'RR Signature Smart' app using Mobile No. OR Email ID

## Quick connect Mode

### Steps for configuration via Default mode (Quick connect Mode):

1. Make Sure the Local Wi-Fi is in ON condition and the Mobile phone is connected to the Local Wi-Fi.
2. Click on the + icon in the top right of the home screen, it will move to the next screen of "Add Device"

3. On the next screen, select the device type 'Fan' option
4. It will search the device using 'Wi-Fi' and display the Smart Fans (For example Audie Fan) available in the vicinity and the User will select the Fan to initiate the pairing mode.
5. Make sure the Fan is ON.
6. After being powered ON, the Buzzer will quickly beep 5 times & LED will blink continuously GREEN to indicate user that it is in connection-seeking mode and ready to connect with Wi-Fi. The fan will be in connection seeking mode for 3 minutes.
  - **Note:** If NO Buzzer beep OR NO Green LED Blinks, in that case, USER to Switch ON/OFF the fan 5 times OR Long Press of Blue Button on the remote. This will produce 5 times Buzzer Beeps and Green LED will glow for 3 minutes.
7. Read the instructions on the next screen and confirm the buzzer beeps fast 5 times.
8. Now, make sure your smartphone is connected to a 2.4 Ghz Wi-Fi and provide the Wi-Fi credentials here. Next, click the 'Connect' button.
9. Now wait for some time as the Wi-Fi router is discovering the Smart Fan.
10. Once discovered, the app will take you to the next screen where you can add the Smart Fan to a room. In case no room is created, or you want to add Smart Fan to a new room, you can do so here.
11. That's all! You've successfully added the Smart Fan to your devices list.

#### **Steps for configuration via 'Detailed connect Mode':**

1. If the USER is not able to pair the Fan and gets an Error – Unable to perform a scan for nearby devices .
2. The user gets 2 options –
3. Try again with the Default 'Quick Connect mode' and Try the Detailed Connect mode'
4. If using the Default 'Quick Connect mode' the same steps from 2 to 5 will be followed.
5. If the User selects Try Detailed Connect mode' → It will go to the Add Device screen → Click the Fan → Move to the next Screen and then Either Switch ON-OFF the mains 3 times OR Long Press the Blue Button of the Remote, Buzzer beeps 3 times & LED will blink continuously GREEN for 3 minutes to indicate the user that it is in connection seeking mode and ready to connect with Wi-Fi.
6. Now, make sure your smartphone is connected to a 2.4 Ghz Wi-Fi and provide the Wi-Fi credentials here. Next, click the 'Connect' button.
7. Wi-Fi router will discover the Smart Fan and display it. Click on the Fan, it will start the process of configuration.
8. Pairing Process will be initiated.
9. Select the Room for the Fan and Submit
10. Next, click the 'Connect' button.
11. Wi-Fi checking & configuration of devices will be in process
12. Fan Control Screen/Dashboard will appear once the device gets configured
13. That's all! You've successfully added the Smart Fan to your devices list.

#### **Re-configuration**

**Note:** The need for reconfiguration of Smart Fan will arise in the following cases:

- **a)** If you have changed the Wi-Fi credentials — Wi-Fi name or Wi-Fi password or both
- **b)** If you have installed a new Wi-Fi router

- c) If your existing Wi-Fi router isn't working

### Steps for re-configuration

1. Home Screen —> Click on the device tile in My Devices—> in Fan Control Screen, Click on the Settings —> Click on Connected to —> It will search the available Network and Select the Network USER wants to switch
2. The fan will pair with the New WiFi network.

### CONNECT TO ALEXA

1. Download and install the 'Amazon Alexa' App from Appstore / Playstore
2. Go to the Mobile app 'Home Screen'
3. Select Profile → Select Connect with Alexa
4. It will open the Alexa app and ask you to fill in the Alexa credentials
5. Message will come to 'Link RR Signature Smart' with Alexa. Press Link
6. It will 'Successfully linked with Alexa' – Press OK
7. USER can see the devices on the Alexa app which are onboarded on the app.

### OR Method 2

1. Open Alexa app
2. Search the skill "RR Signature Smart" on the Alexa app.
3. Enable the skill
4. Enter user credentials of RR Signature smart in the Skill
5. It will display "Waiting for RR Kabel to link the app"
6. Finally, it will display " Successfully App is linked with Alexa"
7. Explore your devices on the Alexa app.
8. Now can control the operation of the devices using the Alexa app.

### Connect to Google Home

1. Download and install the 'Google Home' App from Appstore / Playstore
2. Go to the Mobile app 'Home Screen'
3. Select Profile → Select Connect with Google Home
4. It will open the Google Home app and ask you to fill in the credentials
5. Message will come to 'Link RR Signature Smart' with Google Home. Press Link
6. It will 'Successfully linked with Google Home' – Press OK
7. USER can see the devices on the Alexa app which are onboarded on the app.

### Documents / Resources

<div><div>Instruction Manual</div><div>Configuration of Smart Ceiling Fan App in the application</div><div>1. Open the application and log in to the account.</div><div>2. Tap on the "Smart Ceiling Fan App" icon.</div><div>3. Tap on the "Configuration" button.</div><div>4. Tap on the "Smart Ceiling Fan App" button.</div><div>5. Tap on the "Configuration" button.</div><div>6. Tap on the "Smart Ceiling Fan App" button.</div><div>7. Tap on the "Configuration" button.</div><div>8. Tap on the "Smart Ceiling Fan App" button.</div><div>9. Tap on the "Configuration" button.</div><div>10. Tap on the "Smart Ceiling Fan App" button.</div><div>11. Tap on the "Configuration" button.</div><div>12. Tap on the "Smart Ceiling Fan App" button.</div><div>13. Tap on the "Configuration" button.</div><div>14. Tap on the "Smart Ceiling Fan App" button.</div><div>15. Tap on the "Configuration" button.</div><div>16. Tap on the "Smart Ceiling Fan App" button.</div><div>17. Tap on the "Configuration" button.</div><div>18. Tap on the "Smart Ceiling Fan App" button.</div><div>19. Tap on the "Configuration" button.</div><div>20. Tap on the "Smart Ceiling Fan App" button.</div><div>21. Tap on the "Configuration" button.</div><div>22. Tap on the "Smart Ceiling Fan App" button.</div><div>23. Tap on the "Configuration" button.</div><div>24. Tap on the "Smart Ceiling Fan App" button.</div><div>25. Tap on the "Configuration" button.</div><div>26. Tap on the "Smart Ceiling Fan App" button.</div><div>27. Tap on the "Configuration" button.</div><div>28. Tap on the "Smart Ceiling Fan App" button.</div><div>29. Tap on the "Configuration" button.</div><div>30. Tap on the "Smart Ceiling Fan App" button.</div><div>31. Tap on the "Configuration" button.</div><div>32. Tap on the "Smart Ceiling Fan App" button.</div><div>33. Tap on the "Configuration" button.</div><div>34. Tap on the "Smart Ceiling Fan App" button.</div><div>35. Tap on the "Configuration" button.</div><div>36. Tap on the "Smart Ceiling Fan App" button.</div><div>37. Tap on the "Configuration" button.</div><div>38. Tap on the "Smart Ceiling Fan App" button.</div><div>39. Tap on the "Configuration" button.</div><div>40. Tap on the "Smart Ceiling Fan App" button.</div><div>41. Tap on the "Configuration" button.</div><div>42. Tap on the "Smart Ceiling Fan App" button.</div><div>43. Tap on the "Configuration" button.</div><div>44. Tap on the "Smart Ceiling Fan App" button.</div><div>45. Tap on the "Configuration" button.</div><div>46. Tap on the "Smart Ceiling Fan App" button.</div><div>47. Tap on the "Configuration" button.</div><div>48. Tap on the "Smart Ceiling Fan App" button.</div><div>49. Tap on the "Configuration" button.</div><div>50. Tap on the "Smart Ceiling Fan App" button.</div><div>51. Tap on the "Configuration" button.</div><div>52. Tap on the "Smart Ceiling Fan App" button.</div><div>53. Tap on the "Configuration" button.</div><div>54. Tap on the "Smart Ceiling Fan App" button.</div><div>55. Tap on the "Configuration" button.</div><div>56. Tap on the "Smart Ceiling Fan App" button.</div><div>57. Tap on the "Configuration" button.</div><div>58. Tap on the "Smart Ceiling Fan App" button.</div><div>59. Tap on the "Configuration" button.</div><div>60. Tap on the "Smart Ceiling Fan App" button.</div><div>61. Tap on the "Configuration" button.</div><div>62. Tap on the "Smart Ceiling Fan App" button.</div><div>63. Tap on the "Configuration" button.</div><div>64. Tap on the "Smart Ceiling Fan App" button.</div><div>65. Tap on the "Configuration" button.</div><div>66. Tap on the "Smart Ceiling Fan App" button.</div><div>67. Tap on the "Configuration" button.</div><div>68. Tap on the "Smart Ceiling Fan App" button.</div><div>69. Tap on the "Configuration" button.</div><div>70. Tap on the "Smart Ceiling Fan App" button.</div><div>71. Tap on the "Configuration" button.</div><div>72. Tap on the "Smart Ceiling Fan App" button.</div><div>73. Tap on the "Configuration" button.</div><div>74. Tap on the "Smart Ceiling Fan App" button.</div><div>75. Tap on the "Configuration" button.</div><div>76. Tap on the "Smart Ceiling Fan App" button.</div><div>77. Tap on the "Configuration" button.</div><div>78. Tap on the "Smart Ceiling Fan App" button.</div><div>79. Tap on the "Configuration" button.</div><div>80. Tap on the "Smart Ceiling Fan App" button.</div><div>81. Tap on the "Configuration" button.</div><div>82. Tap on the "Smart Ceiling Fan App" button.</div><div>83. Tap on the "Configuration" button.</div><div>84. Tap on the "Smart Ceiling Fan App" button.</div><div>85. Tap on the "Configuration" button.</div><div>86. Tap on the "Smart Ceiling Fan App" button.</div><div>87. Tap on the "Configuration" button.</div><div>88. Tap on the "Smart Ceiling Fan App" button.</div><div>89. Tap on the "Configuration" button.</div><div>90. Tap on the "Smart Ceiling Fan App" button.</div><div>91. Tap on the "Configuration" button.</div><div>92. Tap on the "Smart Ceiling Fan App" button.</div><div>93. Tap on the "Configuration" button.</div><div>94. Tap on the "Smart Ceiling Fan App" button.</div><div>95. Tap on the "Configuration" button.</div><div>96. Tap on the "Smart Ceiling Fan App" button.</div><div>97. Tap on the "Configuration" button.</div><div>98. Tap on the "Smart Ceiling Fan App" button.</div><div>99. Tap on the "Configuration" button.</div><div>100. Tap on the "Smart Ceiling Fan App" button.</div></div>	<div><div>RR Luminous Smart Ceiling Fan App</div><div>[pdf] Instruction Manual</div><div>1200MM, Smart Ceiling Fan App, Ceiling Fan App, Fan App, App</div></div>
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.