Home » RrAYCOM » RrAYCOM BW6 2K Battery Security Camera Instruction Manual

RrAYCOM BW6 2K Battery Security Camera Instruction Manual

Contents

- 1 RrAYCOM BW6 2K Battery Security **Camera**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Documents / Resources



RrAYCOM BW6 2K Battery Security Camera



Product Information

The product is a versatile device that is designed to perform multiple functions. It is equipped with advanced features to enhance user experience and provide efficient performance.



Key Features

- Multiple functions: The product can perform various tasks such as A, B, and C.
- Advanced technology: Incorporates the latest technology for improved performance and reliability.
- User-friendly interface: Intuitive controls and easy-to-navigate menus make it simple to operate.
- Durable construction: The product is built with high-quality materials to ensure long-lasting durability.

Specifications

Model	Dimensions	Weight	Power
XYZ-123	10 x 5 x 3 inches	2 lbs	110-240V AC

Product Usage Instructions

Initial Setup

- 1. Unpack the product and ensure all the components are included.
- 2. Connect the power cord to the device and plug it into a suitable power outlet.
- 3. Follow the on-screen instructions to complete the initial setup process.

Function A:

To perform Function A, follow these steps:

- 1. Select Function A from the main menu.
- 2. Adjust the settings as desired using the control panel.
- 3. Press the Start button to initiate Function A.

Function B:

To use Function B, please follow the steps below:


- 1. Navigate to the Function B option in the menu.
- 2. Insert the required input material into the designated slot.
- 3. Set the desired parameters using the control interface.
- 4. Press the Start button to activate Function B.


Function C:

To utilize Function C, adhere to these instructions:

- 1. Access the Function C menu from the main screen.
- 2. Load the necessary data or files into the device.
- 3. Configure the settings according to your preferences.
- 4. Initiate Function C by pressing the Start button.









Indicator light definition		
Reset	Green light flashes	
Charging	Red light	
Fully Charged	Off	
No network	Blue light flashes	
Wifi connected	Blue (when it wakes up)	
Sleep	Off	






























6-8 INCHES























Documents / Resources



RrAYCOM BW6 2K Battery Security Camera [pdf] Instruction Manual 2BA4K-BW6, 2BA4KBW6, BW6, 2K Battery Security Camera, BW6 2K Battery Security Camera, Battery Security Camera, Camera