



# RTAKO RYP-001 Multi Function Bluetooth Device User Manual

[Home](#) » [RTAKO](#) » RTAKO RYP-001 Multi Function Bluetooth Device User Manual 




## RYP-001 Multi Function Bluetooth Device User Manual




### Contents

- [1 Product interface](#)
- [2 Parameter Specification](#)
- [3 Matters needing attention](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)


## Product interface







## Parameter Specification

Product name	Selfie stick (including remote control)
Product model	ZP220 Pro
Product color	black
Product material	ABS+ stainless steel + silicone
Product size	435`84*49mm
Clamping size	54mm-90mm
Net product weight	635g±5g
Bluetooth name	RTAKO
Blue teeth	Bluetooth 5.2
Transmitting frequency	2.4 GHz to 2.483 GH:
Remote control distance	10M
Battery parameter	Polymer lithium battery
Charging interface	Type-C
Charge input	5V  100mA

### Bluetooth remote control introduction



### Remote control operation instructions


1. Long press "  " for 3 seconds and click the like button" Power on ", and the blue light of the remote control indicator flashes;
2. Turn on the phone "Settings" – "Bluetooth" Turn on Bluetooth, search "RTAKO", click the device name to pair, the display "After connection", the indicator stops blinking, that is, the connection is successful (remote control is on).
3.  Direction key: See Tiktok up and down key switch video, left and right keys slide left and right slide; Small video software, long press "Page up" to increase the volume, long press "page down" to reduce the volume;
4.  "Like" button: When watching Tiktok (double click like) or other video software, click pause/continue playing, enter the shooting interface and click auto focus (if you need to cancel after liking, you need to cancel manually).
5.  Shooting key: support the original camera of the phone to shoot (can be used with Bluetooth); Support

- other photo software/Douyin/Kuaishou and other software to shoot video (a few models need to be set).
6. When charging, the indicator light is steady red, and it is turned off after full charging.
  7. After the remote control is turned on, the Bluetooth connection is not made, and the blue light blinks for connection. After 6 minutes of no operation, the remote control will automatically shut down.
  8. After the remote control is turned on and successfully connected to the Bluetooth, the remote control does not operate. After 10 minutes, the Bluetooth connection will be automatically disconnected and the remote control will automatically enter the low-power sleep. After 30 minutes the controller link is successful but no operation, the remote control will automatically shut down.

### Remote control special instructions


#### Special note:

(When the Apple IOS system Settings and Tiktok photo key are invalid, the setting method is as follows)

1. Apple 10S13.4 above setting methods: device connected to mobile phone Bluetooth — screen automatic rotation lock — open Settings — auxiliary function — touch — auxiliary touch — open; Systems above 10S15.0 must turn on the auxiliary touch – tracking sensitivity – (turtle icon) to adjust the dot to the middle.
2. the original photo album key (the method of adjusting the shutter key position when invalid) : Enter the shooting interface of the software=long pressthe —  shooting key of the remote control without moving — at the same time, short press the arrow key to move the” pointer/dot “to the shutter circle of the shooting software, and release the button after adjustment to shoot (the position of the touch key for shooting is different in different phone sizes and different software screens, so adjustment is required).


### How to use Selfie stick

1. Hold and use




2. Anti-shake steady use of the sub-handle

The balance handle can rotate 360 “horizontally, and the mechanical balance for video shooting effectively supports the shooting stabilization.





3. Open the tripod and stand




#### **1/4 interface is used**

1/4 interface compatible with sports cameras, digital cameras, ring lights, clips, etc.



As shown in the figure  
Fitting process



## Matters needing attention

1. When using a selfie stick tripod, be careful of pinching your hand.
2. Before installing the device, ensure that the selfie stick is in a steady state or firmly turned state to avoid accidental damage to the device.
3. Use the selfie stick tripod on a flat ground and keep it away from children to avoid injury or damage to the device.
4. The product contains small parts, do not give babies to play, in case of swallowing.
5. The remote control contains batteries, do not expose it to high temperature, fire or similar overheating environment for a long time, the remote control is not waterproof, do not enter water or contact corrosive liquids.
6. Do not overcharge or overdischarge the battery. Please charge the remote control every 3 months to ensure battery life if you do not use it for a long time.

## Warranty Card

Customer Name:.....

Contact Number: .....

Product Name: .....

Purchase Date; .....

Address: .....

Remark:.....

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver,
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.



**Manufacturer:** Dongguan Dianjin Technology Co., LTD


Address: Room 301, Building 5, No, 487, Tangxia Section, Dongshen Road, Tangxia Town,  
Dongguan City, Guangdong Province

Domestic hotline: 400-878-1101

Made in China

---

## Documents / Resources

	<p><a href="#">RTAKO RYP-001 Multi Function Bluetooth Device</a> [pdf] User Manual RYP-001 Multi Function Bluetooth Device, RYP-001, Multi Function Bluetooth Device, Function Bluetooth Device, Bluetooth Device</p>
---	---

## References

- [User Manual](#)