



Contents [[hide](#)]

- [1 Ruidla JS-017 Fabric Shaver Lint Remover](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)

Ruidla

Ruidla JS-017 Fabric Shaver Lint Remover



INTRODUCTION

An inexpensive yet effective tool for bringing your clothes and textiles back to their original appearance is the Ruidla JS-017 Fabric Shaver Lint Remover. With a 6-leaf stainless steel cyclone floating blade design that rotates at up to 10,000 RPM, this **\$12.99** sweater shaver offers twice the lint removal efficiency. It is ideal for eliminating fuzz, lint, and pills from clothing, beds, couches, curtains, and other materials without causing any harm to the fabric because of its spacious shaving area and three different sizes of honeycomb mesh. The device, which runs on two AA batteries, is cordless, small, and incredibly portable, making it perfect for travel. The safety interlock makes sure the gadget stops if the lid is loose, preventing mishaps, and the magnetic rear cover makes changing the battery simple. The Ruidla lint remover is made with a pocket lint collector and an ergonomic, mouse-like design for comfort, effectiveness, and dependability.

SPECIFICATIONS

Brand	Ruidla
Model	JS-017
Material	Stainless Steel, Plastic
Color	Gray
Operation Mode	Automatic
Blade Type	6-Leaf Cyclone Floating Blades
Blade Speed	Up to 10,000 RPM
Battery Type	2 x AA Batteries (Not Included)
Charging Method	Battery Operated (Cordless)
Shaving Mesh	3 Sizes Honeycomb Mesh
Handle Material	Alloy Steel
Product Dimensions	3.2"D x 3.2"W x 6.02"H
Item Weight	Approx. 8.1 ounces
Collector Type	Pocket-Style Lint Collector
Safety	Auto Shut-Off with Safety Interlock
Manufacturer	Ruidla
Model Number	JS-017
Country of Origin	China

WHAT'S IN THE BOX

- 1 x Ruidla JS-017 Fabric Shaver
- 2 x Extra Stainless Steel Replacement Blades
- 1 x Cleaning Brush


- 1 x User Manual

FEATURES

- **Blade Design:** 6-leaf stainless steel cyclone floating blades offer deep and efficient cleaning.




- **Speed Performance:** Operates at speeds up to 10,000 RPM for fast lint and fuzz removal.
- **Mesh Variety:** Three honeycomb mesh sizes designed to handle different fabric types safely.



Ergonomic Design & Large Lint Container

- **Wide Coverage:** Large shaving surface speeds up the process, covering more area in less time.
- **Safety Lock:** Automatically shuts off if the mesh cover becomes loose for added safety.
- **Magnetic Back Cover:** Allows quick and hassle-free battery replacement.
- **Cordless Design:** Fully portable and compact, ideal for travel and storage.
- **Comfortable Grip:** Ergonomically shaped like a computer mouse for comfortable use.
- **Lint Collector:** Built-in pocket-sized lint container keeps the process mess-free.
- **Extra Blades:** Comes with two spare replacement blades for extended usability.
- **Fabric Friendly:** Tough on lint, fuzz, and pilling while remaining gentle on clothing.
- **Battery Operated:** Powered by 2 AA batteries (no charging needed).



- **Lightweight:** Weighs only about 8.1 ounces, making it easy to carry anywhere.
- **On-the-Go Ready:** Perfect for quick use anytime without worrying about charging.
- **Durable Build:** Stylish combination of sturdy steel and plastic ensures long-term durability.



SETUP GUIDE

- **Open Cover:** Remove the magnetic back cover.
- **Insert Batteries:** Place 2 AA batteries, making sure to match the correct polarity.
- **Secure Cover:** Close the back until it clicks firmly in place.
- **Check Mesh:** Ensure the honeycomb mesh cover is tightly secured for safe operation.
- **Power On:** Slide the switch to turn the device on.
- **Test Run:** Try it on a small fabric area to confirm comfort and effectiveness.
- **Start Cleaning:** Gently glide the lint remover over fabrics.

Ruidla-JS-017-Fabric-Shaver-Lint-Remover-cleaining

- **Optimal Movement:** Use smooth circular motions for the best results.
- **Monitor Collector:** Check the lint container regularly during use.
- **Empty as Needed:** Clear the collector when full to avoid clogging.

- **Turn Off:** Switch the device off when not actively using it.
- **Blade Access:** Open the mesh cover for cleaning or blade inspection.
- **Cleaning Tools:** Use the provided brush to clean blade residue and collected fibers.
- **Blade Care:** Replace the blades if they appear dull or worn.
- **Storage:** Store the device in a dry, safe location when finished.

CARE & MAINTENANCE

- **Clean Collector:** Always empty the lint container after each use.
- **Surface Cleaning:** Wipe the exterior with a soft, dry cloth.
- **Blade Cleaning:** Use the cleaning brush to remove fuzz from the blades.
- **Inspect Blades:** Check for signs of wear and replace when needed.
- **Spare Blades:** Use the included spare blades to maintain performance.
- **Mesh Maintenance:** Keep the honeycomb mesh clean and free of buildup.
- **Avoid Water:** Do not expose the device to water or high moisture.
- **Dust-Free Storage:** Store in a clean, dry environment to prevent damage.
- **Battery Care:** Remove batteries if the device won't be used for an extended period.
- **Heat Protection:** Keep away from direct sunlight and extreme heat.
- **Safety Check:** Regularly inspect the safety lock function for reliable operation.
- **Magnet Check:** Ensure the magnetic back cover stays properly secured.
- **Handle Carefully:** Avoid dropping the device to protect its internal components.
- **Vent Care:** Keep fan vents clean for smooth airflow and performance.
- **Remove Fibers:** Clear out any fabric fibers or debris trapped inside the blades.

TROUBLESHOOTING

Problem	Solution
Device not turning on	Check battery polarity or replace batteries.
Weak performance	Replace with fresh AA batteries; check for blockages.
Blade not rotating	Check for jammed lint; clean the blades.
Safety shut-off triggers	Ensure the honeycomb cover is securely locked.

Problem	Solution
Incomplete lint removal	Use slower strokes or replace dull blades.
Collector overflow	Empty the lint bin more frequently.
Noise or vibration increase	Clean out debris from blades and mesh area.
Battery compartment stuck	Gently pry open the magnetic cover; check for dirt.
Fabric damage	Avoid pressing too hard; use larger mesh holes wisely.
LED indicator (if any) off	Confirm batteries are installed correctly and are charged.

PROS & CONS

PROS:

- Powerful 10,000 RPM motor ensures fast lint removal.
- Large shaving area speeds up fabric defuzzing.
- Comes with 2 extra blades for extended use.
- Magnetic back cover allows quick battery changes.
- Safety interlock prevents accidental injuries.

CONS:

- AA battery operated; not rechargeable.
- Batteries not included in the package.
- Plastic body feels less premium.
- Not suitable for extremely delicate fabrics.
- Needs frequent lint bin emptying during heavy use.

WARRANTY

The Ruidla JS-017 Fabric Shaver comes with a **1-year** hassle-free warranty, covering manufacturing defects and material issues. Customers can easily reach out to customer

support via their Amazon order page by selecting “Your Orders” Find the product “Contact Seller” for warranty claims or assistance.

FREQUENTLY ASKED QUESTIONS

What fabrics can the Ruidla JS-017 Fabric Shaver be used on?

The Ruidla JS-017 is suitable for clothes, sweaters, bedding, upholstery, and curtains, effectively removing lint, fuzz, and fabric pills without damage.

What makes the Ruidla JS-017 safe for fabrics?

The honeycomb mesh cover with three hole sizes protects fabrics while removing pills, plus a safety interlock stops the blades if the cover is loose.

How powerful is the Ruidla JS-017 lint remover?

It operates at up to 10,000 RPM, featuring 6 stainless steel floating blades for faster and more thorough lint removal.

What type of batteries does the Ruidla JS-017 fabric shaver use?

It is powered by 2 AA batteries, offering a cordless design that is ideal for both home use and travel.

What is the function of the magnetic back cover on the Ruidla JS-017?

The magnetic back cover makes it easy to open for battery replacement and secure closure during operation.

Why does the Ruidla JS-017 stop during use?

This typically happens when the lint bin is full, the battery is low, or the mesh cover is loose, activating the automatic shut-off safety feature.

Why is the Ruidla JS-017 not removing lint effectively?

Make sure the blades are not worn and the mesh holes are clean. Also, verify that you are applying the shaver correctly to the fabric surface.

References

- [User Manual](#)

📖 Fabric Shaver Lint Remover, JS-017, Ruidla, Ruidla JS-017, user

📁 Ruidla manual

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.