



RV WIFI 12V System Dishy Dock Instruction Manual

[Home](#) » [RV WiFi](#) » RV WIFI 12V System Dishy Dock Instruction Manual 

RV WIFI 12V System Dishy Dock



Contents

- [1 Introduction](#)
- [2 Inclusions in this kit](#)
- [3 Installation Guide](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)

Introduction

Welcome to RV WIFI Dishy Dock, your complete Star link Integration System. This is the first part of the Integration System and a great way to pre wire your RV for Star link. Other parts to add to your installation include:

- RV WIFI Dishy dock Power – 12volt power adapter
- RV WIFI Dishy Dock Router or RV WIFI 5G router

Inclusions in this kit

- 2 x Internal Dishy Docks/RJ45 ports
- 1 x 5000 meter Dishy Dock Ethernet cable


Please note: this installation is required to be located in a waterproof environment. It is NOT a weatherproof product. For the weatherproof version, please choose RV WIFI Installation 'Weatherproof'.

Installation Guide

1. Choose your Port1 & 2 locations Internal & External).
 - The external Port must be located in a sealed TV box, Tunnel Boot, External Storage Box or other such waterproof locations with cavity access to rear.
 - the internal port in a cupboard, with enough space to fit both the Dishy Dock Power, Dishy Dock Router & install a 10A/12V dual power socket beside it.
2. Feed the Ethernet Cable through the wall cavity from port 1 to port 2.
3. Drill a 29mm sized hole to insert the Dishy Dock into the wall cavity. Do not drill through to other side of wall.
4. Plug one end of the Ethernet Cable into the rear of Port 1.
5. Attach the Port with screws to the wall material and snap on cover.
6. Repeat the installation for Port 2.



Documents / Resources



RV WIFI 12V System Dishy Dock [pdf] Instruction Manual
12V System Dishy Dock, 12V, System Dishy Dock, Dock

References

- User Manual

[Manuals+, Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.