



RYOBI PBLMT50 18 Volt Oscillating Multi-Tool Instruction Manual

[Home](#) » [RYOBI](#) » RYOBI PBLMT50 18 Volt Oscillating Multi-Tool Instruction Manual 



Instruction Manual

Contents

- [1 REPAIR SHEET](#)
- [2 18 Volt Oscillating Multi-Tool](#)
- [3 PBLMT50](#)
- [4 PARTS LIST](#)
- [5 WIRING DIAGRAM](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)


REPAIR SHEET

BRAND
RYOBI


MODEL NO.
PBLMT50

DESCRIPTION

18 Volt Oscillating Multi-Tool



PBLMT50




PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	204179005	Gear Case Assembly	1
2-CN	204179006	Housing Assembly (Inc. Key Nos. 6 & 12-15)	1
2-VN	204179007	Housing Assembly (Inc. Key Nos. 6 & 12-15)	1
3	659635001	Spring Plate	1
4	542075001	Switch Lever Button	1
5	662565001	Screw (M3.5 x 14 mm, T10 Torx Pan Hd.)	10
6	565876001	RYOBI Logo Badge	1
7	566036001	Foam Pad	1
8-CN	206179005	Motor and Circuit Board Assembly	1
8-VN	206179006	Motor and Circuit Board Assembly	1
9	681457016	Flush Cut Wood Blade	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
10	303590023	Sanding Pad Assembly	1
11	681458028	Plunge Cut Wood Blade	1
12	941120717	Icon Label	1
13-CN	941123241	Data Label	1
13-VN	941123632	Data Label	1
14	941120739	Battery Statement Label	1
15	565708002	Brushless Logo Badge	1
16	565928001	Rubber Isolator	2
	Not Shown:		
	998000392	Operator's Manual (961153429)	

WIRING DIAGRAM



TTI CONSUMER POWER TOOLS, INC.

P.O. Box 1288, Anderson, SC 29622

1-800-525-2579 "

www.ryobitools.com

12-14-21 (Rev:02)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.

Documents / Resources



[RYOBI PBLMT50 18 Volt Oscillating Multi-Tool](#) [pdf] Instruction Manual
PBLMT50, 18 Volt Oscillating Multi-Tool