



Contents [[hide](#)]

- [1 RYOBI PCLCK202K String Trimmer Edger Blower Combo Kit](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Product Description](#)
- [5 FAQ](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



RYOBI PCLCK202K String Trimmer Edger Blower Combo Kit



Specifications

- **Brand:** RYOBI
- **Power Source:** Battery
- **Voltage:** 18V, 40V
- **Available Tools:** Trimmers, Blowers, Lawn Mowers, Hedge Trimmers

Technical Details

Manufacturer	CUSHYBITE
Part Number	PCLCK202K
Item model number	PCLCK202K

Product Usage Instructions

Lawn Mower (RY401170VNM)

This lawn mower is suitable for yards of 1 acre or less. It comes with a 40V battery and a

charger. Follow these steps to use the lawn mower:

1. Ensure the battery is fully charged.
2. Adjust the cutting height as needed.
3. Press and hold the safety button while squeezing the handle to start the mower.
4. Push the mower over the grass in a systematic pattern.
5. After use, clean the mower and store it in a dry place.

Hedge Trimmer (RY402011BTLVNM)

This hedge trimmer is ideal for maintaining hedges and shrubs. It operates on an 18V battery and comes with a rapid charger. Here's how to use it:

1. Insert the fully charged battery into the trimmer.
2. Hold the trimmer with both hands for stability.
3. Engage the safety lock and trigger to start trimming.
4. Maintain a steady motion along the hedge for even cutting.
5. After use, clean the blades and store the trimmer safely.

Product Description

The 18V Cordless String Trimmer/Edger and Jet Fan Blower Combo Kit provides an efficient, gas-free solution for yard maintenance. This 2-tool kit includes a 13" string trimmer and a 350 CFM blower, both powered by an 18V 4Ah lithium battery for extended runtime. The trimmer's adjustable 11" to 13" cutting width allows for either maximum performance or longer battery life, while the auto-feed head ensures easy line advancement. A pivoting head quickly transforms the trimmer into an edger, making it easy to achieve , precise lines along sidewalks and driveways. The blower delivers 350 CFM at 100 MPH, ideal for clearing dry leaves and from hard surfaces.

About it

- Cordless operation provides gas-free performance with easy trigger activation for effortless yard maintenance.
- Adjustable 11"-13" cutting width balances power and runtime, with an auto-feed head for easy line advancement.

- Pivoting head transforms trimmer into an edger, delivering , precise cuts along sidewalks and driveways.
- 350 CFM blower with a variable speed trigger clears dry leaves and efficiently while remaining lightweight.
- For best results, compare the product's image and listed dimensions to ensure proper fitment.



13" STRING TRIMMER/EDGER




350 CFM BLOWER



4.0Ah BATTERY



CHARGER



FAQ


Q: Are the batteries interchangeable between different RYOBI tools?

A: Yes, the 40V batteries are compatible with all RYOBI 40V tools, providing flexibility and convenience.

Q: How long does it take to charge the batteries?

A: Charging times vary depending on the charger model and battery capacity. Refer to the specific tool’s manual for detailed charging information.

Documents / Resources

	<p>RYOBI PCLCK202K String Trimmer Edger Blower Combo Kit [pdf] User Guide</p> <p>PCLCK202K, RY401170VNM, RY141802VNM, RY401017BTLVNM, RY402110VNM, RYPM8010, RY401210US, RY404100VNM, RY404010BTLCANVNM, RY402011BTLVNM, RY40606BTLVNM, RY40703B, RY404014BTLVNM, PCLCK202K String Trimmer Edger Blower Combo Kit, PCLCK202K, String Trimmer Edger Blower Combo Kit, Edger Blower Combo Kit, Blower Combo Kit, Combo Kit</p>
--	--

References

- [User Manual](#)

RYOBI

Blower Combo Kit, Combo Kit, Edger Blower Combo Kit, PCLCK202K, PCLCK202K String Trimmer Edger Blower Combo Kit, RY141802VNM, RY401017BTLVNM, RY401170VNM, RY401210US, RY402011BTLVNM, RY402110VNM, RY404010BTLCANVNM, RY404014BTLVNM, RY404100VNM, RY40606BTLVNM, RY40703B, RYOBI, RYPM8010, String Trimmer Edger Blower Combo Kit

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.