



SABRENT AU-MMSC USB Type C External Stereo Sound Adapter for Windows and Mac User Guide

[Home](#) » [Sabrent](#) » SABRENT AU-MMSC USB Type C External Stereo Sound Adapter for Windows and Mac User Guide 



USB TYPE-C STEREO
3D SOUND ADAPTER



AU-MMSC USER GUIDE




Contents

- [1 AU-MMSC USB Type C External Stereo Sound Adapter for Windows and Mac](#)
- [2 MAC](#)
- [3 WINDOWS](#)
- [4 On most Windows Operating systems](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

AU-MMSC USB Type C External Stereo Sound Adapter for Windows and Mac

Plug USB Audio Sound Adapter into Type-C port of computer or laptop — make sure “SABRENT” text on USB Audio Sound Adapter is face up.




To use accessories such as headphones, Speakers, etc. plug into the green port.
To use accessories such as a microphone, plug into the pink port.




Control accessories plugged in using the volume and microphone controls directly from your computer or laptop.

MAC




NOTE: Some systems may require you to activate the sound adapter through the system settings. On most Mac Operating systems

1. Navigate to System Preferences
2. Click on the "Sound" icon




3. Select USB Audio Device on both "input" and "Output" tabs

WINDOWS



On most Windows Operating systems

1. From Control Panel click on sound
2. Under the “Recording” Tab select “Microphone USB Audio Device”



3. Under the “Playback” tab select “Speakers USB Audio Device”
4. Click “Apply”
5. Click “OK”

Documents / Resources

SABRENT
Connecting Everything

USB TYPE-C STEREO
3D SOUND ADAPTER



AU-MMSC USER GUIDE

[SABRENT AU-MMSC USB Type C External Stereo Sound Adapter for Windows and Mac](#) [pdf] User Guide

AU-MMSC, USB Type C External Stereo Sound Adapter for Windows and Mac, AU-MMSC USB Type C External Stereo Sound Adapter for Windows and Mac