



Sabrent CR-UM4C USB 3.0 AND USB TYPE-C TO MICRO SD AND SD CARD READER User Manual

[Home](#) » [Sabrent](#) » Sabrent CR-UM4C USB 3.0 AND USB TYPE-C TO MICRO SD AND SD CARD READER User Manual 






Contents


- [1 CR-UM4C USB 3.0 AND USB TYPE-C TO MICRO SD AND SD CARD READER](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

CR-UM4C USB 3.0 AND USB TYPE-C TO MICRO SD AND SD CARD READER




**USB 3.0 AND USB TYPE-C TO
MICRO SD AND SD CARD READER**





For Laptop or Computer Has Type-C Ports

1. Plug the card reader into the USB Type-C port of your computer or laptop — USB and USB Type-C options are on opposite ends of the Card Reader.
2. Insert card or cards into Card Reader Slot. Please note: This device can only read one memory card at a time.



For Laptop or Computer Has USB Ports

1. Plug card reader into the USB port of your computer or laptop — USB and USB Type-C options are on opposite ends of the Card Reader.
2. Insert card or cards into Card Reader Slot. Please note: This device can only read one memory card at a time.

Enjoy!

At this point, the USB 3.0 and USB Type-C to Micro SD and SD card reader is completely installed — no software drivers are needed to complete the installation.

Thank you for choosing Sabrent and enjoy!

For installation issues please contact: Support@Sabrent.com



Documents / Resources

 <p>CR-UM4C USB 3.0 AND USB TYPE-C TO MICRO SD AND SD CARD READER</p>	<p>Sabrent CR-UM4C USB 3.0 AND USB TYPE-C TO MICRO SD AND SD CARD READER [pdf]] User Manual CR-UM4C, CARD READER, USB CARD READER, SD CARD READER</p>
---	--

[Manuals+](#)