



SACKit Go 200 Smart Bluetooth Speaker User Manual

[Home](#) » [SACKit](#) » SACKit Go 200 Smart Bluetooth Speaker User Manual 

Contents

- 1 SACKit Go 200
 - 1.1 USER MANUAL
 - 1.2 THANK YOU!
 - 1.3 QUICK START GUIDE
 - 1.4 PRODUCT OVERVIEW
 - 1.5 PRODUCT FUNCTIONALITY
 - 1.6 THE DEVICE
 - 1.6.1 Getting started
 - 1.6.2 How to use Bluetooth
 - 1.6.3 Disconnect Bluetooth
 - 1.6.4 Battery information
 - 1.7 TRUE WIRELESS STEREO MODE
 - 1.8 TROUBLESHOOTING
 - 1.9 CLEANING OF THE PRODUCT
 - 1.10 TECHNICAL SPECIFICATIONS
 - 1.11 IMPORTANT SAFETY INFORMATION
 - 1.12 DISPOSAL OF THE PRODUCT
 - 1.13 COMPLAINTS
- 2 Documents / Resources
 - 2.1 References
- 3 Related Posts

SACKit Go 200

USER MANUAL



SACK it[®]



THANK YOU!

Thank you for purchasing the SACKit Go 200 from SACKit . Please read the entire instruction manual before using the product and save it for future reference . We reserve the right to change or update information and to correct errors or inaccuracies in the text, images, and technical data . If you have any questions regarding technical problems please contact our customer services . We hope you will enjoy your new SACKit Go 200 .

Enjoy great sound on the Go!


QUICK START GUIDE

When you first get your SACKit Go 200 speaker you need to charge it before it is ready for use . SACKit Go 200 is charged by using the included USB cable .

Charge SACKit Go 200 for minimum 3 hours before using the product the first time .

Please turn off the speaker after use to prolong battery life .

PRODUCT OVERVIEW



1. USB-C port (B)
2. Power (A)

PRODUCT FUNCTIONALITY

The following is a description of all the product functions . Please use the ‘Product overview’ above to locate each button and area on the SACKit Go 200 .

(A) Power

- Press and hold this button to turn SACKit Go 200 on or off.
- While SACKit Go 200 is on: Press this button to pause/play the music

(B) USB-C port

- Use this port to charge SACKit Go 200 with the included USB-C charging cable .

THE DEVICE

Getting started

Follow these simple steps to get started:

1. Charge SACKit Go 200 in the USB-C port (B) with the included USB-C charger cable.
2. Turn on SACKit Go 200 by holding down the Power button (A).

How to use Bluetooth

1. SACKit Go 200 automatically enters Bluetooth mode when it is turned on. If no device has been paired with the speaker before, the SACKit Go 200 is waiting for a new connection.
2. Go to the Bluetooth settings on your device and make sure Bluetooth is turned on.
3. Look for “SACKit Go 200” in the list of bluetooth devices.
4. When it appears, tap the name to pair. The speaker emits a confirmation voice saying: “Connected” as soon

as it is paired.

5. Your device is now connected to SACKit Go 200 and you can enjoy your music .

To connect to a new device make sure that the previous connected device is disconnected otherwise connecting opportunities will not appear on the new device.

Disconnect Bluetooth

1. To disconnect the Bluetooth connection to a device, double press the the Power button (A). SACKit Go 200 will play the sound "Disconnected".
2. SACKit Go 200 is now disconnected and is searching for a new device to pair .

Battery information

- Battery: rechargeable lithium battery 950mAh
- Power input: DC5V/1A
- Charging Time: Please be sure the battery has been fully charged before first use. It can take up to 3 hours of charging the first time, but 2 hours normally with a 5V/1A adapter.

TRUE WIRELESS STEREO MODE

Use two SACKit Go 200 together

1. Make sure you have two Go 200 speakers in hand and turn on both speakers . If you are already connected to the devices, please unpair the speakers in the Bluetooth settings on your device.
2. When the speakers are disconnected and the LED's are blinking white, quickly press the Power button (A) twice on both speakers to enter TWS pairing mode . One speaker becomes the master speaker, the other the slave. (The LED flashes green on the master and the LED is solid green on the slave).
3. After TWS pairing between the speakers is successful, the master speaker says "Left channel" and the slave speaker says "Right channel".
4. Find the speakers in your device's Bluetooth settings and connect to them. Both LED's will now display a solid green . You are now ready to play your music.
5. To disable TWS unpair the the speakers in Bluetooth setting on your device. One of the speakers LED will blink green . Double press the blinking LED and the speakers will go back to normal pairing.

TROUBLESHOOTING

If you have trouble operating SACKit Go 200, please search the following options for solving the problem. If these solutions do not help fix your problem, please contact our customer service at info@sackit.dk.

No sound from my SACKit Go 200

- Try to increase the volume on your Bluetooth device.

My SACKit Go 200 make static noise

- If you are using a Bluetooth connection, then please make sure that the speaker and your Bluetooth device is within 10 meters of each other.

Bluetooth connection failed

- Please make sure, that SACKit Go 200 is in correct Bluetooth pairing mode.
- Check if your SACKit Go 200 is already connected to another Bluetooth device. SACKit Go 200 can only be connected to one device at a time.
- Please make sure, that the speaker and your Bluetooth device is within 10 meters of each other.
- Please make sure, that there is no obstructions between the speaker and your Bluetooth device.

I cannot turn on/charge my SACKit Go 200

- Please make sure that the adapter and the charging cable is connected correctly .
- Please check the power adapters voltage and current and check if it matches with the requirements of the SACKit Go 200.

CLEANING OF THE PRODUCT

1. Please turn off SACKit Go 200 and remove it from the power supply before you clean it
2. Do not use any strong chemicals to clean the product as this may damage the surface or fabric.
3. Please use a damp cotton- or microfiber cleaning cloth instead.
4. During cleaning please be aware to avoid water in the USB port or other openings . Large amounts of water and fluids may damage the SACKit Go 200.

NOTE: Avoid using sharp objects while cleaning the SACKit Go 200.

TECHNICAL SPECIFICATIONS

- Bluetooth: V5 .0
- Speaker output: 3W
- Battery operated: Built-in 950mAh rechargeable battery
- Playtime: Up to 8 hours at 60% volume
- Charging time: Around 2 hours via USB-C
- Power input: DC5V/1A
- BT frequency bands:2402-2480MHZ
- Product size: 104 x 91 x 50 mm
- Product weight: 0 .25Kg
- Bluetooth range: 10m
- IP grade: IPX4

SACKit ApS declares that the radio equipment type SACKit Go 200 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://SACKit.eu/support>.

IMPORTANT SAFETY INFORMATION

Please read the following information and operate the product and accessories accordingly to ensure correct and safe use of the product . We are not responsible for damage caused by failure to comply with the instructions or irresponsible use of the product.

Warning

To prevent any fires or electrical hazards please act according to the following guidelines:

- Do not disassemble or replace any parts of this device. Please contact professional maintenance or qualified service center if there is any damage to the device.
- Do not place in any liquids.
- If any liquids find its way inside the product, please shut down the product and contact customer service center.
- Do not place this device in or close to sources of excessive heat or fire. (Such as: candles, fireplaces or direct sunlight).
- Keep this device away from any dust and vibration.
- Do not use excessive force when using any of the control buttons.
- If the product is below 5°C when you receive it, please open the product packaging and wait for it to reach room temperature.
- To prevent overheating of the product is it necessary to keep a cleared area of 10 cm around the product while charging.
- Be sure to place this device on stable, flat and level surfaces while charging.

DISPOSAL OF THE PRODUCT

SACKit Go 200 is made from recyclable and high quality materials . Do not dispose of together with household garbage. Please understand the local classification about collecting electronical, electrical products that contains batteries. Correct disposal of the product will help to prevent negative impact to the environment .

COMPLAINTS

Please contact our customer service if you have a complaint or a broken SACKit Go 200.

SACKit®

Documents / Resources



[SACKit Go 200 Smart Bluetooth Speaker](#) [pdf] User Manual
Go 200 Smart Bluetooth Speaker, Go 200, Smart Bluetooth Speaker, Bluetooth Speaker

References

- [!\[\]\(effbd7993c63c039a58fd3395789cf3f_img.jpg\) SACKit - Officiel Webshop - Køb produkter fra SACKit her!](#)
- [!\[\]\(144980d038f2541d7b588a8a9132bd70_img.jpg\) User manuals](#)

Manuals+.