



SACKit Touch 200 Bluetooth and Active Noise Cancellation Headphone User Manual

[Home](#) » [SACKit](#) » SACKit Touch 200 Bluetooth and Active Noise Cancellation Headphone User Manual 

Contents

- [1 SACKit Touch 200 Bluetooth and Active Noise Cancellation Headphone](#)
- [2 THANK YOU](#)
 - [2.1 Let SACKit rock your life](#)
- [3 PRODUCT OVERVIEW](#)
- [4 PRODUCT FUNCTIONALITY](#)
- [5 THE DEVICE](#)
- [6 PRODUCT SETUP](#)
- [7 TROUBLESHOOTING](#)
- [8 CLEANING OF THE PRODUCT](#)
- [9 TECHNICAL SPECIFICATIONS](#)
- [10 IMPORTANT SAFETY INFORMATION](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

SACK^{it}

SACKit Touch 200 Bluetooth and Active Noise Cancellation Headphone



THANK YOU


Thank you for purchasing the SACKit Touch 200 Bluetooth & Active Noise Cancellation headphones from SACKit. Please read the entire instruction manual before using the product and save it for future reference. We reserve the right to change or update information and to correct errors, inaccuracies, or omissions in the text, images, and technical data. If you have any questions regarding technical problems please contact our customer services. We hope you will enjoy your new SACKit Touch 200 headphones.

Let SACKit rock your life

QUICK START GUIDE

When you first get your SACKit Touch 200 headphones you need to charge them before they are ready for use. SACKit Touch 200 is charged by using the included USB cable. Charge SACKit Touch 200 for 4 hours minimum before using the product the first time. Please turn off your headphones after use to prolong battery life.

PRODUCT OVERVIEW



PRODUCT FUNCTIONALITY

Here follows a description of all the product's features. Please use the Overview in the beginning of this user manual to locate them on the SACKit Touch 200 (page 4).

1. Double doughnut design

- The double doughnut ear cushions ensure both comfort and sound quality by directing sound at you and encapsulating the whole sound without being uncomfortable to wear for a longer time.

2. Active Noise Cancellation (ANC)

- Press the Active noise cancellation button to activate ANC
- With ANC activated you can minimize background noise to further enjoy your music

3. LED Charging Indicator

- Turns on when SACKit Touch 200 is charging

4. Charging port

- Charging port for the included USB charging cable

5. Headband

- Adjustable headband to ensure a comfortable fit for everyone

6. Volume up/down

- Volume buttons used to adjust the volume of SACKit Touch 200
- Also used to skip to next or previous song

7. X Button

- Master function button
- Used to power SACKit Touch 200 on and off
- Plays and pause music when the headset is in Bluetooth mode
- Accepts and rejects incoming calls

8. Power indicator

- Indicates when SACKit Touch 200 is turned on and off
- Flashes when SACKit Touch 200 is in Bluetooth pairing mode

9. 3.5mm AUX

- 3.5 mm AUX jack connection to connect the headset to a device without Bluetooth
- In-line use is possible when the battery is empty

THE DEVICE

How to pair SACKit Touch 200 and your device

1. First use: Long press the X Button for 10 seconds. After the first 5 seconds, you will hear the ON sound. Keep pressing the button for another 5 seconds to turn on pairing mode, indicated by flashing the power indicator red and blue
2. Switch on Bluetooth on your device
3. Choose "SACKit Touch 200" under Bluetooth settings on your device. Your headphones are now connected with your device
4. Start playing music on your device
5. Long press the X button to turn off your SACKit Touch 200 headphones

6. SACKit Touch 200 will automatically pair with the last connected device To connect to a new device make sure that the previous connected device is disconnected otherwise connecting opportunity won't appear on the new device. Operation instructions for use after first pairing
1. After first time pairing your SACKit Touch 200 headphones and your Bluetooth device will be connected automatically
 2. The Bluetooth device will automatically reconnect, the LED light will blink blue once SACKit Touch 200 is successfully paired.
 3. Turn the headphones on by holding down the X button until you hear the ON sound
 4. Long press X button to turn off SACKit Touch 200

Note:

If the pairing is not successful, please turn the headphone off and back on and retry pairing. Bluetooth Multipoint SACKit Touch 200 comes with the Bluetooth Multipoint feature. This means that up to two devices can be connected to the headphones at the same time. This enables you to for example connect the headphones to a computer and a smartphone at the same time. To switch between the two devices, just pause the music/sound on one device and press play on the other. If your phone rings, the SACKit Touch 200 will automatically jump on the phone. To connect a second Bluetooth device after a first one is already connected: Turn off the SACKit Touch 200, Then long-press the X Button for 10 seconds. After the first 5 seconds, you will hear the ON sound. Keep pressing the button for another 5 seconds to turn on pairing mode, indicated by flashing the power indicator red and blue Switch on Bluetooth on your new device Choose "SACKit Touch 200" under Bluetooth settings on your device. Your headphones are now connected with your new device

Operation instructions for in-line use

Use the 3.5mm audio cable when you do not wish to use a Bluetooth connection or when the battery needs recharging. In-line use is possible when the battery is empty.

For in-line use

- Connect the 3.5mm plug into your SACKit Touch 200 Headphone 3.5mm jack, then connect the other 3.5mm plug to your device 3.5mm jack
- Adjust the volume using the controls on your mobile phone
- Enjoy the music

How to use the Active Noise Cancellation function

1. Push the ANC button on the left ear cup turning on the green LED light and you can enjoy the headphones in Active Noise Cancellation mode
2. When you don't need the Active Noise Cancellation function, turn the ANC function off by pushing the ANC button
3. Active Noise Cancellation can be activated and deactivated even when the SACKit Touch 200 Headphone is turned off. The Active Noise Cancellation will also remain on even when you turn the SACKit Touch 200 Headphone off.

Battery information

- Battery: rechargeable Polymer Lithium-Ion Battery, DC: 3.7V/500mAh
- Power: USB DC5V, Please use the USB cable sealed with our headphones for charging
- Charging Time: For first-time use please be sure the battery has been charged fully before use. It needs more than 4 hours of charging the first time, then 2-3 hours for recharging
- When the red light is on, the headphone is in charge mode. The red light will turn off when the battery is fully charged.

PRODUCT SETUP

Here follows a description of the setup of the product. A detailed description of the buttons and functionality can be found at pages 4 to 5.

Playing Music with SACKit Touch 200

When SACKit Touch 200 connects with the mobile phone or Bluetooth transmitter, you can enjoy music through the headphone wirelessly.

Functions	Status of headphone	Operation
Pause	Playing music	Short Press X button
Play	Pausing	Short Press X button
Next track	Playing music	Short press volume(+) button
Previous track	Playing music	Short press volume(-) button
Volume up	Playing music	Long press Volume(+) button
Volume down	Playing music	Long press Volume(-) button

Making calls with SACKit Touch 200

When SACKit Touch 200 is connected to your device, you can answer and take calls through the headphones wirelessly.

Functions	Status of headphone	Operation
Redial Last number	Standby mode	Short press X button twice quickly
Volume up	Conversation mode	Short press Volume(+) button
Volume down	Conversation mode	Short press Volume(-) button
Answering calling	Ringling	Short press X button
End call	Conversation mode	Short press X button
Reject calling	Ringling	Press and hold X button for one second until you hear indication sound
Transfer the calling between headset and Bluetooth devices	Conversation mode	Press and hold the X button for 3 seconds can transfer the conversation from headset to mobile phone . Then press and hold the X button for 3 seconds to transfer the conversation back from mobile phone to headphone .

Note:

Not all mobile phones support all the functions listed above. Please refer to the instruction of your device. Some functions and indication tones may vary with depending on the device.

TROUBLESHOOTING

If you have trouble using your SACKit Touch 200 we ask you to try the following solutions. If these solutions does not fix your problem please contact our customer service at info@sackit.dk. I experience issues with stability and connection.

- Try to delete the pairing between SACKit Touch 200 and your device on the device. You do this by accessing the Bluetooth settings on your device and choose “forget SACKit Touch 200”. Now pair SACKit Touch 200 and your device by following the description found on 6SACKit Touch 200 is not playing music while connected to my device.
- Please check the volume on your audio device to make sure it is outputting sound
- If you use in-line please make sure that the 3.5mm plug is fully inserted into your audio device and headset. And please make sure the headphone plug and audio device’s jack sticks are clean
- If SACKit Touch 200 is used wirelessly and still is not playing music, you manually have to choose to play from SACKit Touch 200 in your device settings. Please refer to the instruction of your device or specific app for further information I’m hearing a beep sound in my headset
- When SACKit Touch 200 makes a beep sound, they need recharging. Please charge your headphones fully I don’t feel like SACKit Touch 200 is comfortable to wear.
- Please adjust the length headband by pull/pushing the earcups to adjust to the headset for a comfortable fit I can’t turn on my headset.
- Please recharge your headset by leaving the headset in the charger for minimum 4 hours

CLEANING OF THE PRODUCT

1. Kindly switch off SACKit Touch 200 before you clean your headset and remove it from the power supply
2. Do not use any chemicals to clean the product. If you need to clean the headset, please use a soft cloth with a mild cleaner
3. During cleaning please be aware to avoid water in the USB port, speakers, microphone, and buttons. Large amounts of water and fluids may damage the headset
4. Use a soft, dry, and lint-free cloth to gently clean the speaker fabric.

NOTE:

Avoid using sharp objects to clean SACKit Touch 2

TECHNICAL SPECIFICATIONS

- Model: SACKit Touch 200 Bluetooth and ANC headphones
- Bluetooth version: V5.0
- Operating distance: 10M
- Bluetooth Multipoint
- Battery: 500mAh
- Charging time: 3 hours

- Charging current: 220mA
- Music playing time: 25 hours (Bluetooth on, ANC off) 18 hours
- (Bluetooth on, ANC on)
- Call time: 25 hours
- ANC solution: MAX
- Noise reduction performance: up to 22dB
- Frequency Range: 20Hz-20KHz
- Impedance: ANC_OFF:80Ω ANC_ON:110Ω
- Size: 78x180x165mm
- Weight: 230g

IMPORTANT SAFETY INFORMATION

Please read the following information and operate the product and accessories accordingly to ensure the correct and safe use of the product. We are not responsible for damage caused by failure to comply with the instructions or irresponsible use of the product.

Warning

To prevent any fires or electrical hazards please act according to the following guidelines:

- Do not disassemble or replace any parts of this device. Please contact professional maintenance or a qualified service center if there is any damage to the device.
- Do not place in any liquid
- If any liquids flows inside the product, please shut down the product and contact the customer service center
- Do not place this device in or close to sources of excessive heat or fire. (Such as: candles, fireplaces or direct sunlight)
- Please shut down in lightning weather
- Keep this device away from any dust and vibration.
- Do not use excessive force when using any of the control buttons.
- If the product is below 5°C when you receive it, please open the product packaging and wait for it to reach room temperature.
- To prevent overheating of the product is it necessary to keep a cleared area of 10 cm around the product while charging
- Be sure to place this device on stable, flat and level surfaces while charging.

DISPOSAL OF THE PRODUCT

SACKit Touch 200 is made from recyclable and high-quality materials. Do not dispose of it together with living garbage. Please understand the local classification about collecting electronical, electrical products that contain batteries. Correct disposal of the product will help to prevent a negative impact to the environment.

COMPLAINTS

Please contact our customer service if you have a complaint or a broken SACKit Touch 200 headset. If your headset has a defect, please inform your serial number, when you contact us.

Documents / Resources



[SACKit Touch 200 Bluetooth and Active Noise Cancellation Headphone](#) [pdf] User Manual
Touch 200, On-Ear Headphones, Touch 200 Bluetooth and Active Noise Cancellation Headphone, Bluetooth and Active Noise Cancellation Headphone