

**SAFE-T-GRIP
Deep Fry
Pan Set**



Safe-T-Grip Deep Fry Pan Set Instructions

[Home](#) » [Safe-T-Grip](#) » Safe-T-Grip Deep Fry Pan Set Instructions 

Contents

- [1 Safe-T-Grip Deep Fry Pan Set](#)
- [2 Specifications:](#)
 - [2.1 Product Usage Instructions](#)
 - [2.2 Frequently Asked Questions](#)
 - [2.3 USE & CARE INSTRUCTION](#)
 - [2.4 LIMITED 2-YEAR WARRANTY](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

SAFE – T – GRIP

Safe-T-Grip Deep Fry Pan Set



Specifications:

- Brand: TSC Product Lab
- Manufacturer: The Sneaky Chef, Inc.
- Location: Sag Harbor, NY 11963
- Origin: Made in China

Product Information:

Your new cookware from TSC Product Lab, a division of The Sneaky Chef, Inc., is designed to provide you with many enjoyable cooking experiences. The brand emphasizes healthy cooking, and this cookware is crafted to help you achieve that goal.

Product Usage Instructions

Initial Cleaning:

Before using the cookware for the first time, wash it with warm soapy water and dry it thoroughly.

Heat Settings:

Use low to medium heat settings with this cookware to ensure optimal cooking results and prolong its lifespan.

Utensils:

When cooking with this cookware, it is recommended to use wooden or silicone utensils to avoid damaging the cooking surface.

Cleaning and Maintenance:

After each use, hand wash the cookware with mild detergent and a soft sponge. Avoid using abrasive cleaners or metal scouring pads.

Storage:

Store the cookware in a dry place to prevent any moisture build-up that could lead to damage over time.

Frequently Asked Questions**Q: Can this cookware be used in the oven?**

A: Please refer to the specific product guidelines. Some cookware items may be oven-safe while others are not.

Q: Is this cookware dishwasher safe?

A: It is recommended to hand wash this cookware to maintain its quality and extend its lifespan.

USE & CARE INSTRUCTION**When you take it out of the package:**

- Wash in warm soapy water with a soft cloth.
- Dispose of packing materials in an environmentally friendly way.

When it's time to cook:

- This pan can be used on gas, electric, and ceramic ranges (not for use on induction cooktops)
- Preheat the pan to low to medium heat for 3-5 minutes. Cook at moderate heat. Do not preheat on high setting. You will find that the aluminum base provides very quick and even heat conduction for easy cooking. • Do not allow the pan to boil dry; not only is that dangerous for your home but also may permanently damage the ceramic cooking surface.
- Please use nylon, silicone, or wood utensils for cooking, as the metal utensils will damage the ceramic cooking surface.
- Do NOT expose the handle to the open flame. • Can add cooking oil or butter for better cooking results.
- The handle can become hot in use, and adequate protection such as an oven glove should be used at all times.
- The pan and lid are oven-safe up to 300°F/150°C degrees.
- When moving cookware on the hob, always lift it to prevent scratching. Aluminum-based products may leave silver stains on the stove too. But these can be removed using a suitable deterrent.

When it's time to clean:

- Make sure that your pan is clean and dry after use. Food particles that remain on your pan tend to become harder to remove after continued use.
- Hand washing your cookware in warm water with soap is always your best choice, If you do choose to put your cookware in the dishwasher, please choose alkaline-based detergents to dissolve grease, oil, and fats.
- After cooking, please allow the pan to cool thoroughly before immersing it in water. Do not wash the pan right after cooking, as it may affect non-stick ability and also cause irreparable warping of the pan. How to care for your new cookware:
- Do not use any abrasive substances such as chemical or mineral cleaners.
- Do not use harsh or rough material to clean.
- Do not use scouring pads or steel wool unless they are specifically made for ceramic-coated pans.


- Make sure the pan is clean and dry before storing away.

With proper use and care your new cookware should give you many pleasant cooking experiences. Remember, healthy cooking starts in the pan.

LIMITED 2-YEAR WARRANTY

This is the only express warranty for this product. The Sneaky Chef, Inc., warrants this product to be free from defects in material and workmanship for single-family household use for two years from the date of original purchase. Ordinary wear and tear including damage to the coating and cooking surface is excluded. Use of the product for anything other than its intended purpose is also not warranted. We exclude liability for all consequential damages. Your exclusive remedy is repair or replacement of the nonconforming product, at our option. All liability is limited to the purchase price. All other warranties, including any statutory warranty or condition of merchantability or fitness for a particular purpose, are disclaimed. You may have legal rights that vary depending on where you live. For repair or replacement, please contact our Cookware Team with information on your product’s proof of purchase and a description of the problem.
Customer Service Number: [844-689-0936](tel:844-689-0936) TSC Product Lab, a div of The Sneaky Chef, Inc. Sag Harbor, NY 11963 **Made in China**

Documents / Resources

	Safe-T-Grip Deep Fry Pan Set [pdf] Instructions Deep Fry Pan Set, Fry Pan Set, Pan Set, Set
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.