



Sage 43331277 Utility Cart with Lockable Instruction Manual

[Home](#) » [Sage](#) » Sage 43331277 Utility Cart with Lockable Instruction Manual 



Assembly Instruction
43331277 SAGE SLIM LINE TROLLEY

Contents

1 CARE INSTRUCTIONS:

**2 Documents /
Resources**

2.1 References








CARE INSTRUCTIONS:

Load drawer evenly to prevent from tipping over.



WARNING:

This package contains small parts and sharp points, keep unassembled parts away from children and babies.

Hardware list



	A	Top tube	2PCS
	B	Bottom tube	2PCS
	C	Basket	3PCS
	D	Wheel	2PCS
	E	Wheel with brake	2PCS
	F	Nut	4PCS
	G	Screw	4PCS

STEP1




Ensure that basket securing rails face the inside of trolley as pictured in blowup diagrams of steps1, 2 & 3

STEP2



STEP 3




STEP 4



Sage

Documents / Resources

	<p>Sage 43331277 Utility Cart with Lockable [pdf] Instruction Manual</p> <p>43331277 Utility Cart with Lockable, 43331277, Utility Cart with Lockable, Cart with Lockable, Lockable</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.