



Saitake STK-4003 Wireless Game Controller Joystick User Manual

[Home](#) » [Saitake](#) » Saitake STK-4003 Wireless Game Controller Joystick User Manual

Saitake

STK-4003 Wireless Game Controller Joystick User Manual

Contents [[hide](#)]

- [1 Before use](#)
- [2 Precautions](#)
- [3 Exterior protection](#)
- [4 Storage](#)
- [5 Pair your controller](#)
- [6 Charging your controller](#)
- [7 Specification](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)


Before use

Carefully read this manual and any manuals for compatible hardware. Retain instructions for future reference. Always update your system to the latest version of system software.

Precautions

Safety

- Avoid prolonged use of this product. Take a 15-minute break during each hour of play.
- Stop using this product immediately if you begin to feel tired or if you experience discomfort or pain in your hands or arms during use, If the condition persists, consult a doctor.
- If you experience any of the following health problems, discontinue the use of the system immediately.
If symptoms persist, consult a doctor,
 - Dizziness, nausea, fatigue, or symptoms similar to motion sickness.

- Discomfort or pain in a part of the body, such as eyes, ears, hands, or arms.
- The product is intended for use with the hands only. Do not bring it into close contact with your head, face, or the bones of any other part of the body.
- The vibration function of this product can aggravate injuries. Do not use the vibration function if you have any ailment or injury to the bones, joints, or muscles of your hands or arms. You can turn on or turn off the vibration function from  (setting) on the function screen.
- Permanent hearing loss may occur if the headset or headphones are used at a high volume. Set the volume to a safe level. Over time, increasingly loud audio may start to sound normal but can actually be damaging your hearing. If you experience ringing or any discomfort in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the sooner your hearing could be affected. To protect your hearing:
 - Limit the amount of time you use the headset or headphones at high volume.
 - Avoid raising the volume to block out noisy surroundings.
 - Lower the volume if you can't hear people speaking near you.
- Avoid looking into the light bar of the controller when it is flashing. Stop using the controller immediately if you experience any discomfort or pain in any body parts.
- Keep the product out of the reach of small children. Young children might damage the product causing it to malfunction, swallow small parts, wrap the cables around themselves or accidentally injure themselves or others.

Use and handling

When using the controller, be aware of the following points.

- Before use, make sure that there is plenty of space around you.
- Firmly grip your controller to prevent it from slipping out of your grasp and causing damage or injury.
- When using your controller with a USB cable, ensure that the cable cannot hit a person or any object, and do not pull the cable out of the PlayStation 4 system whilst playing.
- Do not allow liquid or small particles to get into the product.
- Do not allow touching the product with wet hands.
- Do not throw or drop the product or subject it to strong physical shock,
- Do not put heavy objects on the product.
- Do not touch the inside of the USB connector or insert foreign objects.
- Never disassemble or modify the product.

Exterior protection

Follow the instructions below to help prevent the product exterior from deteriorating or becoming discolored.


- Do not place any rubber or vinyl materials on the product exterior for an extended period of time.
- Use a soft, dry cloth to clean the product. Do not use solvents or other chemicals. Do not wipe with a chemically-treated cleaning cloth.

Storage

- Do not expose the product to high temperatures, high humidity, or direct sunlight.
- Do not expose the product to dust, smoke or steam.

Pair your controller

You'll need to pair your controller when you use it for the first time and when you use it with another P4 system. Turn on the P4 system and connect the controller with the USB cable to complete device pairing.



Hint

When you press the PS button, the controller turns on and the light bar glows in your assigned color. The color that is assigned depends on the order in which each user presses the PS button. The first controller to connect is blue, with subsequent controllers glowing red-green, and pink. For details on using the controller refer to the user's guide of the PS4 system,

Charging your controller

Caution-using the built-in battery:

- This product contains a lithium-ion rechargeable battery.
- Before using this product, read all instructions for handling and charging the battery and follow them carefully.
- Take extra care when handling the battery, Misuse can cause fire and burns.
- Never attempt to open, crush, heat, or set fire to the battery.
- Do not leave the battery charging for a prolonged period of time when the product is not in use.
- Always dispose of used batteries in accordance with local laws or requirements.
- Do not handle the damaged or leaking battery.
- If the internal battery fluid leaks, stop using the product immediately and contact technical support for

assistance, If the fluid gets onto your clothes, skin, or into your eyes, immediately rinse the affected area with clean water and consult your doctor. The battery fluid can cause blindness.

Battery life and duration:

The battery has a limited life span. Battery charge duration gradually decreases with repeated usage and age. Battery life also varies depending on the storage method, usage state, environment, and other factors. Charge in an environment where the temperature range is between 10°C-30°C Charging may not be as effective when performed in other environments. Battery duration may vary depending on the usage condition and environmental factors.

When not in use:

When the controller is not used for an extended period of time, it is recommended that you fully charge it at least once a year in order to maintain its functionality.

Specification

Input power rating	DC 5V600Ma
Battery type	Built-in rechargeable Lithium-ion battery
Voltage	DC 3.65V
Battery capacity	600mAh
Operation temperature	5°C-35°C
Mass	Approx. 210g
Country of Production	China

Design and specifications are subject to change without notice.

Wireless Controller
STK-4003

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirements, The device can be used in portable exposure conditions without restriction.

Documents / Resources

	<p>SaitaKE STK-4003 Wireless Game Controller Joystick [pdf] User Manual STK-4003, STK4003, 2ATI7STK-4003, 2ATI7STK4003, STK-4003 Wireless Game Controller Joystick, Wireless Game Controller Joystick</p>
---	---