



# SAL SWL10L Push Button Switch User Guide

[Home](#) » [SAL](#) » SAL SWL10L Push Button Switch User Guide 

## Contents

- [1 SAL SWL10L Push Button Switch](#)
- [2 Foreword](#)
- [3 Product Introduction](#)
- [4 Product Features](#)
- [5 Product illustration](#)
- [6 Specifications](#)
- [7 Wiring and Installation](#)
- [8 Installation process](#)
- [9 Warranty](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)



## SAL SWL10L Push Button Switch



## Product Information

<b>Model No.</b>	SWL10L
<b>Input (V)/(Hz)</b>	250/50
<b>Load rating</b>	10AX
<b>IP</b>	20
<b>Color</b>	White
<b>Dimension L x W x H (mm)</b>	42 x 22 x 22
<b>Wireless</b>	N/A

## Product Usage Instructions

### Wiring and Installation

LED indicator permanently on Load off permanently, on momentarily Connect the light fitting (Load) to the NEUTRAL and ACTIVE terminals. The LED indicator will be permanently on, and the load will be off permanently but can be turned on momentarily. LED indicator off permanently, on momentarily Load off permanently, on momentarily Connect the light fitting (Load) to the NEUTRAL and ACTIVE terminals.

The LED indicator will be off permanently, and the load will be off permanently but can be turned on momentarily. LED indicator permanently on Load on permanently, off momentarily Connect the light fitting (Load) to the NEUTRAL and ACTIVE terminals. The LED indicator will be permanently on, and the load will be on permanently but can be turned off momentarily. LED indicator on permanently, off momentarily Load on permanently, off momentarily Connect the light fitting (Load) to the NEUTRAL and ACTIVE terminals. The LED indicator will be on permanently, and the load will be on permanently but can be turned off momentarily.

### Warranty

In accordance with SAL's standard terms and conditions of sale, SAL warrants this product to be free from defects in materials and/or workmanship for a specified period. This warranty does not cover incorrect installation, maintenance, operation, mishandling, environmental factors, unauthorized modifications, or electrical operating conditions outside the specified product specification. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

To make a claim under warranty, contact SAL National Pty Ltd at the following addresses:

<b>State</b>	<b>Address</b>
NSW   ACT	40 Biloela Street Villawood NSW 2163
QLD	36 Whitelaw Place Richlands QLD 4077
VICT   TAS   SA   NT	46-48 Keys Road Moorabbin Victoria 3189
WA	29 Beringarra Av Malaga WA 6090

## Foreword

**IMPORTANT:** IN THE INTEREST OF PRODUCT PERFORMANCE AND SAFETY PLEASE READ THESE GUIDE AND WARRANTY INSTRUCTIONS BEFORE INSTALLING THE PRODUCT

SAL products are designed in accordance with all mandatory International and Australian Standards, which require installation in accordance with AS/NZS3000 by a qualified installer and regular cleaning and maintenance of the equipment. Products are sold in accordance with the following instructions and SAL standard terms and conditions of sale, available via [www.sal.net.au](http://www.sal.net.au) Due to continued product and information updates, product data sourced from sal.net.au shall not form part of any contract and or technical performance guarantee unless expressly confirmed in writing by SAL at the time of order. The product wireframe drawings in this document are intended for illustration purposes only and may differ from the final physical product. The installation instruction is subject to change without prior notice.

## Product Introduction

SAL Push Button Switch is a mechanical push button ON/OFF switch, with different wiring options to enable/disable the LED indicator.


## Product Features

- Fits most branded switchplates
- Fits 1 to 6 gang wall plate installation
- Same look as PIXIE smart switches under the PIXIE ambiance cover plate
- LED indicator can be enabled and disabled
- 10AX load rating

## The package includes

- SAL Push Button Switch \* 1
- Extra keycaps \* 2
- Quick Start Guide \* 1

## Product illustration





All drawings shown are for illustration purposes only, the actual product may vary due to product enhancement.

## Specifications

Model No.	Input (V)/(Hz)	Load rating	IP	Colour	Dimension L x W x H (mm)	Wireless
SWL10L	250/50	10AX	20	White	42 x 22 x 22	N/A

## Wiring and Installation



### LED indicator permanently on



Load off permanently, on momentarily

### LED indicator off permanently

on momentarily Load off permanently, on momentarily



LED indicator permanently on Load on permanently, off momentarily

LED indicator on permanently, off momentarily Load on permanently, off momentarily

## Installation process

- Make sure the key cap compatibility, fits a suitable keycap
- Check and confirm the load compatibility
- Turn OFF the mains electricity supply before commencing installation
- Connect the switch according to the wiring diagram
- Turn ON the mains electricity supply, then test the switch operation by pressing the switch button.

## Warranty

In accordance with SAL's standard terms and conditions of sale, SAL warrants this product to be free from defects in materials and or workmanship for a period as stated below for goods not subject to incorrect installation, maintenance, operation, mishandling, environmental, unauthorized modifications or electrical operating conditions outside the nominated product specification as detailed in these installation instructions. The benefits to you given by this warranty are in addition to other rights and remedies you have under the law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**Warranty term** – Residential usage (12) months, Commercial usage (12) months

### How to make a claim?

**Step #1** – Within 30 days of the fault discovery, please contact the original place of the SAL product purchase during standard (local) business hours, with the following information (a) proof of purchase (b) description and

quantity of the claimed fault (c) address of installation. (d) operating hours of the product.


**Step #2** – It is then the responsibility of the original place of product purchase to report the matter to SAL aftersales;

NSW   ACT	SAL National Pty Ltd, 40 Biloela Street Villawood NSW 2163	P # 02 9723 3099
QLD	SAL National Pty Ltd, 36 Whitelaw Place Richlands QLD 4077	P # 07 3879 5999
VICT   TAS   SA   NT	SAL National Pty Ltd, 46-48 Keys Road Moorabbin Victoria 3189	P # 03 9532 3168
WA	SAL National Pty Ltd, 29 Beringarra Av Malaga WA 6090	P # 08 9248 7458

**Step #3** – Upon review of your claim and if the product is required to be returned to SAL for technical evaluation, then at the owner's expense the product must be returned to SAL as per the above-nominated locations.

**Step #4** – Pending the evaluation, the claim will be validated resulting in the product being repaired or replaced with the same or best equivalent product at the discretion of SAL, or rejected if the product fault was found to be caused by conditions beyond the responsibility of SAL warranty obligations. Consideration of installation, product removal, return freight, and or testing fees are not the responsibility of SAL.

## Documents / Resources

	<a href="#">SAL SWL10L Push Button Switch</a> [pdf] User Guide SWL10L Push Button Switch, SWL10L, Push Button Switch, Button Switch
--	--

## References

- [Welcome to SAL - Lighting a Smarter Future - SAL](#)
- [Welcome to SAL - Lighting a Smarter Future - SAL](#)