




**Contents** [ [hide](#) ]

- [1 Samhoo D580, D588 Two Way Radio](#)
- [2 User Information](#)
- [3 Optional Accessories](#)
- [4 Product controls](#)
- [5 Before Use](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)



## Samhoo D580, D588 Two Way Radio



## **Preface**

Thanks for your favor in our product. To derive optimum performance from the product, please read this manual carefully before using it.

## **This manual applies to the following models of A580 series:**

A580Vs A580 A580 IJ4

A588Vs A588 A588 IJ4 two-way radio products.

## **User Information**

- Government law prohibits governmental jurisdiction within the scope of unauthorized use of radio.
- Illegal operation will be subject to fines or arrest.
- Repair only by trained professional and technical personnel.
- Security: Users need to know and understand the use of radio.
- Note: The pictures presented in this manual are only for reference!

## **Note**

- Please observe the following precautions to prevent fire, personal injury and damage to the radio.
- Continuous using radio long time or at high power transmit mode will cause the heat of the back of the terminal.
- In any case, do not dismantling the unit. Do not let the terminal by prolonged direct sunlight, and do not use the radio near the heating device.
- Do not put the radio on extremely dusty, damp and splashing water areas, and also on uneven surface.
- If you find any unusual smells or smoke from the terminal, you should immediately remove the battery, and contact with the local dealer.

## **Instructional Icon**

- The following icons are available through this manual:
- Caution: Indicates situations that could cause damage to your radio. you make better use of your radio. restricted function.

- Note: Indicates tips that can
- Asterisk: Indicates the currently

## **Term Explanation**

### **Key operation**

Short press: To press the key and release it quickly. Long press: To press the key and remain holding it down about a period of 1.5 seconds Hold down: To press the key and remain holding it down.

### **Group call**

Group call is initiated by a single us to a group. Involving the calling party and all the group members.

### **Emergency call**










An emergency call is the highest priority call. It is used to call for help to the companion or the control center in an emergency situation. The general set is a group call form. If initiating an emergency call, any non-emergency calls can be interrupted.

### **Conventional mode**

Under conventional mode, Simplex communication can be carried out directly between the terminals without ne two limitations. But the user cannot use the functions that need network support.

### **Checking Items In The Package**







Please unpack carefully and check that all items listed below are received. The radio unit is ASB0 or ASBB .if any item is missing or damaged, please contact your dealer.

		
Battery	Power adapter	Antenna
		
Belt clip	Charger	Strap
		
A580 Radio unit	A588 Radio unit	Ower's manual

## Note

1. The frequency band of the antenna is marked on the label of it, if not, please refer to the label on the radio unit for frequency band information.
2. The pictures presented in this manual are only for reference!

## Optional Accessories


		
D-Earset	Programming cable	Six-Slot Desk Charger
		
Transparent Acoustic Tube Earset	Hand microphone	Desk Charger Power adapter

**Note:** If you need to know more information about the optional accessories, please contact us.


In order to ensure the normal operation of the machine and the user's personal safety, be sure to select the right accessories.

## A580 Product Overview

## Product controls




NO.	Part Name	NO.	Part Name
1	LED Indicator	2	Emergency Call Key
3	Antenna	4	PTT Key (transmit key)
5	SK1 (Battery strength broadcast)	6	SK1 (Safety flashing light ON-OFF)
7	Channel Knob	8	Radio ON-OFF/Volume
9	Speaker	10	Accessory Jack Cover
11	Microphone	12	Safety flashing light
13	Accessory Jack	14	Strap Hole
15	Belt Clip	16	Battery
17	Battery Pole Piece	18	Battery Latch



NO.	Part Name	NO.	Part Name
1	LED Indicator	2	Emergency Call Key
3	Antenna	4	PTT Key (transmit key)
5	SK1 (Battery strength broadcast)	6	SK1 (Safety flashing light ON-OFF)
7	Channel Knob	8	Radio ON-OFF/Volume
9	Speaker	10	Accessory Jack Cover
11	Microphone	12	Safety flashing light
13	Accessory Jack	14	Strap Hole
15	Belt Clip	16	Battery
17	Battery Pole Piece	18	Battery Latch
19	LCD Display	20	Function Keypad

## Programmable keys

[Sk1] key, [SK2] key can be set as function menu shortcut keys by your dealer. You only need to press the corresponding key to quickly access the needed menu or function.



## LED indicators

The LED indicator on top provides you with the information of the current operation status of the radio.

<i>Handheld terminal status</i>	<i>Indicator status</i>
Transmitting the call	LED glows red
Receiving the call	LED glows green
Phone call	LED glows red on both sides
Channel is idle	LED flashes green slowly
Channel is busy	LED glows orange

## Before Use

### Charging the battery

#### Charging operation steps

Please only use the charger and battery specified by the indicator of the charger can show the charging progress.

1.



As 8 shown, connect the power adapter to AC power socket and the jack at the back of the charger.

2. As shown, insert the battery or the radio with battery into the charger, and make sure the contact between the battery and charger is good.
3. The charging process initiates when the indicator glows red.
4. When the indicator turns green, it indicates that the charging is finished.

The charging time for the standard battery normally takes about 3 hours, for optimal battery performance, the first charging time should be up to 5 hours.

### Charger LED indicator and charging status

<i>LED indication</i>	<i>Charging status</i>
LED flashes red  and green alternatively	Standby(not loaded)
LED glows red	Charging status
LED glows green	Fully charged

## Documents / Resources

	<a href="#">Samhoo D580, D588 Two Way Radio [pdf]</a> Owner's Manual D588-U1, 2ABUB-D588-U1, 2ABUBD588U1, D580 D588 Two Way Radio, D580 D588, Two Way Radio, Radio
--	--

### References

- [User Manual](#)

■ SAMHOO

🔑 2ABUB-D588-U1, 2ABUBD588U1, D580 D588, D580 D588 Two Way Radio, D588-U1, Radio, SAMHOO, Two-Way Radio

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.



