




Sammode Cugnot 100 LED Luminaire Instruction Manual

[Home](#) » [Sammode](#) » Sammode Cugnot 100 LED Luminaire Instruction Manual 


Contents

- [1 Sammode Cugnot 100 LED Luminaire Instruction Manual](#)
- [2 Sammode Cugnot 100 LED Luminaire](#)
 - [2.1 Do not open when energized](#)
- [3 Read More About This Manual & Download PDF:](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Sammode Cugnot 100 LED Luminaire Instruction Manual



Sammode Cugnot 100 LED Luminaire



CUGNOT 100

Type	L	Entraxe max
	(mm)	(mm)
12H	697	611
13H	1007	911
14H	1307	1211
15H	1607	1511
16H	1850	1754


CUGNOT 133

Type	L	Entraxe max
	(mm)	(mm)
22H	737	833
23H	987	891
24H	1287	1191
25H	1587	1491
26H	1587	1754




Do not open when energized


Installation & raccordement / Wiring / Verkabelung




1.




2.




3.



4.




1.




2.



3.




4.




5.




6.




1. Position & cable / Position & cabl,e / Posit:ion & kabel



2. Ftasques / End caips / Endkap1pen



3. Vis centrale / Central screw/ Zentrale .schraube



Read More About This Manual & Download PDF:

Documents / Resources

[Sammode Cugnot 100 LED Luminaire](#) [pdf] Instruction Manual
Cugnot 100 LED Luminaire, Cugnot 100, LED Luminaire