



samsara CBL-VG-CRCR-Y1 Vehicle Gateway Installation Guide

[Home](#) » [Samsara](#) » samsara CBL-VG-CRCR-Y1 Vehicle Gateway Installation Guide 










samsara

CBL-VG-CRCR-Y1 Vehicle Gateway
Installation Guide

samsara.com/support

DRAFT





| | |
|--|--|
| <p>1</p>  | <p>2</p>  |
| <p>Locate the reefer control panel that is usually located on the dashboard.</p> | <p>Disconnect th</p> |
| <p>3</p>  | <p>4</p>  |
| <p>Connect the Samsara cable (A) to the reefer cable and (B) to the control panel.</p> | <p>Connect the L way.</p> |
| <p>5</p>  | <p>6</p>  |
| <p>Fasten connected gateway in a secure position. Verify the gateway indicator light turns green, this could take 1-3 minutes.</p> | <p>Mount the cor board.</p> |

DRAFT
samsara.com/support

Contents
[1 Documents / Resources](#)
[2 Related Posts](#)

Documents / Resources

| | |
|---|---|
|  | <p>samsara CBL-VG-CRCR-Y1 Vehicle Gateway [pdf] Installation Guide CBL-VG-CRCR-Y1, Vehicle Gateway, CBL-VG-CRCR-Y1 Vehicle Gateway</p> |
|  | <p>Samsara CBL-VG-CRCR-Y1 Vehicle Gateway [pdf] Installation Guide CBL-VG-CRCR-Y1 Vehicle Gateway, CBL-VG-CRCR-Y1, Vehicle Gateway, Gateway</p> |