



[Home](#) » [Samsung](#) » **SAMSUNG QA75Q7FAAXXZW QLED Smart Display Installation Guide** 

Contents [[hide](#)]

[1 SAMSUNG QA75Q7FAAXXZW QLED Smart Display](#)

[2 PACKAGE CONTENT](#)

[3 Specifications](#)

[4 Unpacking Instructions](#)

[5 Installation Instructions](#)

[6 FAQ](#)

[7 Documents / Resources](#)


[7.1 References](#)

SAMSUNG

SAMSUNG QA75Q7FAAXXZW QLED Smart Display





PACKAGE CONTENT



Specifications


Model	A (mm /in)	B (mm /in)	C (m m/in)	D (mm/ in)	E (mm/ in)	F (mm /in)	G (m m/in)	H (m m/in)
QA75Q7FA AXXZW	1677.5 / 66.0	962.4 / 37.9	61.1 / 2.4	1006.3 / 39.6	1031.3 / 40.6	325.0 / 12.8	189 / 7.4	25.3 / 1.0

QA75QEF1 AXXZW	1677.5 / 66.0	962.4 / 37.9	61.4 / 2.4	1006.3 / 39.6	1031.3 / 40.6	359.0 / 14.1	214 / 8.4	32.5 / 1.3
QA85Q7FA AXXZW	1901.2 / 74.9	1088.4 / 42.8	61.4 / 2.4	1132.3 / 44.6	1157.3 / 45.6	359.0 / 14.1	214 / 8.4	33.1 / 1.3



	A	B	C	D	E	F	G	H	I
QA75Q7FAAXXZW QA75QEF1AXXZW	1677.5 公釐	962.4 公釐	61.1 公釐	1006.3 公釐	1031.3 公釐	325.0 公釐	189 公分	25.3 公斤	25.8 公斤
QA85Q7FAAXXZW	1901.2 公釐	1088.4 公釐	61.4 公釐	1132.3 公釐	1157.3 公釐	359.0 公釐	214 公分	32.5 公斤	33.1 公斤

數字僅供參考以實機為主



	VESA 螺絲孔規格 A x B (單位：公釐)	C (公釐)	D x 4
QA75Q7FAAXXZW QA75QEF1AXXZW	400 x 400	19-21	M8
QA85Q7FAAXXZW	600 x 400		


Unpacking Instructions

1. Handling the TV

- For 75" and 85" models, ensure two people lift the TV.
- Avoid using sharp tools or applying pressure on the screen.

2. Removing Packaging

- Carefully remove the protective covering and foam.
- Ensure the TV is placed on a flat surface.



Installation Instructions

1. Stand Assembly

- Attach the stand legs to the TV securely.
- Ensure the stand is stable and level.


2. Wall Mounting

- Use VESA mounting standards: 400 x 400 mm for smaller models, 600 x 400 mm for larger models.
- Secure with M8 screws, ensuring they are tightened properly.


3. Cable Connections

- Connect power, HDMI, LAN, and other necessary cables.
- Ensure all connections are secure and tidy.


3



4




4



5




6



- **What should I do if the TV screen is damaged during unpacking?**
Contact Samsung customer service for assistance.
- **Can I mount the TV on any wall?**
Ensure the wall can support the weight of the TV and use the recommended VESA mount.
Use M8 screws for wall mounting.
- **How do I ensure the stand is stable?**
Follow the stand assembly instructions carefully and check for stability before use

Documents / Resources

	SAMSUNG QA75Q7FAAXXZW QLED Smart Display [pdf] Installation Guide QA75Q7FAAXXZW, QA75QEF1AXXZW, QA85Q7FAAXXZW, QA75Q7FAAXXZW QLED Smart Display, QA75Q7FAAXXZW, QLED Smart Display, Smart Display, Display
--	---

References

- [User Manual](#)

■ Samsung
◆ Display, QA75Q7FAAXXZW, QA75Q7FAAXXZW QLED Smart Display, QA75QEF1AXXZW, QA85Q7FAAXXZW, QLED Smart Display, Samsung, Smart Display

—

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.