

SAMSUNG RFC88001 Bluetooth and Voice Control Replacement Remote Instruction Manual

Home » Samsung » SAMSUNG RFC88001 Bluetooth and Voice Control Replacement Remote Instruction

Manual

Contents

- 1 SAMSUNG RFC88001 Bluetooth and Voice Control Replacement Remote
- 2 STREAMING PROVIDER APPS HOTKEY PROGRAMMING
- **3 OVERVIEW**
- **4 PAIRING**
- **5 Documents / Resources**
 - **5.1 References**
- **6 Related Posts**



SAMSUNG RFC88001 Bluetooth and Voice Control Replacement Remote




Product Information

The Bluetooth & Voice Control Replacement Remote is a universal remote control that can be used to control various streaming provider apps. It has hotkeys for popular streaming services such as Netflix, Prime Video, Hulu, and more. The remote also features voice control, numeric and colour keys, multiview mode, cursor function, and program up/down function.

Product Usage Instructions


- 1. To enter App programming mode, press and hold the 1, 2, and 3 keys simultaneously for 6 seconds until the LED light turns on.
- 2. Use the cursor key to enter the 3-digit code for the streaming service you want to program.
- 3. Press OK to confirm the code.
- 4. If the programming is successful, the LED light will flash for 2 seconds and then turn off.
- 5. To use the voice control function, press the Voice Control key and speak your command.
- 6. To use the multiview mode, press the Multiview Mode key for a short press or the Frame Mode key for a long press (over 3 seconds).
- 7. Use the cursor function to navigate through menus and select options.
- 8. The Home key will take you back to the home screen of your device.
- 9. Use the Volume and Channel List keys to adjust the settings of your device.
- 10. Use the Program Up/Down keys to select different programs or channels.
- 11. To use the hotkeys for streaming services, simply press the corresponding key for the service you want to use.

STREAMING PROVIDER APPS HOTKEY PROGRAMMING



☆1 Key	☆2 Key	☆3 Key	CODE
Netflix	Prime Video	Hulu	101
Netflix	Prime Video	RokuTV	102
Netflix	Prime Video	WWW	103
Netflix	Prime Video	Samsung TV	104
Netflix	Prime Video	ZEES	110
Netflix	Prime Video	VIEON	111

OVERVIEW




- 1. Power
- 2. Mute
- 3. Voice Control
- 4. Numeric- & Colour Keys
- 5. Multiview mode (short press)
- 6. Frame mode (long press >3s) 6 Cursor
- 7. Back
- 8. Play/Pause
- 9. Home
- 10. Volume +/-
- 11. Channel List
- 12. Program Up/Down
- 13. Apps Hotkeys

Important notice!


If a bluetooth remote control is already paired with your TV, then please remove the batteries from that remote control and switch off the mains power to the TV for approximately 20 seconds. Switch the TV back on again and start the pairing process with your new Classic Bluetooth remote control RFC88001.

PAIRING


Step 1:



Step 2:



Scope of supply



EU Declartion of Conformity

By using the CE mark, CLASSIC Service Parts GmbH declares that the product complies with the requirements and guidelines of the European regulations.

Classic Service Parts GmbH Rodensteiner Str. 40 64385 Reichelsheim www.classic-serviceparts.com

UK Support:

TW Electronics (Newbury) Ltd. www.twelectronics.co.uk WEE-Reg.-№ DE91546912

Recycling guide

According to the European WEEE Directive, electrical equipment must not be disposed of in household waste. By law, you as the end user are required to return all waste electrical/electronic equipment and batteries either to the manufacturer, the point of sale or to a public recycling center.

Documents / Resources



SAMSUNG RFC88001 Bluetooth and Voice Control Replacement Remote [pdf] Instruction Manual

RFC88001 Bluetooth and Voice Control Replacement Remote, RFC88001, Bluetooth and Voice Control Replacement Remote, Voice Control Replacement Remote, Control Replacement Remote, Remote, Remote, Remote

References

- O Classic Service Parts GmbH
- Remote Control Manufacturers | TW Electronics | Newbury, UK

Manuals+,