

SANUS WSSE3A1 Adjustable Height Speaker Stand **Instruction Manual**

Home » SANUS wsse3A1 Adjustable Height Speaker Stand Instruction Manual

SANUS WSSE3A1 Adjustable Height Speaker Stand Instruction Manual



Before getting started, let's make sure this product is perfect for you!

This stand is designed to support only Sonos® Era 300™ speakers.



CAUTION: Avoid potential personal injuries and property damage!

- Check your speaker owner's manual to see if there are any special requirements for mounting your speaker.
- Please read through these instructions completely to be sure you're comfortable with this easy install process.
- Do not use this product for any purpose not explicitly specified by manufacturer.
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use.
- If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact Customer Service at US: +1 (800) 359-5520 EMEA: +31 (0) 495 580 852 UK: +44 (0) 800 056 2853.


Speaker Weight Limit

DO NOT EXCEED



Tool Needed

Screwdriver





Contents

- 1 Dimensions
- 2 Parts and Hardware
- 3 Install Rubber Pads -or- Carpet Spikes
- 4 Attach Bracket to Pillar
- 5 Install Speaker
- **6 Height Adjustment**
- 7 Secure Cable(s)
- 8 Documents / Resources
- 9 Related Posts


Dimensions

Top View






Front View



Side View



Parts and Hardware




WARNING: This product contains small items that could be a choking hazard if swallowed.

Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!


NOTE: Not all hardware included will be used.

Quantities shown are for one speaker stand.

STEP 2




STEP 3




Rubber Pad



OPTIONAL






Carpet Spike Jam Nut

x4



x4

STEPS 4 and 5



Bracket





Speaker Screw




STEP 6




Trigger




STEP 7



Route Cable(s)




Attach Base to Pillar




Install Rubber Pads -or- Carpet Spikes

Rubber Pads Twist rubber pads 05 into the base 02 .




Optional Carpet Spikes


WARNING: The ends of carpet spikes 06 are sharp and may scratch flooring, damage wiring, or be hazardous to children.




Attach Bracket to Pillar



Install Speaker



Height Adjustment




LOWER




CAUTION: Avoid potential personal injuries and property damage!


Hold upper post 01 BEFORE pressing trigger button 10 . Trigger button 10 is removable to prevent accidental lowering, or to route cables into post 01 (STEP 7).




HOLD




PRESS



LOWER



Secure Cable(s)



Thank you for choosing SANUS! Please take a moment to let us know how we did:

Legrand AV Inc.

6436 City West Parkway Eden Prairie, MN 55344 USA

US: +1 (800) 359-5520

Legrand AV Netherlands B.V.

Franklinstraat 14 6003 DK Weert Netherlands

UK: +44 (0) 800 056 2853 **EMEA**: +31 (0) 495 580 852

Authorized Representative for the UK

Starline Holding Technology Ltd. Unit C Island Road Reading RG2 0RP UK

Legrand AV Inc. and its affiliated corporations and subsidiaries (collectively, "Legrand"), intend to make this manual accurate and complete. However, Legrand AV makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

©2022 Legrand AV Inc. All rights reserved. SANUS is a brand of Legrand. SANUS and the SANUS logo are registered trademarks of Legrand.

Sonos and Sonos product names are trademarks or registered trademarks of Sonos, Inc. All other brand names or marks are used for identification purposes and are trademarks of their respective owners

Legrand AV Inc. • 6436 City West Parkway • Eden Prairie, MN 55344 USA



Documents / Resources



SANUS WSSE3A1 Adjustable Height Speaker Stand [pdf] Instruction Manual WSSE3A1 Adjustable Height Speaker Stand, WSSE3A1, Adjustable Height Speaker Stand, Height Speaker Stand, Stand

Manuals+,