

**SANUS**

**WSSE3A1  
Height  
Adjustable  
Speaker  
Stand**



## **SANUS WSSE3A1 Height Adjustable Speaker Stand Instruction Manual**

[Home](#) » [SANUS](#) » SANUS WSSE3A1 Height Adjustable Speaker Stand Instruction Manual 

### **Contents**

- [1 SANUS WSSE3A1 Height Adjustable Speaker Stand](#)
- [2 Product Usage Instructions](#)
- [3 Frequently Asked Questions](#)
- [4 IMPORTANT SAFETY INSTRUCTIONS](#)
- [5 Dimensions](#)
- [6 Parts and Hardware](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)

**SANUS**

**SANUS WSSE3A1 Height Adjustable Speaker Stand**



## Specifications

- **Model:** WSSE3A1 / WSSE3A2
- **Product:** Height-Adjustable Speaker Stand
- **Speaker Weight Limit:** 10 lbs. (4.5 kg)
- **Tool Needed:** Screwdriver

## Product Usage Instructions

### Parts and Hardware

Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, contact Customer Service.

### Assembly Steps

1. **Step 1:** Route Cable(s)
2. **Step 2:** Attach Base to Pillar
3. **Step 3:** Install Rubber Pads -or- Carpet Spikes
4. **Step 4:** Attach Bracket to Pillar
5. **Step 5:** Install Speaker
6. **Step 6:** Height Adjustment (Raise/Lower)
7. **Step 7:** Secure Cable(s)

### Rubber Pads vs. Carpet Spikes

Twist rubber pads into the base for standard use. Optional carpet spikes can be used for added stability, but be cautious as they may damage flooring or wiring.

### Height Adjustment

Hold the upper post before pressing the trigger button to raise or lower the stand. Ensure safe handling to avoid injuries or damages.

### Frequently Asked Questions

**Q: What is the weight limit for the speakers on this stand?**

**A:** The weight limit for speakers on this stand is 10 lbs. (4.5 kg).

**Q: What tool is required for assembly?**

**A:** A screwdriver is needed for assembly.

**Q: Can carpet spikes be used instead of rubber pads?**

**A:** Yes, optional carpet spikes can be used for added stability, but be cautious as they may damage flooring or wiring.

**Q: How do I adjust the height of the speaker stand?**

**A:** To adjust the height, hold the upper post and press the trigger button to raise or lower the stand.

### IMPORTANT SAFETY INSTRUCTIONS


PLEASE READ ENTIRE MANUAL PRIOR TO USE — SAVE THESE INSTRUCTIONS

Before getting started, let's make sure this product is perfect for you!


This stand is designed to support only Sonos® Era 300™ speakers.

**CAUTION:** Avoid potential personal injuries and property damage!

- Check your speaker owner's manual to see if there are any special requirements for mounting your speaker.
- Please read through these instructions completely to be sure you're comfortable with this easy install process.
- Do not use this product for any purpose not explicitly specified by manufacturer.
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use.
- If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact Customer Service at US: +1 [800-359-5520](tel:800-359-5520) • EMEA: +31 (0) 495 580 852 • UK: +44 (0) 800 056 2853.

<p><b>Speaker Weight Limit</b></p> <p><b>DO NOT EXCEED</b></p>		<p><b>Tool Needed</b></p>  <p>Screwdriver</p>
--	---	--

### Dimensions




## Parts and Hardware

**WARNING:** This product contains small items that could be a choking hazard if swallowed.

Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!


**NOTE:** Not all hardware included will be used.

The quantities shown are for one speaker stand.




## STEP 1

Route Cable(s)



**STEP 2**  
Attach Base to Pillar




### STEP 3

Install Rubber Pads -or- Carpet Spikes


#### Rubber Pads

Twist rubber pads **05** into the base **02**.




OR


#### Optional Carpet Spikes




**⚠ WARNING:** The ends of carpet spikes **06** are sharp and may scratch flooring, damage wiring, or be hazardous to children.



### Attach Bracket to Pillar









**↓ LOWER**

**⚠ CAUTION:** Avoid potential personal injuries and property damage!


Hold upper post **01** BEFORE pressing trigger button **10**.

Trigger button **10** is removable to prevent accidental lowering, or to route cables into post **01** (STEP 7).



## STEP 7

Secure Cable(s)



Thank you for choosing SANUS! Please take a moment to let us know how we did:

Legrand AV Inc.  
6436 City West Parkway  
Eden Prairie, MN 55344 USA  
US: +1 [800-359-5520](tel:800-359-5520)



Legrand AV Netherlands B.V.  
Franklinstraat 14 6003 DK Weert Netherlands  
UK: +44 (0) 800 056 2853  
EMEA: +31 (0) 495 580 852

Authorized Representative for the UK  
Starline Holding Technology Ltd.  
Unit C Island Road  
Reading RG2 0RP UK


Legrand AV Inc. and its affiliated corporations and subsidiaries (collectively, “Legrand”), intend to make this manual accurate and complete. However, Legrand AV makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

©2022 Legrand AV Inc. All rights reserved. SANUS is a brand of Legrand. SANUS and the SANUS logo are registered trademarks of Legrand.  
Sonos and Sonos product names are trademarks or registered trademarks of Sonos, Inc. All other brand names or marks are used for identification purposes and are trademarks of their respective owners.

Legrand AV Inc. • 6436 City West Parkway • Eden Prairie, MN 55344 USA

We'll Make It Stress-Free  
If you have any questions along the way, just give us a call.  
US: +1 [800-359-5520](tel:800-359-5520) • EMEA: +31 (0) 495 580 852 • UK: +44 (0) 800 056 2853 We're ready to help!

## Documents / Resources

	<a href="#">SANUS WSSE3A1 Height Adjustable Speaker Stand</a> [pdf] Instruction Manual WSSE3A1, WSSE3A2, WSSE3A1 Height Adjustable Speaker Stand, WSSE3A1, Height Adjustable Speaker Stand, Adjustable Speaker Stand, Speaker Stand, Stand
---	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.