



saphe One+ Speed Camera Alarm User Manual

[Home](#) » [saphe](#) » **saphe One+ Speed Camera Alarm User Manual** 

saphe One+ Speed Camera Alarm




Contents

- 1 GETTING STARTED
- 2 REPORTING ALARMS
- 3 CHECK CONNECTION
- 4 TURN OFF
- 5 DISCONNECTED
- 6 INSTALLATION
- 7 CHECKLIST
- 8 SUPPORT
- 9 Documents / Resources
 - 9.1 References
- 10 Related Posts



GETTING STARTED

Download the Saphe Link app.




This product requires Club Saphe membership. Sign up at www.club.saphe.com or in the Saphe Link app.


Turn on by pressing the red button for 2 seconds and the LED will flash green.





Pair your device in the Saphe Link app and not from the phones Bluetooth settings. Go to: 'Menu' > 'Devices' > 'Unknown device' and select your 'Saphe One+'.









Saphe One+ will beep twice and display a flashing green LED if connected correctly.




Accident, Danger on the road and Car on shoulder are displayed by a red light and Speed cameras by a blue light. More information about the alarms can be found in the app.




	Mobile speed camera
	Fixed speed camera
	Average speed camera
	Traffic light camera
	Danger
	Car on shoulder

REPORTING ALARMS

Press the blue button to report Mobile speed camera and the red button to report Danger on the road. Hold and press the red button for two seconds to report Car on shoulder. The actions tied to the red button may be different depending on country of purchase.




When reporting or confirming an alarm, press the button when you are at a Mobile speed camera or Accident and not immediately upon seeing it.



CHECK CONNECTION

Press and hold the blue button for two seconds to check connection. If connected correctly the LED will display a flashing green light.





TURN OFF

To turn off the Saphe One+ press and hold the red button for 5 seconds.




5 seconds

Turned off




DISCONNECTED


If Saphe One+ fails to connect within 30 seconds after starting your trip, it will give an alarm with a red and yellow light.




INSTALLATION



On the dashboard.





“Do not ingest battery, Chemical Burn Hazard.”

This product contains a coin cell battery. If the battery is swallowed it can cause severe internal burns in just 2 hours and can lead to death.

Always keep new and used batteries away from children.

If the product cannot be closed securely and thereby leaving the battery accessible, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

CHECKLIST

To ensure the best experience with the Saphe One+, you can use following steps as a checklist.

- Always bring your smartphone.
- Saphe One+ and your smartphone are connected correctly through the Saphe Link app.
- Bluetooth is enabled on your smartphone.
- Location settings for Saphe Link app is set to 'Always turned on'.
- Your smartphone is recently updated.

- Placing your smartphone in a purse or in your pocket could block the GPS signal.

SUPPORT

If you need help try our support website: support.saphe.dk

www.saphe.com



Documents / Resources



[saphe One+ Speed Camera Alarm](#) [pdf] User Manual
One Speed Camera Alarm, One, Speed Camera Alarm

References

- [Support : Support](#)
- [S Saphe Traffic Alarms](#)