




sauermann TRACKLOG Lora-Powered Temperature Thermocouple Data Logger User Guide

[Home](#) » [sauermann](#) » sauermann TRACKLOG Lora-Powered Temperature Thermocouple Data Logger User Guide 



Contents


- 1 TRACKLOG
 - 1.1 Quick start guide
- 2 Documents / Resources
- 3 Related Posts

TRACKLOG

Quick Start Guide

www.sauermanngroup.com

1



Gateway



2




Gateway

3



Gateway

4



tracklog.inair.cloud

Quick start guide

1. Connect the gateway to the mains and connect the Ethernet jack
2. The LED flashes when it is connected to the electricity grid
3. The fixed LED indicates that the Gateway is connected to the LoRa® network
4. Log in to tracklog.inair.cloud to configure your TrackLog data loggers

Hereby, Sauermann Industrie SAS declares that the radio equipment type TrackLog is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.sauermanngroup.com



Download the full manual



Read the FAQs




Customer service portal

Use our Customer service portal to contact us

<https://sauermann-en.custhelp.com/>

www.sauermanngroup.com



22/02/2021 – We reserve the right to modify the characteristics of our products without prior notice.



Documents / Resources

	sauermann TRACKLOG Lora-Powered Temperature Thermocouple Data Logger [pdf] User Guide TRACKLOG, Lora-Powered Temperature Thermocouple Data Logger, TRACKLOG Lora-Powered Temperature Thermocouple Data Logger, A5-02-2021, NTsimp-Tracklog
---	--

Manuals+,