



SBOL X5 Plus Wireless Controller Instruction Manual

[Home](#) » [SBOL](#) » SBOL X5 Plus Wireless Controller Instruction Manual 

Wireless Controller — XS/Dios —

Contents

- 1 [Product Instruction](#)
- 2 [Android Direct Play Mode](#)
- 3 [Mapping for direct play mode](#)
- 4 [Instruction for key function](#)
- 5 [Electrical Parameters](#)
- 6 [Android Standard HID Mode](#)
- 7 [Downloading the game center](#)
- 8 [Power on/off](#)
- 9 [Charging Controller](#)
- 10 [PC/PS3 Mode\(need 2.4 receiver\)](#)
- 11 [Android Devices](#)
- 12 [PC Devices](#)
- 13 [iOS Direct play Mode](#)
- 14 [Turbo Function](#)
- 15 [Precautions](#)
- 16 [Accessories List](#)
- 17 [Documents / Resources](#)
- 18 [Related Posts](#)

Product Instruction


1. X5Plus new upgraded gamepad.with Bluetooth +2.4G wireless transmission function.Easy to operate No activation.No APP is needed.
2. It can be operated in 6-8 metes area.
3. Bluetooth supports android 6.0 and JOS 11 0 above system.
4. 2.4G Wireless support Win/7/8/10.Android/PS3 Console
5. Applicable devices: Smartphones/Tablets/PC1PS3 Console.

6. With a built-in 400mA lithium battery.
7. Design with telescopic phone holder(up to 90mm)





Attaching a smartphone


Fix the bracket to the gamepad. then fasten the smartphone onto the bracket.

1. Open the bracket.
2. Pull the rod. and fix the Smartphone on the bracket.



Android Direct Play Mode

1. First, turn the power of the controller off, then press the  and  button for 3 seconds, led  will flash quickly
2. Set Bluetooth in the phone, turn on Bluetooth and search device.
3. The phone will search "kingpin-X5Plus" out and click pair, led  will light.
4. Due to mobile system issues, some mobiles may not support this mode(e.g.:mobile under Win platform do not support)




Mapping for direct play mode

If need to modify the gamepad buttons by yourself, please search to download "ShootingPlus V3" APP from APP

Store or Googplay, sel up the mapping from'ShootingPlus V3", you can get the detailed operation on app help

Instruction for key function


Please make sure the compatibility of your device before connecting it to the gamepad.




Electrical Parameters

Item	Specification
Product size	16*11*5.6CM
Net weight	165g
Wireless distance	0 8M
Support OS	Android/iOS/PS3/Windows
Battery	400mA
Work time	20- 30h
Charge time	5V<300mA
Connecting current	10mA
Work current	8mA
Sleep current	10uA

Android Standard HID Mode

1. First, turn the power of the controller off, then press "X- and  button for 3 seconds, led will flash quickly.
2. Set Bluetooth in the phone, tum on Bluetooth, and search device.
3. The phone will search 'kingpin-X5Plus" out and click pair, led light.
4. Support to the mobile system under the MTK platform.




Downloading the game center


1. Search Octopus APP on Google Play Store or scanning QR code to download Game Center.
2. Add a game from your local applications. Launch a game you added from Octopus Click the floating ball of Octopus to set the gamepad keys. Switch gamepad mode to play games.
3. Support android smartphone, smart TV, TVI30X, tablet.



<http://www.phoenixos.com/octopus/intro?ref=gamtec>


Power on/off

Power on: A long press of 2 seconds on the  (HOME) button will turn on the device
 Power off: A long press for 5 seconds will turn off the device






Charging Controller

1. Controller charged by usb cable. The charging current is 5V<300mA, Charging time is about 3 hours.
2. After the controller is connected, the led on the gamepad flash which means power is low please charge to the controller,
3. The controller on charging, the LED flash slowly, after charging the LED on.
4. The controller stays a long time, the battery life will be reduced_ Notes If already paired, but can't connect, please cancel the pair and boot the device and connect again.



PC/PS3 Mode(need 2.4 receiver)

1. First, turn the power of the controller off, then press  and  buttons for 3 seconds, led CD will flash quickly.
2. Plug USB receiver into the device, the device connecting success.
3. Supports Windows/Android/PS3 mode. The gamepad will identify the connected OS and switch automatically.



Android Devices

Supports Android devices without Bluetooth, plug the usb receiver into the usb port. Then the controller will be working.





PC Devices


2.4G connection supports PC Xbox360 (X-input) mode(default) in windows 7/8/10, 3 seconds press on the back+start buttons at the same time will switch to the normal PC (D-input) mode.

PS3 Device

1. Connect the controller to PS3 console by 2.4G RF.
2. After the controller is paired, plug the usb receiver into the PS3 usb port. Then the controller will be working.
3. Enjoy PS3 games with the X5Plus gamepad.

iOS Direct play Mode

1. First, turn the power of controller off, then Press  and  button for 3 seconds, led  will flash quickly
2. Set nineteen) in the phone, turn on Bluetooth and search the device
3. The phone will search "mingpin-X5Plus" out and click part, LED  will light.
4. If need reset the mapped buttons, Alonso download APPSearch "Shooting Plus" on APP store, download and install the APP
5. Support iOS system 11.0 or above




Turbo Function

1. Six action buttons(XNIAJB/1.11R1)can use TURBOci Key'Ounction
2. The action button can be set manually with the TURBO function.
3. Setting method-. Press the action button for a long time, and then press the TURBO key to turn it on Press the action key for a long time, and then press the TURBO key again to turn off
4. After the gamepad is turned off, power off, slept or restart the gamepad The previous TURBO setting will not be stored.If you want to enable the Turbo function buttons again, then please reset the TURBO function.


Precautions

1. Please don't store this product in a damp or high-temperature place.
2. Do not knock, beat, pierce, or try to disintegrate this product so as not to damage it unnecessarily.
3. Don't discard it with garbage as this product is with a lithium battery built-in;
4. Don't use this product near fire or heat sources;
5. If unauthorized and non-professional personnel dissembled this product and caused damage, this product is not within the scope of an after-sales warranty.

Accessories List



Documents / Resources



[SBOL X5 Plus Wireless Controller](#) [pdf] Instruction Manual
9200000123455592, X5 Plus Wireless Controller

[Manuals+](#).