

# SBOX EB-TWS32 Bluetooth Earbuds User Manual

Home » SBOX » SBOX EB-TWS32 Bluetooth Earbuds User Manual



## **Contents**

- 1 SBOX EB-TWS32 Bluetooth
- **Earbuds**
- **2 OVERVIEW**
- **3 Product parameter information**
- **4 Operating instructions**
- **5 Safety instructions**
- 6 Serious warning
- 7 Packing includes
- 8 Documents / Resources
- 9 Related Posts



# **SBOX EB-TWS32 Bluetooth Earbuds**



#### **OVERVIEW**



• Matching mode: automatic matching

• Power-on prompt: power-on.

• Power off prompt: power off.

• Pairing status: bluetooth connected

· Connection status: bluetooth is connected

• Low power hint: low power.

## **Key functions:**

- Power on: long press (3 seconds) to power on
- Power off: long press (3 seconds) to power off
- Pause/play: click any action key to pause/play the music
- Answer/hang up the phone:/ click any action key on the incoming call to answer/hang up the phone
- Previous song: three clicks on the left ear piece
- Next song: three clicks on the right ear piece

## Increase/ decrease volume:

Double click the right ear function key to increase the volume and double-click the left ear function key to decrease the volume. Voice assistant: long press 2 seconds

Language switch: double click on the matching red and blue lights Unconnected standby: automatically shuts down after 10 minutes.

## **Product parameter information**

• Bluetooth version: V5. 1

• Listening time: 3 hours (single use with full battery) Standby time: 160 hours (if in the charger) Charging time:

40 minutes

• Operating current: 12 mA

• Standby current: 4 uA

• Bluetooth level: level 2

• Frequency band/band: 2.4 - 2.485 GHz

• Support protocol: AZDP/AVRCP/HSP/HFP Modulation process: GFsK

• Maximum transmitted power: +2 dBm

## Move the charging bin parameters

1. Input current 5V 1A

2. Output current 5V / 500 mA

3. Charging time of charging warehouse: about 1 h

4. Operating temperature: -10'C to 55°C

## **Operating instructions**

#### Special note:

if you use the earbuds for the first time or use it again after 1 hour, you need to take the earbuds out of the charger and put it back. The charger automatically connects both earbuds as you take them out of the carger. IF you can't connect the left and right earbud, please follow the instructions.

#### • Instructions:

Turn on both earbuds at the same time. Red and blue lights will alternate and flicker for about 5 seconds. Turn the Bluetooth on your device, and earbuds will automatically connect with LED lights turning off.

#### Steps for single earbud use:

Take one earbud out of the charger and turn it on while having Bluetooth on your phone turned on.

Call voice assistant: after the earbuds are connected with the device, press and hold for 2 seconds to call your voice assistant (SIRI).

## • Using the primary and secondary earbud:

after the earbuds are connected, they can be used independently of one another. If one earbud runs out of battery, the other one can be used without any issues.

#### Bluetooth reconnect operation:

Connecting the earbuds to the same device. If you previously connected the earbuds to the device and didn't delete it from the Bluetooth list, they will automatically connect to the same device without the process of connecting like the first time. Also, if you take the earbuds out of the charger, they will automatically connect to the familiar device.

#### · Charging the earbuds

- Put the earbuds into the charger. LED will turn red. The status of the battery will be represented with 4
   blue LED lights on earbuds. When it's fully charged, LED will turn off.
- When there's one or no LED light on the charger, that means the charger has to be charged. Charging takes around 1 hour with 4 LED lights showing the status of charging.

#### Notes:

- Please do not drop, hit, scratch, twist, crush or throw the earbuds into the water.
- When using the earbuds, keep it away from magnets, house appliances and speakers.
- Try to avoid placing the Bluetooth earbuds in the environment of extreme temperatures (use the ambient operating temperature range of -10 °C-45 °c
- · Avoid environment with high moisture.

- If you don't use the earbuds for a longer period of time, please charge it every other week to extend the life of the product.
- Keep the product away from any fire source.
- Don't put the product close to inflammable and explosive contents;

# Safety instructions

please use the standard DC charger (DC 5V/500mA - 2A) for charging the earbuds charger. Don't remove the charging bay and earbuds or insert other items into the product to avoid damage or injury to yourself.

## **Serious warning**

Do not use this product while charging. Please use the adapter from the manufacturer to charge product. Do not disassemble the lithium battery and place it in the fire. Do not allow metal objects to touch or short circuit the electrode. Do not knock or squeeze the battery.

Avoid placing it in the environment of moisture, corrosion or extreme temperatures (>60°C).

## **Packing includes**

- Bluetooth earbuds x2
- Charger x1
- · Charging cable x1
- Instructions manual x1

# **Documents / Resources**



SBOX EB-TWS32 Bluetooth Earbuds [pdf] User Manual EB-TWS32 Bluetooth Earbuds, EB-TWS32, Bluetooth Earbuds, Earbuds

Manuals+,