



## SCANCOOL Scandomestic User Guide

[Home](#) » [SCANCOOL](#) » SCANCOOL Scandomestic User Guide 

### Contents

- [1 SCANCOOL Scandomestic](#)
- [2 Caution and Attention](#)
- [3 How to use](#)
- [4 How to change door](#)
- [5 Ventilation requirement](#)
- [6 Trouble shooting](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

# SCANCOOL

**SCANCOOL Scandomestic**



## Caution and Attention

- Please read the user manual carefully before using it.
- Electrical wire is easy to be damaged by cutting, extending or healing.
- Fire and creepage will be happened if using damaged electrical wire.
- If electrical wire is damaged, please change to appropriate one or change it from factory.
- Avoiding catching fire, please don't lengthen electrical wire or using it with other appliances.
- Avoiding creepage, please don't touch plug and power switch by wet hand.
- Please use standard and qualified electrical outlet.
- Please don't maintain, repair and disassemble it by yourself.
- Please unplug electrical plug if dangerous things happen.
- Please unplug electrical plug if not using it for long time.
- Please don't store food, fruit and beverage for long time if opening it, otherwise it is easy to make bad and germ, also please don't eat them.
- Because insulation material is flammable, please keep it away from fire

## How to use

- Please put it on horizontal place and make ventilation well according to our ventilation requirement.
- Please connect with electrical outlet and check whether the lamp is light, if light, it means working.
- Close the door and let it run for 2 hours, then put food, fruit or beverage into it.
- Model 32 B and MB 34 B: Our setting inside temperature is around 8°C based on 25°C ambient temperature.
- Model MB 32 BGD and MB 34 BGD: Our setting inside temperature is around 12°C based on 25°C ambient temperature.

- If need clean it, please take off plug firstly.
- Please use soft or cotton cloth to clean it.
- If need move it, please take out plug and all of food, fruit, or beverage firstly.

## **How to change door**

### **Model MB 32 B**

- Take out top hinge after loosening the 3 screw on top hinge. Take outdoor.
- Take out bottom hinge.
- Take out screw cover.
- Install bottom hinge.
- Install door and install top hinge.
- Install screw cover to another side.

### **Model MB 34 B**

- Remove both left and right hinge cover.
- Release screws of bottom hinge. Take out bottom hinge.
- Remove door in bottom direction and place somewhere on the floor.
- Remove upper hinge.
- Mount the left upper hinge at left minibar side.
- Move in the door from bottom entrance and mount it on the left upper hinge.
- Install bottom hinge bolt at left side of the door.
- Screw in bottom hinge inside mini-bar
- Install both left and right hinge cover.

### **Model MB 32 BGD and MB 34 BGD**

- Take out the bottom hinge.
- Take out hinge cover.
- Take outdoor.
- Take out the top hinge after loosening the three screws
- Take out hinge hole covers.
- Install door and top hinge.
- Install bottom hinge.
- install hinge covers.

## **Ventilation requirement**

### **MB 32 B:**

There must be more than 3 cm of air on both sides, and at the top and depth.

### **MB 34 B:**

There must be more than 3 cm of air on both sides, and more than 5 cm in top and depth.

### **MB 32 BGD and MB 34 BGD:**

There must be more than 5 cm of air on both sides and in top and depth.


## **Trouble shooting**

### **Does not work:**

- Is the power off?
- Is there a connection to the socket?
- Is there light in the lamp?
- Is the ambient temperature very high?

### **The internal temperature is not good enough**

- Is the door closed properly?
- Does it comply with the ventilation requirements?
- Is the ambient temperature very high?



Access to professional repair, such as internet webpages, addresses, contact details. Model no: MB 32 B

### **Aftersales service station list:**

Address	Scandomestic A/S
Contact Number	7242 5571
Website	Scandomestic.dk
QR code	543905
Relevant information for ordering spare parts, directly or through other channels provided by the manufacturer, importer or authorised representative;	Scandomestic A/S
The minimum period during which spare parts, necessary for the repair of the appliance, are available;	7 years
Instruction on how to find the model information in the product database, as defined in Regulation (EU) 2019/2019 by means of a weblink that links to the model information as stored in the product database or a link to the product database and information on how to find the model identifier on the product.)	<a href="http://www.scandomestic.dk">www.scandomestic.dk</a>

**Note:** The address or contact phone number of the service site is subject to change without prior notice. Please confirm whether the service station is a directly affiliated one of our company when requiring services.

Access to professional repair, such as internet webpages, addresses, contact details. Model no: MB 32 BGD

**Aftersales service station list:**

Address	Scandomestic A/S
Contact Number	7242 5571
Website	Scandomestic.dk
QR code	543918
Relevant information for ordering spare parts, directly or through other channels provided by the manufacturer, importer or authorised representative;	Scandomestic A/S
The minimum period during which spare parts, necessary for the repair of the appliance, are available;	7 years
Instruction on how to find the model information in the product database, as defined in Regulation (EU) 2019/2019 by means of a weblink that links to the model information as stored in the product database or a link to the product database and information on how to find the model identifier on the product.)	<a href="http://www.scandomestic.dk">www.scandomestic.dk</a>

**Note:** The address or contact phone number of the service site is subject to change without prior notice. Please confirm whether the service station is a directly affiliated one of our company when requiring services.

Access to professional repair, such as internet webpages, addresses, contact details. Model no: MB 34 B

**Aftersales service station list:**

Address	Scandomestic A/S
Contact Number	7242 5571
Website	Scandomestic.dk
QR code	543928
Relevant information for ordering spare parts, directly or through other channels provided by the manufacturer, importer or authorized representative;	Scandomestic A/S
The minimum period during which spare parts, necessary for the repair of the appliance, are available;	7 years
Instruction on how to find the model information in the product database, as defined in Regulation (EU) 2019/2019 by means of a weblink that links to the model information as stored in the product database or a link to the product database and information on how to find the model identifier on the product.)	<a href="http://www.scandomestic.dk">www.scandomestic.dk</a>

**Note:** The address or contact phone number of the service site is subject to change without prior notice. Please confirm whether the service station is a directly affiliated one of our company when requiring services.

Access to professional repair, such as internet webpages, addresses, contact details. Model no: MB 34 BGD

#### **Aftersales service station list:**

Address	Scandomestic A/S
Contact Number	7242 5571
Website	Scandomestic.dk
QR code	1037160
Relevant information for ordering spare parts, directly or through other channels provided by the manufacturer, importer or authorised representative;	Scandomestic A/S
The minimum period during which spare parts, necessary for the repair of the appliance, are available;	7 years
Instruction on how to find the model information in the product database, as defined in Regulation (EU) 2019/2019 by means of a weblink that links to the model information as stored in the product database or a link to the product database and information on how to find the model identifier on the product.)	<a href="http://www.scandomestic.dk">www.scandomestic.dk</a>

#### **Note:**

The address or contact phone number of the service site is subject to change without prior notice. Please confirm whether the service station is a directly affiliated one of our company when requiring services.

## **Documents / Resources**

MB 32 B  
MB 32 BGD  
MB 34 B  
MB 34 BGD

Brugermanual  
User manual  
Bedienungsanleitung  
Användarmanual

SCANCOOL  
Industri A/S · Industrivej 10 · DK-2600 Lyngby

## SCANCOOL Scandomestic [pdf] User Guide

MB 32 B, MB 32 BGD, MB 34 B, MB 34 BGD, Scandomestic

## References

- ⓘ [Scandomestic | Scandomestic.dk](#)
- ⓘ [Scandomestic | scandomestic.dk](#)

Manuals+.