SCANGRIP 03.5426 Zone Rechargeable Headlamp Instruction Manual

Contents hide

SCANGRIP 03.5426 Zone Rechargeable Headlamp Instruction Manual

PATENT PROTECTED

* go to scangrip.com to register

WARNING / CHARGING INSTRUCTION / BATTERY TIPS

- Avoid looking directly into the beam of light, as this will result in dazzling
- Do not use the lamp near a naked flame
- Before using the lamp for the first time, the battery must be fully charged
- The red charging indicator lights up during charging
- The green charging indicator lights up when charging is completed
- Recharge frequently
- Always replace the battery with an original SCANGRIP battery
- Do not leave the battery without charge for an extended period
- Deep discharge risks damaging the battery
- The light source of this lamp is not replaceable; when the light source reaches its end of life the whole lamp shall be replaced
- Only charge the lamp indoors at min 0 °C

Discarded electrical products must not be disposed of together with household waste.
Please use recycling facilities. Ask your local authority or retailer for advice on recycling.

- The battery must be removed from the device before it is broken up
- The device must be disconnected from the mains when the battery is removed
- Please dispose of the battery safely

Read More About This Manual & Download PDF:

Documents / Resources

SCANGRIP 03.5426 Zone Rechargeable Headlamp [pdf] Instruction Manual
03.5426, Zone Rechargeable Headlamp

References

- ❮ **Europe's leading manufacturer of LED work lights**
- ❮ **Europe's leading manufacturer of LED work lights**

Manuals+,

- **home**
- **privacy**