



Home » SCANGRIP » SCANGRIP MINIFORM LED Work Light Instruction Manual 📆



Contents [hide]

- 1 SCANGRIP MINIFORM LED Work Light
- 2 Specifications
- **3 CHARGING INSTRUCTIONS AND BATTERY TIPS**
- 4 USE
- **5 SPARE PARTS**
- **6 MANUFACTURER'S WARRANTY**
- 7 5 warranty years
- 8 Documents / Resources
 - 8.1 References



SCANGRIP MINIFORM LED Work Light



Specifications

Model: MINIFORM 03.6207

Warranty: 5 years

• LED: 20-200 lumen, 3 levels

• OptiLight: 27 hours / 3 hours, Spot: 120 lumen, OptiLight: 7 hours

• Battery: 3.7 V / 1010 mAh Li-ion

• IP Rating: IP65

• Impact Protection: IK07

Dimensions: 126 x 60 x 23.5 mm / 4.96 x 2.36 x 9.25 in

• Weight: 106 g / 0.23 lbs

• Additional: Includes USB cable, Excludes charger

WARNING

- Avoid looking directly into the beam of light, as this will result in dazzling.
- Do not use the lamp near a naked flame.
- The light source of this lamp is not replaceable. When the light source reaches the


end of its life, the whole lamp must be replaced.

CHARGING INSTRUCTIONS AND BATTERY TIPS

- Only charge the lamp indoors at 5 °C to 40 °C / 41 to 104 °F.
- Before using the lamp for the first time, the battery must be fully charged.
- The red charging indicators light up with the highest flashing during charging.
- The highest charging indicator will not be flashing if the temperature does not allow charging.
- The red charging indicators will all be constantly on when fully charged.
- Always replace the battery with an original battery.
- Do not leave the battery without charge for an extended period.
- Deep discharge risks damaging the battery.

USE

• To turn the lamp on or off, press the power button (A).



- Press and hold the power button (A) to turn on the spotlight.
- Press the brightness button (B) to turn on the lamp in OPTILight mode.
- The OPTILight indicator will turn on.
- To increase or decrease the brightness, press the brightness button (B).

- When the brightness is changed, the new value is saved, and the lamp will start at that level the nexttime it is turned on.
- When the battery is below 10 %, the lamp will flash 3 times every 2 minutes.
- If the lamp temperature is too high or too low, the lamp will turn off and flash all battery indicators 10 times.



SPARE PARTS

- With convenient access to spare parts, users can extend the lifespan of our products and ensure long-lasting functionality.
- Find available spare parts on <u>scangrip.com</u>
- Discarded electrical products must not be disposed of together with household waste. Please use the recycling facilities.
- Ask your local authority or retailer for advice on recycling.
- The battery must be removed from the device before it is broken up.
- The device must be disconnected from the mains when the battery is removed.
- Please dispose of the battery safely.

MANUFACTURER'S WARRANTY


Information for customers in Australia and New Zealand only

This SCANGRIP product is guaranteed for 2 (two) years from the date of purchase. This guarantee shall become invalid if the product has been misused, tampered with or accidentally damaged. If the product is defective, we undertake to repair or replace the product or any part of it that is defective, or wholly or partly recompense you if they are defective.

This guarantee is in addition to other rights and remedies available to consumers, all of which are given by us to you if you are a consumer. Our goods come with guarantees that cannot be excluded under the Australian or New Zealand Consumer Law. You are entitled to a replacement or refund for a major failure, compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods

repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If you wish to make a claim, please return this product to the original place of purchase together with your purchase receipt or go to our website www.scangrip.com and fill out the claim form.

5 warranty years



Read the terms and register on scangrip.com to activate your warranty



CANGRIP.COM

DESIGNED BY SCANGRIP



IN DENMARK

Documents / Resources



SCANGRIP MINIFORM LED Work Light [pdf] Instruction Manual 03.6207, 11341470A, MINIFORM LED Work Light, MINIFORM, LED Work Light, Work Light

References

- <u>Europe's leading manufacturer of LED work lights</u>
- User Manual
 - 03.6207, 11341470A, LED Work Light, MINIFORM, MINIFORM LED Work Light, SCANGRIP, Work
- SCANGRIP Light
 - —Previous Post

SCANGRIP 03.6208 Uniform LED Work Light Instructions
Next Post—

SCANGRIP MINI SLIM LED Work Light Installation Guide

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *		

Name

Email
Website
Save my name, email, and website in this browser for the next time I comment.
Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.