



Home » scanovus » scanovus BBK 199 Automatic Ironing Machine Instruction Manual 📆



Contents [hide]

- 1 scanovus BBK 199 Automatic Ironing Machine
- 2 Intended Use
- 3 Product Specification
- 4 Product Feature
- 5 Product Overview
- 6 Product Components
- 7 Assembly
- 8 How to use
- 9 Troubleshooting
- 10 FAQ
- 11 Documents / Resources
 - 11.1 References

scanovus

scanovus BBK 199 Automatic Ironing Machine



Intended Use

- 1. This device is intended to be used to dry and press textiles, for example, blouses and shirts. Delicate textiles such as wool or similar fabrics must not be pressed on the presser. Always follow the care labels for the textiles before use.
- 2. The device is for personal use only and is not intended for commercial applications.
- 3. The device should only be used as described in these instructions. Any other use is deemed to be improper.

Important Safeguard

- 1. Please always keep away from water and fire; place the device on a hard and flat floor and good air well-ventilated area.
- 2. The device can use a soft cloth to wipe the surface only. Never immerse the device, the mains cable, or the mains plug in water or other liquids.
- 3. Please hang on the clothes after dehydration; NEVER drip water.
- 4. This device is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or a lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety.
- 5. Children are supervised not to play with the device.
- 6. Never cover the wind inlet and outlet.
- 7. If the supply cord is damaged, please return to the authorized service center for repair.

 Do not attempt to disassemble or repair yourself.
- 8. The device must always be switched off and disconnected from the mains power when it is not being used and before assembling, disassembling or cleaning the device.
- 9. Allow the device to cool down completely before it is cleaned and stored away.
- 10. Suitable for textiles such as pants and shirts, delicate textiles such as wool or similar fabrics must not be pressed on the device.
- 11. CAUTION: Hot surfaces! The motor unit/telescopic rod will become hot during use. You should therefore not touch it during or shortly after use.

Product Specification

• Rated Voltage: 220-240V~

• Rated Frequency: 50/60Hz

• Rated Power: 1250W


• Timer: 0-60 minutes or on

• Protection class: II

Product Feature

- Safety ceramic heating element.
- Super strong wind and low noise fan.
- Novelty and elegant structure design, with clips to presser and a hidden type power cord.
- Hot air tension technology heats and smooth your garments
- High temperature is used to dry the garments in a short time.

Product Overview




Product Components

Serial No.	Part name	Quantity
------------	-----------	----------

A	Motor unit 1set	
В	Lower rod	2pcs
С	Telescopic rod 2pcs	
D	Hanger 1set	
E	Clips 4pcs	
F	Magnetic clamps 4pcs	
G	Shoes rack 1pc	
Н	Shirts balloon 1pc	
I	Pants balloon 1pc	


Assembly

• Pull the main plug out of the back of the motor unit.




SHIRTS

- Connect the lower rods (B) with the telescopic rods (C). Insert the two telescopic rods with the lower rods into the corresponding holes of the motor unit (A), and set the height you want.
- To do this, open the screw, pull out the telescopic rod and then close the screw again.
- Place the hanger (D) (with 4 clips (E), if you want to dry socks or underwear while the machine is on) onto the top of the telescopic rods (C).




- Put on the shirt's bag (H) and pull the elastic cord at the bottom of the airbag over the mounting flange (A). Hang the garments over the shirt's bag from the back and turn on the motor. After the body is inflated, make sure the shirt hangs tight around the body. Put the magnetic clamps (F) on the bottom of the garments, and stretch the garment to make it smoother.
- Size setting: Open or close the zipper of the shirt airbag (H) to fit a variety of different shirt sizes. There are 2 in each side.




PANTS

Take off the hanger (D) and extend the telescopic rods (C). Put on the pants balloon
 (I) and pull the elastic cord at the bottom of the airbag over the mounting flange (A).
 Hang the pants over the body and turn on the motor.



SHOES

• Insert the shoes rack (G) on the top of the motor unit (A). Hang the shoes over the rack and turn on the motor unit.




Disassembly

• To disassemble this machine, follow the assembly steps in reverse.

How to use

- 1. Insert the power plug into the power socket, and enter the standby state after powering on.
- 2. Select the ON/OFF button to start the machine.
- 3. Select the TEMP SETTING to the one you require at the position of COOL, 50°C, 60°C, or 70°C; and select TIME+/ TIME- to the one you require, Then the machine

starts to work.



Tips

• Please make the Shirts/Pants form-fitting and smooth on the air bag.

Attention

- 1. Wet clothes, shoes, and other items should be wrung or dried so that they are not soaked.
- 2. Please ensure that the clothes and shoes to be ironed and dried can withstand the temperature you set.

Troubleshooting

No.	Problem	Possible cause/solution
1	The device does not work. The LE Ds do not light up	Is the mains plug inserted in the plug socket correctly? Correct the fit of the mains plug. Is the plug socket defective? Try another plug socket. Check the fuse of the mains connection. Is the device switched on? Set the timer to a time.
2	Unusual noises	Are the wind outlet covered up or blocked? Free up the outlet vent.

3	The device switc hes off suddenly.	Are the wind outlet covered up or blocked? Free up the outlet vent. The device has an automatic safety switch-off function. It switches off automatically if it overheats. Allow the device to cool down and switch it on again.
4	Odors produced	You may notice a slight odor from production residues d uring the first use. Rest assured, this is harmless and will disappear with continued use.

SIZE ADJUSTMENT

Adjust the telescopic rods to set the height. Use both side zippers to adjust the width –
 the larger the size, the more\ thé zippers should be opened.

WEIGHT CLIPS

 Place the weight clips at the bottom to ensure that the critical areas of the garment are properly stretched.

TEMPERATURE AND TIME

• Set the temperature and time according to the fabric type. Use a lower temperature for delicate fabrics.

FOLD THE COLLAR

• Fold up the collar and button all buttons while ironing.

FAQ

- Q: Can I use this device for delicate fabrics like wool?
- A: No, delicate textiles such as wool should not be pressed on this device. Always follow care labels for textiles before use.
- Q: Is this device suitable for commercial applications?
- A: No, this device is intended for personal use only and is not suitable for commercial applications.
- Q: Can children use this device?
- A: This device is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities.

Documents / Resources



scanovus BBK 199 Automatic Ironing Machine [pdf] Instruction Manual BBK 199 Automatic Ironing Machine, BBK 199, Automatic Ironing Machine, Ironing Machine, Machine

References

- User Manual
- scanovus
- Automatic Ironing Machine, BBK 199, BBK 199 Automatic Ironing Machine, Ironing Machine, Machine, scanovus

Leave a comment

Your email address	will not be published. Required fields are ma	rkea

Commer	nt *			

Name
Email
Website
☐ Save my name, email, and website in this browser for the next time I comment.
Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.