




SCANSTRUT HS-02 PowerTower Hinge System User Manual

[Home](#) » [SCANSTRUT](#) » SCANSTRUT HS-02 PowerTower Hinge System User Manual 

SCANSTRUT HS-02 PowerTower Hinge System User Manual






Contents

- [1 HS-02 PowerTower Hinge System](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)


HS-02 PowerTower Hinge System

127mm Hole Spacing for
Aluminium & Stainless
Steel Power Towers


150mm Hole Spacing for
Composite Power Towers




≤25mm Gap Between Hinge System
& Mounting Surface Edge Required



2 x DS-30 Deck Seals
Included



Full 180° Hinging Motion
For Maximum Clearance




SCANSTRUT

For help & information

E-mail: sales@scanstrut.com

Tel: +44 (0) 1392531280

Documents / Resources

	SCANSTRUT HS-02 PowerTower Hinge System [pdf] User Manual HS-02, APT-250-01, DS-30, HS-02 PowerTower Hinge System, HS-02 Hinge System, PowerTower Hinge System, PowerTower Hinge, Hinge System, Hinge
---	---

[Manuals+.](#)