

SCARLETT SC-921 Lint Remover Instruction Manual

Home » SCARLETT » SCARLETT SC-921 Lint Remover Instruction Manual

Contents [hide

- 1 SCARLETT SC-921 Lint
- Remover
- **2 DESCRIPTION**
- **3 IMPORTANT SAFEGUARDS**
- **4 CLEANING AND CARE**
 - 4.1 STORAGE
- **5 Documents / Resources**
 - **5.1 References**
- **6 Related Posts**





SCARLETT SC-921 Lint Remover



DESCRIPTION

- 1. Lint container
- 2. Safety cover
- 3. Protective metal grid
- 4. On/Off switch
- 5. Body
- 6. Battery compartment





IMPORTANT SAFEGUARDS

- For home use only. Do not use for industrial purposes. Do not use the appliance for any other purposes than described in this instruction manual.
- Do not take this product to a bathroom or use near water.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not leave the appliance switched on when not in use.
- Do not use other attachments than those supplied.
- Do not attempt to repair, adjust or replace parts in the appliance. Check and repair the malfunctioning appliance in the service center only.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not use as a shaver for human body.
- Do not use on clothes while wearing.
- Do not use it for plush clothes, clothes with nap, embroidery, etc.

INSTRUCTION FOR USE

- Open the battery compartment cover.
- Insert one D battery (not included). Please follow correct battery polarities otherwise the set will not work.
- Close the battery compartment cover.

- · Check your batteries regularly.
- Place the clothes on a flat surface and smooth to take out the folds.
- Take off the blade guard cover and set the On/Off switch to ON position.
- Treat lint by fluent circular movements without pressure.
- When finished, set the On/Off switch to OFF position and close the blade guard cover.

CAUTION: Do not press strongly on the clothes since the clothes or the head of the lint remover can be damaged.

CLEANING AND CARE

- Remove batteries before cleaning and or if the unit is not used for a long time. Clean the storage container regularly.
- Wipe over the body using a soft damp cloth.
- · Do not use hard abrasives or cleaners.
- · Remove the blade guard cover and unscrew the grill.
- Take out the cutting blade carefully and clean it with the brush (included). Replace the blade and reassemble the lint remover.
- · Wipe the appliance dry.

STORAGE

- · Switch off the appliance and remove batteries.
- Complete all requirements of Chapter CLEANING AND CARE.
- · Keep the appliance in a dry cool place.

www.scarlett.ru

Documents / Resources



SCARLETT SC-921 Lint Remover [pdf] Instruction Manual SC-921, Lint Remover, SC-921 Lint Remover, Remover

References

Manuals+, home privacy