



Schrader 33500 EZ-sensor Single SKU Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor User Manual

[Home](#) » [Schrader](#) » Schrader 33500 EZ-sensor Single SKU Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor User Manual 

Schrader 33500 EZ-sensor Single SKU Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor User Manual



Contents

- 1 MOUNTING INSTRUCTIONS
- 2 DISMOUNTING
- 3 PROGRAMMING INSTRUCTIONS
- 4 Family of Products
- 5 Service Pack Options
- 6 Compatible TPMS Programming Tools*
- 7 Technical Support
- 8 Documents / Resources
 - 8.1 References

MOUNTING INSTRUCTIONS

- Tire mounting paste.



- Valve core torque tool.



- Rubber valve and valve puller.



- T-10 Torque Tool.



1. Lubricate and insert.



2. Pull the valve, making sure it remains parallel to the valve hole.



3. Position the sensor 180° from the mounting/dismounting head.



4. Install the tire.



5. Take out valve core.



6. Inflate tire until both beads are securely in place.



7. Insert valve core.



8. Inflate tire to recommended pressure



DISMOUNTING


1. Remove valve core



2. Position the valve at 90° from the bead breaker.




3. Place the valve under the mount/dismount head



4. Remove the screw and detach sensor body.



Recycle



PROGRAMMING INSTRUCTIONS


This is a blank sensor (writable/empty).



Make/Model/Year info must be written with a compatible scan tool into sensor prior to installation. See second page for a list of compatible tools




Once programmed, install sensor onto the rim



Look up and perform relearn procedure




Family of Products



Service Pack Options

Black Anodized Aluminum Clamp-In Valve #34010

Aluminum Adjustable Angle Valve #20049



T-10 Screw 11.5 In lb (1.3 Nm)

Compatible TPMS Programming Tools*

Now offering TPMS tool and sensor bundles



ST-1



S-57



S-56



S-46



S-41



EZ-sensor® PAD



TPMS5



TPMS4



TPMS3



MAXIMUS TPMS 2.0





OTC3838



ET3838



- TECHRITEPRO



- TECH450PRO



- TECH550PRO



- TECH600PRO



- TECH1000



- TECH400PRO



- TECH300PRO



- TECH500



Scan to view full list



For training information, visit our website or scan the QR code



www.TPMSAcademy.co

Technical Support

USA | CA: 1.800.288.1804

MEX: SchraderMX@sensata.com



Documents / Resources



[Schrader 33500 EZ-sensor Single SKU Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor \[pdf\] User Manual](#)

33500 EZ-sensor Single SKU Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor, 33500 EZ-sensor, Single SKU Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor, Programmable Snap In Fixed Angle Valve Tire Pressure Monitoring Sensor, Fixed Angle Valve Tire Pressure Monitoring Sensor, Valve Tire Pressure Monitoring Sensor, Tire Pressure Monitoring Sensor, Monitoring Sensor, Sensor

References

- [Schrader Performance Sensor](#)
- [User Manual](#)