

Screwfix C360116 Pneumatic Push Button



## Screwfix C360116 Pneumatic Push Button User Manual

[Home](#) » [SCREWFIX](#) » Screwfix C360116 Pneumatic Push Button User Manual 

### Contents


- [1 Screwfix C360116 Pneumatic Push Button](#)
- [2 Installation of pneumatic push button](#)
- [3 Documents / Resources](#)
  - [3.1 References](#)
- [4 Related Posts](#)

# Screwfix

**Screwfix C360116 Pneumatic Push Button**




### Installation of pneumatic push button



The push button can be installed on the top or front panel of a furniture WC unit in a variety of positions. Check for obstructions before cutting any panels.

## Documents / Resources



[Screwfix C360116 Pneumatic Push Button](#) [pdf] User Manual  
C360116 Pneumatic Push Button, C360116, Pneumatic Push Button, Push Button, Button

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.