

scs sentinel CAC0054 SONE Additional Wireless and Batteryless Push Button Instruction Manual

Home » SCS sentinel » scs sentinel CAC0054 SONE Additional Wireless and Batteryless Push Button Instruction Manual ♣








https://www.youtube.com/playlist?list=PLhdc503NdLNZGhzwdGs3dLjazqmU_z-nk

Contents


- 1 PROGRAMMING
- **2 INSTALLATION**
- 3 Documents /
- **Resources**
 - 3.1 References
- **4 Related Posts**

PROGRAMMING

Place the chime close to the push button



INSTALLATION





150 m	100%	free-field
	80%	wood, glass
	60-70%	plasterboard
	50-70%	stone
	20-50%	concrete
	<10%	metal

Frequency: 433,92 MHz / Maximum transmitted power: < 10mW



3 years warranty. It is imperative to keep a proof of purchase during the whole warranty period.



For an individual answer, use our online chat on our website www.scs-sentinel.com

Hereby, SCS Sentinel declares that this product complies with the essential requirements and other relevant provisions of Directive 2014/53/UE. The UE declaration of conformity may be consulted on the website: www.scs-sentinel.com/downloads

This manual is an integral part of your product. Keep it in a safe place for future reference. Use the equipment

only for its intended purpose. The appliance should not be exposed to dripping or splashing water. No objects filled with liquids, such as vases, should be placed near the appliance. Do not clean the appliance with abrasive or corrosive substances. Only use a soft cloth.

Don't throw out of order products with the household waste (garbage). The dangerous substances that they are likely to include may harm health or the environment. Make your retailer take back these products or use the selective collect of garbage proposed by your city. Do not let children play with the product or with the packagings.



IP 65: The outdoor unit is protected against dust and water jets from all directions.

V.062023 - IndA

Documents / Resources



scs sentinel CAC0054 SONE Additional Wireless and Batteryless Push Button [pdf] Instruction Manual

CAC0054, CAC0054 SONE Additional Wireless and Batteryless Push Button, SONE Additional Wireless and Batteryless Push Button, Additional Wireless and Batteryless Push Button, Wireless and Batteryless Push Button, Batteryless Push Button, Push Button

References

- Solutions en motorisation de portail, carillon, interphone et vidéosurveillance pour votre maison -SCS Sentinel
- Contact SCS Sentinel
- Manuels pour la recherche "" SCS Sentinel

Manuals+,