



scs sentinel LightSensor Motion Sensor Switch Instruction Manual

[Home](#) » [SCS sentinel](#) » **scs sentinel LightSensor Motion Sensor Switch Instruction Manual** 



LightSensor
Motion sensor switch for outdoor lighting
Installation and user manual


Contents

- [1 INSTALLING](#)
- [2 WARRANTY](#)
- [3 Documents / Resources](#)
- [3.1 References](#)

INSTALLING



To avoid unwanted activations, avoid placing the unit near trees or shrubs. Avoid pointing or placing the unit near heat sources or violent lights. When first turned on, the lamp lights for about 2 minutes, then turns off. Do not walk past the sensor during this time, it is in boot mode.



1. Mains supply must be disconnected
2. Connect the 2 wires for the mains 230V on a protected line with fuse or circuit breaker. Wiring specifications:
The wires connected to 230V must be rigid and cross section must not be smaller than 1.5mm². Wires connected to 230V should be fixed with anchorages. The wires connected to 230V must not be:
 - flat twin tinsel wires,
 - lighter than braided wires, ordinary tough rubber sheathed wires and light polyvinyl chloride sheathed wires
3. Screw the wires without any looseness
4. Do not turn on the switch of power source before all wiring step is done.

WARNING

- Maintain a minimum distance of 10 cm around the device for sufficient ventilation.
- When installing the product, keep the packaging out of reach of children and animals. It is a source of potential danger.
- This appliance is not a toy. It is not designed to be used by children.



Disconnect the appliance from the main power supply before service. Do not clean the product with solvent, abrasive or corrosive substances. Only use a soft cloth. Do not spray anything on the appliance.



Don't throw out of order products with the household waste (garbage). The dangerous substances that they are likely to include may harm health or the environment. Make your retailer take back these products or use the selective collect of garbage proposed by your city.

WARRANTY



Garantie 2 ans

2 YEARS


The invoice and barcode will be required as proof of purchase date during the warranty period.



For an individual answer, use our online chat on our website www.scs-sentinel.com



Documents / Resources

	<p>scs sentinel LightSensor Motion Sensor Switch [pdf] Instruction Manual LightSensor Motion Sensor Switch, LightSensor, Motion Sensor Switch, Sensor Switch</p>
--	--

References

- [User Manual](#)